

DMX Big Bubble Machine

User Manual



DMX Big Bubble Machine

The bubble machine can produce bubbles all over the sky and create color dream-like world under the sun.

It is the imported the fan, with low noise and big flow. Its high-precision motor can blow out very big bubbles covering a large space, and under the high rev of the plastic double wheel, can produce a great number of colorful bubbles. It is applicable for the big stage or entertainment place. And it is equipped with remote control.

After receiving the bubble machine, open the package, check carefully whether the machine is damaged or the accessories are lost, if problems found, please contact the distributor.

Put the machine on a level plane and then pour 2L bubbles into the basin of the machine.

Connect the power supply.

If wireless control is used, please connect the wireless receiver onto the corresponding connector, then turn on the red

switch, press the transmitter in your hand, and now the machine works.

If wireless control is not used, use the additional manual switch or silicon box for the control, take the wireless receiver from the machine, turn off the red switch and turn on the green switch.

Please let the bubble oil out from the back exit of the machine if the machine is not used for long, and then cut off the power supply.

Technical Parameters:

Voltage: AC220V

Frequency: 50Hz-60Hz

Power Consumption: 300W Fuse:3A

Lasting Time: 90min

Water Tub Volume: 3L

Coverage: 500m²

Size: 62*47*54cm

Weight: 13kg