



power. anywhere. everywhere

User Manual









**BOOM**PODS" designed in the UK by DT-Design Ltd, all rights reserved @2014 This product uses **BOOM**PODS" technology and is covered by international patents. *powercase-IP*: 2012(330050919) B.F.C.C: Made in China



powercase 2400mAh

Package contents:

1 x Micro USB charaina cable

1 x 3.5mm audio extension cable


1 x powercase

1 x user manual

1 x frame

# Introduction:

Before using your Powercase for the first time, please take a few moments to read through the user manual.




## Installing:

 To install your iPhone, firstly remove the frame @ & place the iPhone into the Powercase, replace the frame @ then gently press all the way around until you hear the clips have enagged & no gaps are visable.

2. To remove your iPhone, simply pull up the bottom of the frame at point @.

### Charaina iPhone 5/5s via Powercase:

1. Hold down the power button (0 for approximately 2 seconds to charge your iPhone.
2. Hold down again for approximately 2 seconds to turn off the Powercase when your iPhone is fully charged. Please ensure this instruction is followed as this will save the capacity of the built-in bottlery for charging next time.



### Charaina Powercase:

 Connect your Powercase® with your iPhone already installed, to the Micro USB charging cable. Then connect the Micro USB charging cable to any USB power source to start charging. Both your iPhone and Powercase will be charged simultaneously.

2. Charge until the LED indictor is full @.



**Note:** When your iPhone battery is fully drained in the Powercase, the iPhone charging icon will revert to its normal usage.

### Technical details:

Power capacity: 2400mAh Input: 5V-1A Output: 5V-1A Dimensions: 166 x 62 x 137mm Weight: 80g

Charging time: Up to 2hrs
Standby time: Up to 255hrs
Talk time: Up to 8hrs
Internet surfing time: Up to 8hrs
Audio play time: Up to 40hrs
Video play time: Up to 10hrs

#### Warranty

Your BOOMPODS<sup>III</sup> product is guaranteed against any defects in material or workmanship for one year from the date of original purchase providing it has not been dissembled and it has not suffered accidental damage such as a knock or immersion in water, etc.

The device must be used in accordance with the user manual. The guarantee is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and lear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shoioning cost of the returned item.

Please check www.boompods.com for your local service centre.

