

VAPERIZA

SMOKE MACHINE

V500
V1000
V1500
V2000

PRODUCT USER MANUAL



TECHNICAL SPECIFICATIONS

	V500	V1000	V1500	V2000
Smoke Output	8000cu.ft per minute	10000cu.ft per minute	18000cu.ft per minute	20000cu.ft per minute
Warm Up Time	4.5 Minutes	4.5 Minutes	8 Minutes	8 Minutes
Tank Capacity	0.25 Liters	0.25 Liters	1.2 Liters	1.2 Liters
Power Consumption	500 Watt	1000 Watt	1500 Watt	2000 Watt
Power Supply	110V 240V	110V 240V	110V 240V	110V 240V
Unit Dimensions	25x14x19cm 2.25Kg	25x14x19cm 2.25Kg	53x32x27cm 5.6Kg	53x32x27cm 5.6Kg

VAPERIZA

SMOKE MACHINE

CAUTION!

Keep this device away from rain and moisture

Unplug Mains lead before opening the housing

Make sure of the voltage on your end is suitable for the unit

For your own safety, please read this user manual carefully before you initially start

Any person involved with the installation, operation and maintenance of this device

has to

- Be qualified

- Follow the instructions in this manual

1. INTRODUCTION

Thank you for having chosen the AVE Vaperiza range. You will see you have acquired a powerful and versatile device. Unpack your item. Before your initial start-up, please make sure that there is no damage caused by transportation. Should there be any, please consult your dealer and do not attempt to use the device.

2. SAFETY INSTRUCTIONS

If the device has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your device. Leave device switched off until it has reached room temperature. Always plug in the power plug last. Make sure that the power-switch is set to the OFF position before you connect the device to the mains. Never let the power-cord come into contact with other cables. Handle the power-cord and all connections with the mains with particular caution. Make sure that the available voltage is not higher than stated on the rear panel. Make sure that the power-cord is never crimped or damaged by sharp edges. Check the device and the power-cord from time to time. CAUTION! Before filling the machine disconnect from mains. Never drink fluid or use it on the inside or outside of a human body. If fluid gets in contact with skin or eyes, rinse thoroughly with water. If it is necessary call a doctor immediately DANGER OF EXPLOSION! Never add flammable liquids of any kind to the fog liquid. Keep minimum distance of 50cm to nozzle. Always disconnect from mains, when the device is not in use or before cleaning it. Only handle the power-cord by the plug. Never pull out the plug by tugging the power-cord. Keep away children and amateurs. Never leave this device running unattended

3. STARTING OPERATION

Install the device on a plane surface. The fluid tank of the device needs to be filled with standard smoke fluid before starting up operation and always disconnected from the mains as fluid could be spilled. We recommend high-quality AVE Magic Mist fluid. You must not use substances that are classified as "dangerous working material" or "inflammable fluids". If fluid should get into the interior of the device, disconnect from mains immediately and consult a technician. Switch the device on via the power switch. Connect the remote control with the remote control-socket through the three-pin socket at the back of the unit. After a certain warm-up time, the device is ready to operate. Upon warming up the fogger is ready to emit and by switching the control box the fogger starts emission. A high quality thermostat regulates the temperature.

CAUTION: The escape nozzle will heat up during operation. Therefore do not touch the nozzle until it has cooled down completely.

CLEANING THE HEATING ELEMENT

The heating element should be regularly cleaned every 30 operational hours in order to avoid clogging. Use smoke machine cleaner available at your dealer.

PROCEDURE:

Fill cleaner into empty tank. Run machine several times in a well-ventilated room only. The number of repetitions depends on the pollution level of the vaporizing elements. After use clean all remaining cleaners and rinse the tank thoroughly. There are no serviceable parts inside the device except for the fuse. Maintenance and service operations are only to be carried out by an authorized dealer.

PLEASE NOTE: All information is subject to change without prior notice.

PRODUCT USER MANUAL

