

User's Manual

Floorstanding speakers **Niagara Platinum**

Made in France

Warning :

GLASS. FRAGILE : HANDLE & USE WITH CARE.

Please read this notice
before unpacking.
A minimum of 2 persons is requested
to unpack or repack each Speaker.

Unpacking and using this product means you have read & understood this warning

WARNING : GLASS. FRAGILE. HANDLE & USE WITH CARE :

- The floorstanding speaker you have purchased is made of GLASS PANELS.
- Any Impact on the product could potentially damage the product.
- There is a potential risk of injury to persons if the product is not used as instructed.
- In the event the speakers break, **DO NOT** attempt to pick up the pieces of glass of the speaker without first protecting your hands and using appropriate tools in collecting the pieces of the speaker.
- This product has been designed for indoor residential use only.
- This product is not intended to be placed in any area of passage, including but not limited to walk ways and stairways.
- In addition Niagara speakers have been designed to be used only on indoor flooring, and must not be affixed to walls, attached to ceilings, placed in entertainment centers or otherwise used or placed in any location other than on the floor.

USE CAUTION WHEN UNPACKING, REPACKING, INSTALLING AND USING THE PRODUCT.



1) Unpacking / Repacking : Always unpack your speakers with somebody's help.

Always unpack your speakers with somebody's help. Unpack as shown on the photos hereunder. To repack, reverse the procedure. Always keep your original packaging, always store flat, if you use a carrier always ship on pallet. This document is to be included in any resale of the product.



- 1 Open the box as shown and remove the glass horn box.



2

Remove the protection.

Person n°1 is positioned at the bottom of the speaker, **person n°2** at the top.

Pull out the speaker at the same speed.



- 3 Remove the foam protection on the "top" of the speaker. Start by the rear.






- ④ Remove the plastic protection by hands.

NO TOOLS




Then place the speaker in the listening position.

Do not connect the speaker to the amplifier yet.



- ⑤ When the speaker is in place then position the glass horn as shown.

Beware **NOT TO HIT** the Glass Horn onto the speaker. Never try to move the speaker when the glass horn is in place.



- ⑥ Connect the glass horn as shown. Then connect the speakers to your amplifier. **Never plug your speakers into the main supply.**

2) Positioning :

This product has been designed for indoor residential use only. This product is not intended to be placed in any area of passage, including but not limited to walk ways and stairways. In addition Niagara speakers have been designed to be used only on indoor flooring, and must not be affixed to walls, attached to ceilings, placed in entertainment centers or otherwise used or placed in any location other than on the floor. Make sure your speakers are positioned on a perfectly flat and level surface. Placing your speakers in a corner will enhance the low frequencies, and placing further off the wall will enhance the sound image. However each room and configuration being different and unique, we advise you to test different positions to achieve the best performance.

3) Connection :

Make sure the cable is of the right section and specific to loudspeakers connection. Follow the polarities : + (red terminal), - (black terminal), for each speaker. Use the same length cable for both right and left speakers. Do not connect your speakers directly to the mains.

We highly recommend the use of Waterfall Audio Cable made up with a high quality

oxygen free copper, which you can purchase from your Waterfall dealer.



4) Cleaning :

Any glass cleaner can be used, apply with a soft paper towel. **Never use abrasive products.**

5) Warranty :

See **Waterfall Warranty Card**

This document is to be included in any resale of the product.



All drivers are developed and manufactured by Atohm (France).

Unité de fabrication et bureaux : ZA Praderies, 83 570 Carcès - France - Tel : +33 (0)4 98 05 11 30 - Fax : +33 (0)4 98 05 11 31 - contact@waterfallaudio.com

www.waterfallaudio.com