

Quick Start Guide

ApplianceLinc™ - INSTEON® Plug-In Appliance
On/Off Module
Model: 2456S3

Introduction

Allows you to remotely control any appliance/device in and outside your home at the touch of a button. Can be used with incandescent lamps up to 480 Watts and inductive loads up to 15 Amps.



Installing ApplianceLinc

- 1) Plug appliance/device (also called the load) you want to control into bottom ApplianceLinc outlet
- 2) Plug ApplianceLinc into unswitched wall outlet
Status LED will turn on
The load will turn on
- 3) If load does not turn on, turn it on manually using the switch on the load itself
- 4) Tap Set button to toggle load on and off
You can use the pass-through outlet on the front of ApplianceLinc as a normal uncontrolled wall outlet. However, do not plug another home automation product into this outlet—stacked modules may overheat and malfunction.

Make ApplianceLinc a Responder

Control ApplianceLinc from another INSTEON device:

- 1) Use Set button to adjust ApplianceLinc to desired state (on or off)
- 2) Put controller into linking mode. (For most controllers press and hold Set button for 3 seconds or an on/scene button for 10 seconds.)
- 3) Press and hold ApplianceLinc Set button until it double-beeps
Status LED will flash twice and then turn on solid
- 4) Confirm link by tapping controller's button on and off
Connected light/load will turn on and off

Owner's Manual and Tech Support

For the complete Owner's Manual and the most up-to-date Quick Start Guide visit <http://www.insteon.com/support>.
Call: INSTEON Support Line at 800-762-7845