



USER MANUAL

EC
PEDALS

Rusty Cooley Double Overdrive User Manual

Description

Rusty Cooley's signature pedal is the new secret weapon for the ultimate player - 2 overdrive channels with switchable OD1\OD2!

This pedal features 2 footswitches - the right one operate as ON/OFF for the pedal and the left one will switch between the right overdrive channel to the left one giving you the option of getting 2 separate overdrive settings that you can switch between them.

The cool thing about this pedal is that the left switch will operate even when the pedal is off so you can switch for the desired channel even before turning the pedal on.

Controls

- 1 - On\Off
- 2 - Input Jack
- 3 - Output Jack
- 4 - DC Input - Use only 9-12VDC Negative Center Power Supply
- 5 - Gain Knob X 2
- 6 - Volume Knob X 2
- 7 - Tone Knob X 2
- 8 - OVERDRIVE A \ OVERDRIVE B

Internal switches

Inside the pedal you will 2 switches for each overdrive side, the upper one of each controls the clipping mode for the specific side, the left side of the switch will turn the diode clipping while the right side will turn on LED clipping mode.

The switch below on each side will control the tone mode for the specific side, the left side of the switch will give you the default tone stack while the right side will enable FAT tone stack with more bass response.

Each side of the pedal can have different clipping and tone stack settings.


Features

- 2 X Gain, Tone control and Level control
- True Bypass for noise free operation
- High grade components only
- Neutrik Jacks
- Hand Built

Knobs

Each side is a completely standalone overdrive pedal
Switch 8 switches between the 2 overdrives which each has its own independent VOL - TONE - GAIN knobs which dont affect the other overdrive.

** Internal switches are also independent to each overdrive and can be set separately to each one



EC PEDALS