



## user manual for the rain cape VC-1M

you receive the following accessories with your rain cape:  
adapter ring CA 52

**To be able to fasten the camera in the rain cape, you have to buy a step-up ring which connects your lens to the CA52 Adapter (52mm thread).**

You can buy this step-up ring from your local photo dealer.



1. Remove the sunshade from your lens and screw on the step-up ring mentioned above in the filterthread of your lens.
2. screw the CA 52 adapter on the step-up ring mentioned above.
3. put the camera into the rain cape and push it with the adapter rings against the optical front glassport.
4. push the camera upwards in the rain cape till the viewfinder is in front of the rear PVC window.

5. close the cape with the press-stud to prevent the possibility of water splashing up onto the bottom of the camera.



You can also use the LCD screen of the camera while the camera is in the cape.

6. Open the two PVC press buttons to be able to unfold the cape.
7. Open the LCD monitor and pull the cape over it.

If you do not longer need the LCD monitor, just fold the rain cape together again and close it with both PVC press buttons.