

[www.alcatelonetouch.com](http://www.alcatelonetouch.com)

For more information on how to use the phone, please go to [www.alcatelonetouch.com](http://www.alcatelonetouch.com) and download the complete user manual. Moreover, on the website, you can also find answers to frequently asked questions, upgrade the software via Mobile Upgrade, and so much more.

# Table of contents

<b>1</b>	<b>Getting started.....</b>	<b>6</b>
1.1	Set-up .....	6
1.2	Power on your phone.....	11
1.3	Power off your phone.....	11
<b>2</b>	<b>Your mobile.....</b>	<b>12</b>
2.1	Keys .....	12
2.2	Status bar icons.....	16
<b>3</b>	<b>Making a call.....</b>	<b>17</b>
3.1	Placing a call .....	17
3.2	Calling your voicemail .....	21
3.3	Receiving a call .....	22
<b>4</b>	<b>Assistance (SOS).....</b>	<b>23</b>
4.1	SOS contacts .....	23
4.2	SOS message.....	23
<b>5</b>	<b>Menu screen .....</b>	<b>24</b>
5.1	Access main menu.....	24
5.2	Access submenu .....	25
<b>6</b>	<b>Contacts.....</b>	<b>26</b>
6.1	Consulting your contacts .....	26
6.2	Adding a contact.....	27
6.3	Delete a contact.....	29
<b>7</b>	<b>Messages .....</b>	<b>30</b>
7.1	Write message .....	30
7.2	Read message .....	33
7.3	Settings.....	34
<b>8</b>	<b>FM Radio.....</b>	<b>36</b>
<b>9</b>	<b>Alarm .....</b>	<b>38</b>

<b>10</b>	<b>Camera .....</b>	<b>39</b>
<b>11</b>	<b>Weather.....</b>	<b>40</b>
<b>12</b>	<b>Tools.....</b>	<b>41</b>
12.1	Calculator .....	42
12.2	Calendar .....	42
12.3	Images.....	42
12.4	Videos.....	42
12.5	Voice alarm .....	43
12.6	My files .....	43
12.7	Bluetooth.....	43
12.8	Services .....	43
<b>13</b>	<b>Settings .....</b>	<b>44</b>
13.1	General .....	44
13.2	Sound.....	45
13.3	Display.....	45
13.4	Call settings.....	45
13.5	Assistance.....	45
13.6	Network selection .....	45
13.7	Security .....	46
13.8	Regulatory & Safety.....	46
13.9	Restore default.....	46
<b>14</b>	<b>Making the most of your mobile .....</b>	<b>47</b>
<b>15</b>	<b>Latin input mode .....</b>	<b>49</b>
	<b>Safety and use.....</b>	<b>50</b>
	<b>General information .....</b>	<b>64</b>
	<b>TCT Mobile (US), Inc. Warranty.....</b>	<b>66</b>
	<b>Troubleshooting.....</b>	<b>70</b>

## Quick Start Guide

For more information about how to use the phone, please go to [www.alcatelonetouch.com](http://www.alcatelonetouch.com) to download complete user manual. Moreover, from the website you can also consult FAQ, realize software upgrade, etc.



**ALCATEL**  
**onetouch®**

English - CJB284AALAAN



[www.sar-tick.com](http://www.sar-tick.com)

This product meets applicable national SAR limits of 1.6 W/kg. The specific maximum SAR values can be found on page 58 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.0 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.




## PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

## Getting started...

### 1.1 Set-up

#### Removing or installing the back cover



## Installing or removing the battery



## Inserting or removing the SD card



Connect battery charger to your phone and plug into the socket

- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).



To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.

## 1.2 Power on your phone

Hold down the  key until the telephone powers on.

## 1.3 Power off your phone

Hold down the  key from the Home screen.


# 2

## Your mobile....

### 2.1 Keys



Assistance (SOS) key



Volume up

Volume down



Torch key

Lock key







From Idle screen

- Press: \*

In Edit mode:

- Press: Change input methods
- Press and hold: Access language list



From Idle screen

- Press: #
- Press and hold: Access speed dial

In Edit mode

- Press: (space)

## 2.2

## Status bar icons <sup>(1)</sup>



**Battery charge level.**



**Call forwarding activated.**



**Alarm or appointments programmed.**



**Level of network reception.**



**Radio is on.**



**Roaming.**



**SMS unread.**



**Silence mode.**



**Missed calls.**



**Vibrate alert**

<sup>(1)</sup> The icons and illustrations in this guide are provided for informational purposes only.



**Headset mode**



**Flight mode.**



**Bluetooth status**





**GPRS connection status**

## 3


## Making a call...


### 3.1 Placing a call

Dial the desired number then press  key to place the call. If you make a mistake, press  key to delete the incorrect digits.




You can also make a call from your call log:

First, press  key from Idle screen to access the call log and choose the contact you want to dial, then select **Options**.




Then select **Call**.





If you want to make a call from phonebook, please select **Contacts\Options\Call**.


Select **Contacts** from main menu:



Choose the contact you want to dial, then select **Options**; finally, select **Call**.



To hang up the call, press the  key (Select **End**).



## Making an emergency call

If your phone has network coverage, dial emergency number and press the send key to make an emergency call. This works even without a SIM card and without typing the PIN code.

### 3.2 Calling your voicemail <sup>(1)</sup>

To access your voicemail, hold down the **1** key. To edit your voicemail, select **Messages\Voicemail\Options\Edit**, then you can edit the voicemail name and number. Finally, select **Save**.


Voicemail	
<Empty>	Call
	Edit
Options	
Select	Back

Voicemail number	
Daniel	
800528563	
Save	Clear

### 3.3 Receiving a call

When you receive an incoming call, press the **📞** key to talk and then hang up using the **📞** key.


Select **Accept** to pick up the call.



#### Rejecting a call

Press the **📞** key once.

Select **Reject** to reject the call.



<sup>(1)</sup> Contact your network operator to check service availability.

## 4 Assistance (SOS).....

### 4.1 SOS contacts


To add an SOS number to your SOS contacts, please select **Assistance\Contact** list and press **Edit**, then you can edit your SOS numbers.


### 4.2 SOS message


From the main menu select **Settings\Assistance\Message** to create an SOS message.

## 5 Menu screen ...


### 5.1 Access main menu


Press  from the Idle screen to enter the main menu.

The main menu can be used to select your favorites by pressing  in the left or right direction.



## 5.2 Access submenu

To access the submenu, press  upwards or downwards from main menu.



# 6 Contacts.....

## 6.1 Consulting your contacts

You can access this function by selecting **Contacts** from the main menu.

### Searching for a contact


You can search for a contact by typing the initial of their name. Subsequent letters may be added to refine the search.


### Viewing a contact

Select a name from your contacts to read the contact information.


## 6.2 Adding a contact

You can add a new contact to phone or SIM card by pressing **OK**, and select **New** to enter the "Add contact" screen.


First, press  from Idle screen to access **Contact** and select **OK**.





Secondly, select **New**.



Thirdly, you can choose to add the new contact to phone or SIM card.




Finally, edit the name and numbers and save them.




### 6.3 Delete a contact

Please select the contact you want to delete and press  to select **Options**.





Then select **Delete** to remove the contact.



## 7 Messages .....

### 7.1 Write message

From the Message screen select **OK/New** to create a text/multimedia message.





## How to type a message:


You can enter text using normal or predictive text input. To set your desired text input, please select **Options\Input mode**.

For normal text input, press a number key, 2-9, repeatedly until the desired character is displayed. If the next letter you want is located on the same key as the present one, please wait until the cursor is displayed.

For predictive text input, start entering a word by using the 2-9 keys and press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing.

Example: For “**ALCATEL**”, press on the following keys:

**2** ABC, **5** JKL, **2** ABC, **2** ABC, **8** TUV -->  
**ALCATEL**.



To insert a punctuation mark or special character, please press the **0+** key.

If you want to delete the already typed letters or symbols please press **↶** to delete them one by one.

## 7.2 Read message

From the Message screen select **OK\Inbox** to read the text/multimedia message.

### How to read a message:

If a message comes, a notification will be shown in the idle screen. Press **Read** to view it or press **Back** to keep it unread.

If you want to view all the messages received or sent, please select **Messages\Inbox\Outbox\Sent**.

While writing a message, select **Options** to access all the messaging options.

You can save any messages that you often send to **Drafts**.

## 7.3 Settings

### Text message

- **SIM**

You can set validity period, message type, sent on/off, etc.

- **Memory status**

Show memory used on the phone and SIM card.

- **Alphabet management**

Enables the definition of SMS data coding for management SMS sending.

## MMS

- **Data account**

Select your data account for multimedia messages.

- **Common settings**

You can set the slide timing, validity period, home network; select preferred storage way, and check memory status, etc.

# 8

## FM Radio .....

Your phone is equipped with a radio <sup>(1)</sup> with RDS <sup>(2)</sup> functionality. You can use the application as a traditional radio with saved channels. You can listen to it while running other applications.

First, to turn on the radio, please select **FM Radio** from main menu.



<sup>(1)</sup> The quality of the radio depends on the coverage of the radio station in that particular area.



<sup>(2)</sup> Depending on your network operator and market.

Then, search the channel by selecting **OK\Options\Auto search** (when using this function for the first time). Stations will be automatically saved to **Channel list**, and you can select one.



## 9 Alarm .....


Your mobile phone has a built-in alarm clock with a snooze feature. You can set up your alarm by selecting **Alarm\OK\Edit** from main menu.



You can set up your time when you access above Alarm screen, select **Edit** to set the repeat time, snooze intervals, ring mode, and alarm ringtone.

## 10 Camera.....

Your mobile phone is fitted with a camera for taking photos and shooting videos by selecting **OK/Options**.




You can use this function in different ways:

- store them as your creations in SD card or phone.
- send them directly by MMS, Bluetooth.
- customise your Home screen, ect.

## 11 Weather <sup>(1)</sup>.....

Your phone is equipped with a weather function for consulting up to 3-day forecast of favorite cities.




From above screen, select **OK/Options/Forecast** to view specific information.

<sup>(1)</sup> It may not be available.

## 12 Tools .....

When you enter this menu, press **OK** to select your preferences in the following features: **Calculator**, **Calendar**, **Images**, **Videos**, **Voice alarm**, **My files**, **Bluetooth** and **Services**.



### 12.1 Calculator

Enter a number, select the type of operation and enter the second number, press **Equal** to display the result.

### 12.2 Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc.


### 12.3 Images

You can select an image or a photo as wallpaper, power on/off screen.

### 12.4 Videos

When access to this feature, you can play, send, rename, delete and store the video according to your preference.

## 12.5 Voice alarm

With this menu, you can create new voice file and set it as the alarm. Select **New** and start to record your voice, press  and select **Yes** to save it to certain date and time.

## 12.6 My files

You will have access to all audio and visual files stored in phone or Memory card in My files.

## 12.7 Bluetooth



You can activate/deactivate the bluetooth, check device list, edit phone's name, etc.

## 12.8 Services

Contact your network operator to check service availability.

# 13 Settings.....

From the main menu, select **Settings** **OK** and access the function of your choice in order to customise your telephone.



## 13.1 General

To modify the General settings, select **General** and you will see **Flight mode**, **Time and date**, **Languages**, and **Input mode**.

## 13.2 Sound

With this menu, you can set up the sound mode from **Normal mode**, **Vibrate mode**, and **Silent mode**.

## 13.3 Display

This function allows you to select phone theme, customise wallpaper, adjust brightness level of LCD display, and set backlight time.

## 13.4 Call settings

You can activate/deactivate **Speed dial**, **Auto redial**, **Voice Assist Dialing**, and **Noise cancellation**, etc.

## 13.5 Assistance

please refer to "**Assistance (SOS)**", page 23.

## 13.6 Network selection

You can access this feature to set and select your preferred network and search mode.

## 13.7 Security

You can protect your phone by activating and changing the PIN and password, its initial one is 1234. The feature also allows you to lock your phone by activating the PIN2 of **Fixed dial number**.

## 13.8 Regulatory & Safety

View your phone information, such as **Product model**, **Manufacturer name**, **Manufacturer address**, **IMEI**, **CU Reference**, etc.

## 13.9 Restore default

Make the phone's settings recover to its default value. End-user data will not be erased. Enter its default password 1234 to confirm to restore and reboot.



# 14 Making the most of your mobile.....

## Mobile Upgrade

Using Mobile Upgrade tool you can update your phone's software from your PC.

Download Mobile Upgrade from ALCATEL ONE TOUCH website ([www.alcatelonetouch.com](http://www.alcatelonetouch.com)) and install it on your PC. Launch the tool and update your phone by following the step by step instructions (refer to the User Guide provided together with the tool).

Your phone's software will now have the latest software.



All personal information will be permanently lost following the update process.

## **Supported Operating Systems**

Windows XP/Vista/Windows 7.

# 15 Latin input mode .....

There are two text entry methods that can be used to write messages:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters.
- Predictive with the eZi mode: this mode speeds up the writing of your text.

## Keypad inputting:

**O +** : Press: Access symbols table

**✕'** : Press: Change input methods

**#** : Press: Enter a space

## Safety and use.....

We recommend that you read this chapter carefully before using your mobile phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

### • TRAFFIC SAFETY:

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile phone when the vehicle is not parked. Check the laws and regulations on the use of wireless mobile phones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

When driving, do not use your mobile phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas.

When switched on, your mobile phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your mobile phone on top of the dashboard or within an airbag deployment area,

- check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from mobile phone RF energy.

## • **CONDITIONS OF USE:**

You are advised to switch off the mobile phone from time to time to optimize its performance.

Remember to abide by local authority rules of mobile phone use on aircrafts.

Operational Warnings: Obey all posted signs when using mobile devices in public areas.

Follow Instructions to Avoid Interference Problems: Turn off your mobile device in any location where posted notices instruct you to do so. In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Switch the mobile phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile phones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the mobile phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere.

When the mobile phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. In particular when using the mobile phone you should hold it against the ear on the opposite side to the device, if any.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your mobile device with your implantable medical device, consult your healthcare provider.

To avoid hearing impairment, answer the call before holding your mobile phone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage.

It is recommended to have proper supervision while small children use your mobile phone.

When replacing the cover please note that your mobile phone may contain substances that could create an allergic reaction.

Always handle your mobile phone with care and keep it in a clean and dust-free place.

Do not allow your mobile phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.). The manufacturer's recommended operating temperature range is -10°C (14°F) to +55°C (131°F) (the max value depends on device, materials and housing paint/texture).

Over 55°C (131°F) the legibility of the mobile phone's display may be impaired, though this is temporary and not serious.

Do not open or attempt to repair your mobile phone yourself.

Do not drop, throw or try to bend your mobile phone.

Do not use the mobile phone if the glass made screen, is damaged, cracked or broken to avoid any injury.

Do not paint it.

Use only batteries, battery chargers, and accessories which are recommended by TCT Mobile Limited and its affiliates and are compatible with your mobile phone model. TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Your mobile phone should not be disposed of in a municipal waste. Please check local regulations for disposal of electronic products.

Remember to make back-up copies or keep a written record of all important information stored in your mobile phone. Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your mobile phone or enabling a flashing-lights feature on your mobile phone. Parents should monitor their children's use of video games or other features that incorporate flashing lights on the mobile

phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety precautions:

- Take a minimum of a 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders.



## PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

## • **PRIVACY:**

Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your mobile phone regarding taking photographs and recording sounds with your mobile phone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy.

It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your mobile phone (including the operator) disclaim any liability which may result from the improper use of the mobile phone.

## • **BATTERY AND ACCESSORIES:**

Before removing the battery from your mobile phone, please make sure that the mobile phone is switched off.

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery,

- Do not burn or dispose of a used battery in the garbage or store it at temperatures above 60°C (140°F).

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates.



This symbol on your mobile phone, the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centers with specific bins for these items of equipment
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

### **In European Union countries:**

These collection points are accessible free of charge. All products with this sign must be brought to these collection points.

### **In non European Union jurisdictions:**

Items of equipment with this symbol are not be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at [www.recyclewirelessphones.com](http://www.recyclewirelessphones.com)

**CAUTION:** RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

## • **CHARGERS**

Home A.C./ Travel chargers will operate within the temperature range of: 0°C (32°F) to 40°C (104°F).

The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.

Characteristics of power supply (depending on the country):

Travel charger: Input: 100-240 V, 50/60 Hz,  
150 mA

Output: 5 V, 550 mA

Battery: Lithium 1000 mAh

## • **RADIO WAVES:**

THIS MOBILE PHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your mobile phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on

standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health.

The exposure standard for mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Industry Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the mobile phone transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the mobile phone while operating can be well below the maximum value. This is because the mobile phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the mobile phone. Before a mobile phone model is available for sale to the public, compliance with national regulations and standards must be shown.

The highest SAR value for this model mobile phone when tested is 0.75 W/Kg for use at the ear and 1.3 W/Kg for use close to the body.

While there may be differences between the SAR levels of various cellphones and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the cellphone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory which positions the mobile phone at least 10 mm away from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. Additional information on SAR can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site: <http://www.phonefacts.net>

The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile phones away from the head and body. (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and,

if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. For other devices, they bear the following statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Your mobile phone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or usb data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the mobile phone at least 10 mm away from the body.

FCC ID: RAD529

## • LICENCES

Obigo®

is a registered trademark of Obigo AB.



zi corporation

microSD Logo is a trademark.

eZiText™ and Zi™ are trademarks of Zi Corporation and/or its Affiliates.



The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCT Mobile Limited and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

**ALCATEL  
ONETOUCH 2004C  
BLUETOOTH  
DECLARATION ID  
D022118**



## Hearing Aid Compatibility

Your mobile phone is rated: «For Hearing Aid», to assist hearing device users in finding mobile phones that may be compatible with their hearing devices.

This device is HAC M3/T4 compatible.  
Reference ANSI C63.19-2007

For more information please visit our website  
<http://www.alcatelonetouch.com>.

## General information

- **Website:** [www.alcatelonetouch.com](http://www.alcatelonetouch.com)
- **Hot Line Number:** In the United States, call 877-702-3444 for technical support.
- **Address:** Room 1910-12A, Tower 3, China HK City, 33 Canton Road, Tsimshatsui, Kowloon, Hong Kong
- **Electronic labeling path:** Touch Settings\Regulatory & Safety or press \* # 07 #, you can find more information about labeling. <sup>(1)</sup>

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server: [www.alcatelonetouch.com](http://www.alcatelonetouch.com)

Your mobile phone is a transceiver that operates on GSM networks with 850/900/1800/1900 MHz bands.

<sup>(1)</sup> It depends on countries.

## Protection against theft <sup>(1)</sup>

Your mobile phone is identified by an IMEI (mobile phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your mobile phone by entering \*#06# and keep it in a safe place. It may be requested by the police or your operator if your mobile phone is stolen.

## Disclaimer

There may be certain differences between the user manual description and the mobile phone's operation, depending on the software release of your mobile phone or specific operator services.

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

<sup>(1)</sup> Contact your network operator for service availability.

## TCT Mobile (US), Inc. Warranty .....

TCT Mobile (US), Inc. warrants to the original retail purchaser of this wireless device that should this product or part thereof during normal consumer usage and condition be proven to be defective in material or workmanship that results in product failure within the first twelve (12) months from the date of purchase as shown on your original sales receipt from an authorized sales agent. Such defect(s) will be repaired or replaced (with new or rebuilt parts) at the company's option without charge for parts or labor directly related to the defect(s).

Batteries, power adapters, and other accessories sold as in box items are also warranted against defects and workmanship that results in product failure within the first six (6) months period from the date of purchase as shown on your original sales receipt. Such defect(s) will be repaired or replaced (with new or rebuilt parts) at the company's option without charge for parts or labor directly related to the defect(s).

The limited warranty for your wireless device will be voided if any of the following conditions occur:

- Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the geographical area where your phone is used;
- Connection to any equipment not supplied or not recommended by TCT Mobile (US), Inc.;
- Modification or repair performed by individuals not authorized by TCT Mobile (US), Inc. or its affiliates;
- Changes to the device operating system by the user or third party applications;
- Acts of god such as inclement weather, lightning, power surges, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation;
- Removal or altering of the wireless device's event labels or serial numbers (IMEI);
- Damage from exposure to water or other liquids, moisture, humidity, excessive temperatures or extreme environmental conditions, sand, excess dust and any condition outside the operating guidelines;
- Defects in appearance, cosmetic, decorative or structural items such as framing and non-operative parts;
- Damage as result of physical abuse regardless of cause.


There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your jurisdiction. In no event shall TCT Mobile (US), Inc. or any of its affiliates be liable for incidental or consequential damages of any nature whatsoever, including but not limited to commercial loss, to the full extent those damages can be disclaimed by law. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

How to obtain Support: Contact the customer care center by calling (877-702-3444) or going to (<http://www.alcatelonetouch.com/usa/>). We have placed many self-help tools that may help you to isolate the problem and eliminate the need to send your wireless device in for service. In the case that your wireless device is no longer covered by this limited warranty due to time or condition, you may utilize our out of warranty repair options.

How to obtain Hardware Service within the terms of this warranty: Create a user profile ([alcatel.finetw.com](http://alcatel.finetw.com)) and then create an RMA for the defective device. Ship the device with a copy of the original proof of purchase (e.g. original copy of the dated bill of sale, invoice) with the owner's return address (No PO Boxes accepted), wireless carrier's name, alternate daytime phone number, and email address with a complete problem description. Only ship the device. Do not ship the SIM card, memory cards, or any other accessories such as the power adapter. You must properly package and ship the wireless device to the repair center. TCT Mobile (US), Inc. is not responsible for devices that do not arrive at the service center or are damaged in transit. Insurance is recommended with proof of delivery. Upon receipt, the service center will verify the warranty conditions, repair, and return your device to the address provided in the RMA. Check the warranty repair status by going online with the RMA number on web portal.

## Troubleshooting.....


Before contacting the service center, you are advised to follow the instructions below:

- You are advised to fully charge (  ) the battery for optimal operation.
- Avoid storing large amounts of data in your phone as this may affect its performance.
- Use User Data Format <sup>(1)</sup> to perform phone formatting (to perform User Data format, hold down # key while simultaneously pressing the power on/off key under power off mode). ALL User phone data: contacts, messages and files will be lost permanently. It is strongly advised to fully backup the phone data and profile before doing formatting.

### **My phone cannot switch on**

- Check the battery contacts, remove and reinstall your battery, then turn your phone on
- Check the battery power level, charge for at least 20 minutes
- If it still does not work, please use User Data Format <sup>(1)</sup> to reset the phone

### **My phone is frozen or has not responded for several minutes**

- Restart your phone by pressing and holding the  key
- Remove the battery and re-insert it, then restart the phone

- If it still does not work, please use User Data Format <sup>(1)</sup> to reset the phone

### **My phone turns off by itself**

- Make sure power off key is not jammed or stuck.
- Check the battery charge level
- If it still powers off by itself, please use User Data Format <sup>(1)</sup> to reset the phone

### **My phone cannot charge properly**

- Make sure you are using an ALCATEL ONE TOUCH battery and the charger from the box
- Clean the battery contact if it's dirty.
- Make sure your battery is inserted properly before plugging in the charger.
- Make sure that your battery is not completely discharged; if the battery power has been empty for a long time, it may take around 20 minutes to display the battery charger indicator on the screen
- Make sure charging is carried out under normal conditions (0°C (32°F) to + 40°C (104°F))
- When traveling, check that the voltage input is compatible

### **My phone cannot connect to a network or “No service” is displayed**


- Try connecting in another location
- Verify the network coverage with your operator

- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded

### **Invalid SIM card**

- Make sure the SIM card has been correctly inserted
- Make sure the chip on your SIM card is not damaged or scratched
- Make sure the service of your SIM card is available

### **Unable to make outgoing calls**

- Make sure you have dialed a valid number and press the  key
- For international calls, check the country and area codes
- Make sure your phone is connected to a network, and the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not barred outgoing calls
- Make sure that your phone is not in flight mode

### **Unable to receive incoming calls**

- Make sure your phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card valid, etc.)

- Make sure you have not forwarded incoming calls
- Make sure that you have not barred certain calls
- Make sure that your phone is not in flight mode



### **The caller's name/number does not appear when a call is received**

- Check that you have subscribed to this service with your operator
- Your caller has concealed his/her name or number

### **I cannot find my contacts**

- Make sure your SIM card is not broken
- Make sure your SIM card is inserted properly
- Import all contacts stored in SIM card to phone

### **The sound quality of the calls is poor**

- You can adjust the volume during a call by pressing the  key
- Check the network strength 
- Make sure that the receiver, connector or speaker on your phone is clean

### **I am unable to use the features described in the manual**

- Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an ALCATEL ONE TOUCH accessory

### **When I select a number from my contacts, the number cannot be dialed**

- Make sure that you have correctly recorded the number in your file
- Make sure that you have inputted the country prefix when calling a foreign country

### **I am unable to add a contact in my contacts**

- Make sure that your SIM card contacts are not full; delete some files from your SIM card or save the files in the phone contacts

### **My callers are unable to leave messages on my voicemail**

- Contact your network operator to check service availability
- I cannot access my voicemail
- Make sure your operator's voicemail number is correctly entered in "Messages\Voicemail"
- Try later if the network is busy

### **The flickering icon is displayed on my standby screen**

- You have saved too many short messages on your SIM card; delete some of them or archive them in the phone memory

### **SIM card PIN locked**

- Contact your network operator to obtain the PUK code (Personal Unblocking Key)

### **How to make your battery last longer**

- Make sure you follow the complete charge time (minimum 3 hours)

- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
- Switch on the backlight upon request

ALCATEL is a trademark of Alcatel-Lucent and is used under license by  
TCT Mobile Limited

All rights reserved © Copyright 2015  
TCT Mobile Limited

TCT Mobile Limited reserves the  
right to alter material or technical  
specification without prior notice.