

## **User Manual**

### **Mugen Power Extended 3000mAh Battery Case for Motorola Moto X (2<sup>nd</sup> Generation). Part # CC-MotoX2.**

Thank you for purchasing Mugen Power battery case for your Motorola Moto X. Now you will be able to get over 2X extra power while protecting your phone with the complete protection of a hard shell case.

#### **Compatibility**

Motorola Moto X 2<sup>nd</sup> Generation. (Will not fit the original Moto X)

#### **Charging the battery case for the first time**

Please charge the battery case without the phone for 3-4 hours before initial use. The USB cable can be plugged into your computer or any power source with a USB out.

#### **Installing the battery case**

Remove the top piece from the bottom master part of the case and slide the phone into the case properly and lock it in position by putting back the top piece.

#### **How to charge your phone using the battery case**

Turn on the battery case by moving the power switch to charge position. When your phone recognizes the battery case, a charging symbol will appear on the screen. This indicates that the phone is charging and/or using the power from the battery case rather than from phone itself.

If your phone is drained of power, the battery case will first charge your phone. If your phone is fully charged, the battery case will act as your primary battery and no power will be lost from the phone internal battery until the battery case is depleted.

#### **Checking the status of the battery case**

To check the power status of the battery case, press the button on the back of the case. The LED lights next to the button will illuminate for several seconds.

4 LEDs – power is at 100%

3 LEDs – power is at 75%

2 LEDs – power is at 50%

1 LED – power is at 25%

LED is red – battery is charging

LED is green – battery is fully charged

## **User tips and warnings**

- Keep your battery case dry and away from moisture.
- Avoid using the battery case in poor ventilation environment, such as jean pockets, purses, etc.
- Do not store or use the battery in a high temperature environment, including the direct sunlight heat.
- Do not disassemble the battery or attempt to modify it.
- Recharge your battery case once every month when not in use.
- Do not switch from charge to MS card instantly. Please make sure to move the switch to off position before accessing the MS card.