




ACCUSPLIT. PRO SURVIVOR™ PRO SPLIT STOPWATCH

STOPWATCH OPERATIONS



SINGLE EVENTS

- R – START
- R – STOP
- L – RESET

TIME-IN, TIME-OUT

- R – START
- R – STOP
- R – RESTART
- R – STOP
- L – RESET

LAP SPLIT

- C – PUSH AND RELEASE UNTIL “LAP” APPEARS
- R – START
- L – SPLIT
- L – RETURN TO RUNNING TIME
- R – STOP
- L – RESET

CUMULATIVE SPLIT


- C – PUSH AND RELEASE UNTIL “CUM” APPEARS
- R – START
- L – SPLIT
- L – RETURN TO RUNNING TIME
- R – STOP
- L – RESET

1,2 FASH FINISH

- C – PUSH AND RELEASE UNTIL “CUM” APPEARS
- R – START
- L – FINISH #1
- R – FINISH #2
- L – DISPLAY #2
- L – RESET

BATTERY CHANGING

See Specifications panel and drawing to right.



ACCUSPLIT, Inc.
6120 Stoneridge Mall Rd.
Suite 210
Pleasanton, CA 94588 USA
800-965-2008 • 925-226-0888
FAX 925-463-0147
www.ACCUSPLIT.com
support@ACCUSPLIT.com

SPECIFICATIONS
Batteries: Batteries should last for 18 months. If display becomes dim, open back and replace with Duracell LR43, Eveready 186, or Ray-O-Vac LR43.
Operating Temperature: 14°F to 130°F (-10°C to 55°C).
Quartz Crystal Accuracy: 0.04 sec/hr (accuracy may vary with shock, temperature or aging of crystal).

NO-PROOF-OF-PURCHASE LIMITED WARRANTY
See label on back of unit for details, or check <http://support.ACCUSPLIT.com>

REGISTER NOW Please return your Survivor Stopwatch Registration to the Repair Center address in the warranty, & we will let you know about future products.

User _____

Email (preferred) _____

1-800-965-2008 or 1-925-226-0888
FAX: 925-463-0147
support@accusplit.com
www.accusplit.com

ASSEMBLED IN PRChina
© 2005 ACCUSPLIT