




# ACCUSPLIT. SURVIVOR™ PRO SPLIT STOPWATCH

## STOPWATCH OPERATIONS



### SINGLE EVENTS

- R – START
- R – STOP
- L – RESET

### TIME-IN, TIME-OUT

- R – START
- R – STOP
- R – RESTART
- R – STOP
- L – RESET

### LAP SPLIT

- C – PUSH AND RELEASE UNTIL “LAP” APPEARS
- R – START
- L – SPLIT
- L – RETURN TO RUNNING TIME
- R – STOP
- L – RESET

### CUMULATIVE SPLIT

- C – PUSH AND RELEASE UNTIL “CUM” APPEARS
- R – START
- L – SPLIT
- L – RETURN TO RUNNING TIME
- R – STOP
- L – RESET

### 1,2 FASH FINISH

- C – PUSH AND RELEASE UNTIL “CUM” APPEARS
- R – START
- L – FINISH #1
- R – FINISH #2
- L – DISPLAY #2
- L – RESET

### BATTERY CHANGING

See Specifications panel.

ACCUSPLIT, Inc.  
6120 Stoneridge Mall Rd.  
Suite 210  
Pleasanton, CA 94588 USA  
800-965-2008 • 925-226-0888  
FAX 925-463-0147  
[www.ACCUSPLIT.com](http://www.ACCUSPLIT.com)  
support@ACCUSPLIT.com

**REGISTER NOW** Please return your Survivor Stopwatch Registration to the Repair Center address in the warranty, & we will let you know about future products.

User \_\_\_\_\_

Email (preferred) \_\_\_\_\_

**SPECIFICATIONS**

Batteries: Batteries should last for 18 months. If display becomes dim, open back and replace with Duracell LR43, Eveready 186, or Ray-O-Vac LR43.

Operating Temperature: 14°F to 130°F (-10°C to 55°C).

Quartz Crystal Accuracy: 0.04 sec/hr (accuracy may vary with shock, temperature or aging of crystal).

**NO-PROOF-OF-PURCHASE LIMITED WARRANTY**

See label on back of unit for details, or check <http://support.ACCUSPLIT.com>

1-800-965-2008 or 1-925-226-0888  
FAX: 925-463-0147  
support@accusplit.com  
www.accusplit.com

ASSEMBLED IN PRChina  
© 2005 ACCUSPLIT