
POWER TOOLS USER MANUAL







Index

General Introductions	2
1. Safe Rules	2
2. Notices before use	3
3. Notices of Battery use	3
4. Safe rules in working area	4
5. Electrical safety	4
6. Personal safety	5~6
Features & Specifications	7
1. Driver	7
2. Wrench	8
Product Structures	g
Charging Instruction	10
1. Take out the battery	10
2. Charging the battery	11
Operating Instructions	12
1. Full charge	12
2. Switch turns on proper portion	12
3. Switch direction	12
Changing accessories	13
1. Driver type	13
2. Wrench type	13
3. End Use	13
Maintenance	14
Ouick O&A	1/



Cordless

Power Tool User Manual

General Introductions



To avoid occurring any unexpected accident, please be read all instructions before using.

1. Safe Rules

- To be avoiding the vibration from the impact and tool falling down, please hold the handle tightly when use it.
- Do not be fixed or loose the tool directly under the area of electronic machine or a place in conducting wire. Unless make sure all electronic machines or conducting wires are power off or ask a help from an electronic engineer.
- Always wear a protective equipment such as an eye goggles/ working clothes when use tool.
- To be avoiding the tool damage, do not be changed to the other hand when use or
 - operate tool in bad condition.
- Please be sure to keep all bits steadily or use an auxiliary equipment when use tool.
- In case of tool damage, do not use it anymore to avoid the hurt.
 And please contact with customer service center for repair.

-

2. Notices before use

- Follow all limitations from the user manual when use tool.
- Follow all instructions from the user manual and use tool corrrectly.
- Keep the switch in the center portion as turn off when you do not use it.
- Please choose the correct accessories for different application to avoid occurring tool damage or body injury.
- Keep the tool from reach of children and do not allow persons unfamiliar with the tool to use.

3. Notices of Battery use

- Battery charge must follow the instructions from user manual.
- Keep the battery dry and away from the flammable.
- Battery is a consumables, please replace it when out of warranty to avoid occurring tool damage.
- Do not expose battery under direct sunlight or any hot condition.



4. Safe rules in working area

 Keep working area clean and bright to avoid occurring any unexpected accident.



Keep well ventilation in working area.
 Do not use tool under airtight room or the room fills with flammable liquid/gaseous.



 Keep children and bystanders away from the working area.



5. Electrical safety

 Do not modify the plug or socket anyway.
 Make sure to use the plug and socket with grounded connector to decrease the risk from the electric impact.



 Do not use tool in the moist room or in a rainy day to avoid getting an electric shock.





6. Personal safety



 Always wear protective equipment such as an eye goggles/ working clothes when use tool.



Keep working area smooth and steady to avoid tumbling since climb.



 Keep working area clean and bright to avoid occurring any unexpected accident.



Before using the tool, please check all details in advance.
 When there is any damage on tool, please contact with customer service center for repair.



 Unusual sound occurred during use, please inspect all details. If there is any damage happening, please contact with customer service center for repair.





Cordless

Power

Tool User Manual

 Do not expose battery under direct sunlight or any hot condition.



 Do not use tool in the moist room or a rainy day to avoid getting an electric shock.



Do not charge battery in a rainy day to avoid getting an electric shock.



 During and after using tool, do not throw heavily and put it down carefully to avoid occurring tool damage.





Co

Features & Specifications

1. Driver

Features

- Environment friendly by Li-ion battery power
- Optional heavy duty square drive: 1/4" (6.35 mm)
- Interchangeable motor carbon brush
- Electric brake switch
- Reversible function
- Led light
- Powerful cooling fan for high-motor durability
- Efficient impact system and balance handle
- Charger: dual charge system AC 100V~240V & DC12V
- Long life cycle

Specifications

- Voltage : DC 14.8VTorque : 230N/M
- Battery: 3.0 AH Li-ion battery
 Turn speed: 0~2600 R.P.M
- Chuck: 1/4" (6.35 mm) square drive
- Battery : Brand SANYO
- Dimension : 168.4x66x253.3mm
- Weight (with battery): 1.67Kg

Accessories

- 1 PC AC&DC 100-240V Charger
- 1 PC AC Power Cord
- 1 PC 12V D.C. Cord (for car charger)
- 1 PC 3.0Ah Li-ion Battery Pack
- 2 PCS 65 mm Double Way Bits
- Others request by clients.



Power Tool User Manual

2. Wrench

Features

- Environment friendly by Li-ion battery power
- Optional heavy duty square drive: 1/2" (13 mm)
- Interchangeable motor carbon brush
- Electric brake switch
- Reversible function
- Led light
- Powerful cooling fan for high-motor durability
- Efficient impact system and balance handle
- Charger: dual charge system AC 100V ~ 240V & DC12V
- Long life cycle

Specifications

- Voltage : DC 14.8V
 Tarraya : 020N/M4
- Torque : 230N/M
- Battery : 3.0 AH Li-ion battery
 Turn aread : 0.2000 B BM
- Turn speed : 0~2600 R.P.M
- Chuck: 1/2" (13 mm) square drive
- Battery Brand : SANYO
- Dimension : 168.4x66x253.3mm
- Weight (with battery): 1.72Kg


Accessories


- 1 PC AC&DC 100-240V Charger
- 1 PC AC Power Cord
- 1 PC 12V D.C. Cord (for car charger)
- 1 PC 3.0Ah Li-ion Battery Pack
- 2 PCS Sockets (19 & 21mm)
- Others request by clients.

-

Product Structures







Charging Instructions



Cordless

Power Tool User Manual

When use the tool at first time, it must have full charge then use it. Remove the battery and recharge by instruction in following the marked on circle.

1. Take out the battery





 Press the battery button and pull the handlebar back.



• Remove the battery from the tool body.



• Completed.



2. Charging the Battery

Connect the plug of charger with the battery by instruction in following the marked on circle.


• In face of the charger connector




• In face of the battery connector



Connect charger and battery.



• Connect the AC socket to power cord and charge it.



WARNING!

In case of disconnecting properly or wrong connection, do not force to connect it and be damaged the pin.

Operating Instructions

To be read all operating instructions when use the tool at first time.



Cordless


Tool User Manual

1. Full charge
When use the tool at first time, battery must be full charge and the time will be around 6-8 hours. After that, the charging time will depend on using condition.

2. Switch turns on proper portion

This tool designed with an automatic locking system.

When the lock is in the center which is "OFF" to avoid starting.



3. Switch direction

Reverse turn



Upright turn






Changing accessories

Please choose the correct accessory for different application to be sure the accessory under right condition.

1. Driver type








2. Wrench type







3.End Use Please put the turn switch in the center



Maintenance



Cordless Power Tool User Manual

WARNING!

Please use a dry cloth to keep the tool and battery clean.
 Do not use any strong or alkaline liquid for cleaning.

WARNING!

- Do not use any sharp articles or external force to replace, the tool and battery are one of conductor instrument. Under both conditions, they will be conducted and damaged to decrease the life time of tool.
- Do not tear serial number, warranty sticker either one, once any broken or change will be out of guarantee.

Quick Q&A

- Q. When the battery is, can be disassembled by self?
- A. The battery is a conducting device, absolutely can not disassemble by self.
- Q. While using the tool at first time, but there is no any response after pressing the power switch?
- A. The battery is not full charge yet, please must charge full 8-10 hours when first use.
- Q. Does still not any response after full charge?
- A. Please double check the power switch on the right position.
- Q. Can be recycled of the battery?
- A. The battery can be recycled, if out of warranty, please take it to the battery-recycle station.
- Q. What do mean the lights color on charger?
- A. There are four battery modules (4 Series +2 Parallels)inside the battery pack and also four LED lights to be appearance.
 - a. Before connecting battery module, four LEDs are all GREEN color.
 - b. Battery in charging, four LEDs are all RED.
 - c. One of battery module is full charge, one of light is becoming GREEN.
 - d. All of battery modules are full charge, four LEDs are all GREEN.
- Q. How will keep the tool for long time unused?
- A. Please have battery full charge then put into blow case and under shady and cool place.