

Motion Marketing,
Kansas City
Service and Help

www.motionmarketinginc.com

[email: service@motionmarketinginc.com](mailto:service@motionmarketinginc.com)

Phone Number: 913-631-4402



PS200
Electronic Digital Postal Scale
Max. 22 lb d=0.1oz



The PS200 is a quality electronic digital scale with many features and functions. Please read this manual carefully to enjoy this product. If you are unsure about how to unpack, how to start using and how to care for a digital scale please consult our web pages for more information and solutions in case you encounter any problem.

Operating Instructions

SCALE SPECIFICATIONS

Range	: 0 ~ 22lbs Mechanical overload protection
Tare	: Unlimited up to the total capacity of the scale
Accuracy	: $\pm 0.1\%$ of reading ± 1 digit
Calibration	: Four points of Automatic Calibration for greater accuracy
Resolution	: 0.1 oz
Minimum Weight	: 0.1 oz
Min. Add-on Wt.	: 0.1 oz
Power	: AC Adaptor UL listed: 9V, 100mA (Supplied) Battery: 6 x 1.5V AAA alkaline batteries (Not supplied)
Warm-up time	: 1 minute or less
Display	: 7 segment LCD with 5 digits
Auto Off	: Auto off after 5 minutes of non-use (only in battery operation)
Temperature	: Good performance within 20 degrees to 110 degrees F
Case & Platform	: Fine textured ABS plastic
Load Cell Technology	: Optimally placed strain gages with temperature compensation elements
Load Cell Body	: High Tensile Strength Aluminum Alloy

Unpacking and assembling the scale

Unpack the scale. Gently place the weighing platform to the body of the scale via the location points. Make sure that the sloped side of the platform faces the front (keyboard) of the scale. Do not press too hard or use force in placing the platform.


Using the scale with a battery

Remove the battery compartment cover underneath the scale. Insert six AA size batteries in the correct orientation as indicated in the scale. Replace the battery compartment cover.

Using the scale with the power adapter


Connect the supplied power adapter to the input socket found at the rear of the scale and plug it into the power supply. It is advisable to remove the batteries before using the power adapter.

Scale startup

Press the  key.  will appear briefly in the LCD window as the scale performs a self-check/zeroing routine, after which  will appear in the LCD window. Wait 60 seconds for the scale to warm up. Your scale is now ready to weigh.

Using the TARE key

You can tare (set to zero) any article used as a container for small items in the following way.


If the scale is switched off, press the  key and wait for  to display. Place the container onto the platform, and

then press the  key. The display will show . Place the item to be weighed into the container, on the platform. The scale will now show the weight of the item, excluding the weight of the container.

Be sure that the scale is operated on a flat surface

In order to operate correctly, the scale must be installed on a firm, flat surface. It is advisable to turn the scale on one to two minutes prior to its use.

Error Messages



The weight capacity of the scale has been exceeded.



When the input voltage is less than 7V, LO appears in the upper left LCD at the scale's startup.

Limited Warranty

This USPS scale is warranted to be free of defects in parts and workmanship for a period of one year from the time of purchase by the original owner. If this product is found to be defective, Motion Marketing will repair or replace defective parts at no charge, subject to the following conditions:

- 1.) Owner must request a return authorization from Motion Marketing - please fill up the web form located at www.motionmarketinginc.com
- 2.) Owner must include verification of the date of purchase when requesting Limited Warranty Service. (Dated Sales Receipt Required)

www.motionmarketinginc.com

[email: service@ motionmarketinginc.com](mailto:service@motionmarketinginc.com)

Phone Number: 913-631-4402