


44 lb (20 kg) /110 lb (50 kg) Stainless Steel FLAT TOP SCALE

44 lb. MODEL #24-0301 110 lb. MODEL #24-0401



TO CLEAN THE SCALE

Thoroughly wipe clean with a soft damp cloth and mild detergent. Wipe with clear water and dry immediately. DO NOT IMMERSE THE SCALE IN WATER OR LIQUIDS.

ASSEMBLY INSTRUCTIONS

Before using the **Flat Top Scale** for the first time, attach the **Platform** onto the top of the **Scale**.

- 1. Begin by removing the cardboard support from the top of the **Scale**.
- 2. Attach the **Platform** to the top of the **Scale** with the included **Wing Nuts**.
- DO NOT over-tighten the Wing Nuts to prevent damaging the threads.

ZERO THE SCALE

After attaching the **Platform** to the top of the **Scale**, the **Pointer** may not indicate "0" weight. Set the **Pointer** to the "0" position for the **Scale** to accurately indicate an object's weight.

To zero the **Scale**, rotate the **Tare Dial** either clockwise or counter-clockwise (depending on the direction in which the **Pointer** is off) until the **Pointer** indicates "0" weight.

The **Platform** is to be empty while zeroing the **Scale**.

To ensure accurate weight, make sure the **Pointer** is set to "0" before weighing an object.

To weigh objects in a container, place an empty container on the **Platform** then rotate the **Tare Dial** to zero the **Scale**. The **Scale** will now only indicate the weight of objects added to the container.

REV122710