



Lex Lighting Safety Instructions

1. Please keep this User Manual for future reference and be sure to pass this manual on to anyone using the fixture.
2. Always make sure that you are connecting to the proper voltage as stated on the decal or rear panel of the fixture.
3. This product is intended for indoor use only! To prevent risk of fire or shock, do not expose fixture to rain or moisture.
4. Make sure there are no flammable materials close to the unit while operating.
5. The unit must be installed in a location with adequate ventilation, atleast 20inches (50 cm) from adjacent surfaces. Be sure that no ventilation slots are blocked.
6. Always disconnect from power source before servicing or replacing fuse and be sure to replace with same fuse rating.
7. Secure fixture to fastening device using a safety chain.
8. Maximum ambient temperature (Ta) is 104° F (40° C). Do not operate fixture at temperatures higher than this.
9. In the event of a serious operating problem, stop using the unit immediately. Never try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction and will void your warranty. Please contact the nearest authorized technical assistance center.
10. Never connect the device to a dimmer pack.
11. Make sure the power cord is never crimped or damaged.
12. Never disconnect the power cord by pulling or tugging on the cord.
13. Never carry the fixture directly from the cord. Always use the hanging/mounting bracket.
14. Avoid direct eye exposure to the light source while it is on.



Lex F900 USER MANUAL

Please read through the manual before operating this product. Keep in a safe place for future reference.



www.lexlighting.co.uk

Congratulations on purchasing your new effect from Lex-lighting. Reading through this manual will ensure trouble free and long life operation of the unit.

Features:

- **900w Heater for Huge Smoke Output**
- **Wired / Wireless Remote(model depending)***
- **Hanging Bracket**
- **Built in Tank**

Contents:

- **Fog Unit Lex F900**
- **Wired Remote***
- **Wireless Remote and Receiver***
- **User manual**

Operating Your F900

Plug in your F900 and select which remote you are going to use. Both Wired and Wireless remote receiver are connected to the machine via a IEC fitting.

Fill the units tank with fluid to the recommended level as shown in the level gauge at the back of the F900.

When using the wired remote, the red LED will illuminate on the remote when the machine has heated. Press the red button for smoke output.

When using the wireless remote, wait 5 minutes or so then press any button on the remote for smoke output.

If two or more F900's are in use via the wireless remote, all units will fire from one remote.

Mounting Your Fixture

Your F900 is designed to be hung from either a Ceiling, DJ Truss or T-Bar Stand. The bracket comes supplied with a hole to allow mounting of the fixture. Also rubber feet are fitted so it can be placed on the floor.

Always ensure the fixture is tightly fitted to whatever it is your mounting it too.

Care and Maintenance

Cleaning your fixture will keep it looking great for many years and also ensure its long life and trouble free operation. Clean your F900 with a slightly damp, lint-free cloth. Never use chemicals to clean the fixture as this could impair its finish. Always make sure the fixture is powered off before cleaning.

If you need to replace the fuse, always make sure you replace with the same fuse specification. NEVER attempt to wrap foil around the fuse.

Your F900 will get very hot during use. Please let it cool down before handling the unit.

Your F900 is fitted with a 'Auto-Cut Off' feature which stops smoke output while the unit is re-heating. This is normal.

Never let the F900 run dry of fluid. Doing so will damage the pump. Always use a good quality fluid for the F900.

Never let anyone stand close to the smoke output. We recommend a distance of at least 2 metres.

Ensure good ventilation around the F900 when operating.