There are 2 methods to teach the module (brain) the transmitter code

ACCESSING THE MODULE REMOTE TRANSMITTER CODE LEARNING WITHOUT

taught without accessing the module under the dash Some DesignTech Remote Starters have a special feature that allows new transmitters to be

- 1924 Turn ignition (key) ON then OFF (Do not start the vehicle)
 - Flip control toggle switch OFF then ON.
- Slowly push the brake pedal TWICE (dash lights will turn on for 2 seconds)
- Flip control toggle switch OFF then ON (while dash lights are on for the 2 sec-
- PUSH and HOLD the , button on the transmitter.
- **8** 7 6 5 The dash lights will turn on then off to signal the code has been learned.
 - Teach other transmitters. Repeat steps 5 and 6.
- Dash lights will turn on and off four times to signal the exit of the programming

TRANSMITTER CODE LEARNING AT THE MODULE

pedal controls. The module is 9" long by 2" wide with two push buttons and one LED (The module is often be located under the driver's side of the dash, mounted above the on the side)

- Turn the Control Switch ON
- come on for a second. (The remote starter powers the ignition and accessory wires) Push the RED button to the right of the red LED. The red LED and the dash lights wil
- ω Hold down the stansmitter until the red LED and the dash lights come on again for a second. (The module has now learned the transmitter code.) Release the transmitter button.
- 4 To learn additional transmitters (up to 3 more), immediately (within 5 seconds) push and hold the button on another transmitter until the red LED and the dash lights come on for a second again.
- accessories will flash 4 times signaling that the unit has exited code Learning. Wait 10 seconds after the last transmitter was taught to the unit, the LED, ignition and

to begin teaching a new transmitter. transmitters must be taught at the same time. You have only 5 seconds between transmitters Note: Teaching the module a new transmitter code will erase all previous codes, so all

transmitters must be taught at the same time. Note: Teaching the module a new transmitter code will erase all previous codes, so all

HELP LINE: For any assistance regarding this product you may call DesignTech on our


shipping and handling. directly through your local dealer or DesignTech at the address below. All prices include toll-free telephone number — (800) 337-4468. Additional transmitters can be purchased Retail Pricing

Five button transmitters - 24471 Replacement Lithium Battery (CR2032) #20059 \$69.95

received, including that which may cause undesirable operation. This device may not cause harmful interference, and 2) it must accept any interference This device complies with FCC Rules Part 15. Operation is subject to two conditions: 1)

FCC ID: ELGTRAN2 or ELGTX4 CANADA 1476 102 320 or 14761021029

User 巨女しても **Manual** Transmitter



tional, Your transmitter has the following special features: Thank you for purchasing an additional transmitter from DesignTech Interna-

- allows control of four separate vehicles with one single transmitter These transmitters have a special "SHIFT" feature (the fabrush) which
- Anti-Scan technology to prevent copying.
- Three color LED to confirm function and transmission verification
- Uses one 3-volt lithium battery (CR2032), easily obtained at Radio Shack (Catalogue # 23-162) or DesignTech (Catalogue # 20059).

To control the First vehicle, simply push the button on the transmitter to control the desired function. For Start; Defor Lights; Defor Lock and for Deformation for Deformation for the desired function.

To control the Second vehicle, when the first button is pushed, and while the push the button on the transmitter to control the desired function colored LED light on the transmitter alternates between RED and GREEN

To control the **Third** vehicle, when the 'For button is pushed a second time, and the transmitter to control the desired function. while the colored LED light on the transmitter blinks RED push the button on

To control the Forth vehicle, when the ' button is pushed a third time, and on the transmitter to control the desired function. while the colored LED light on the transmitter blinks GREEN push the buttor

After the LED stops flashing, the transmitter goes back to controlling vehicle #1

remember to "shift" the transmitter accordingly before pushing the START button (Button) to teach the transmitter to the unit. When teaching the same transmitter to several different vehicles, it is important to

starters **NOTE:** These transmitters will only work with DesignTech remote



Tel: 1-800-337-4468 7955 Cameron Brown Court; Springfield, Virginia 22153 USA. Fax: 703-866-2001 www.designtech-intl.com