

Model Number: CCK3-RO

User Manual

Please read this manual thoroughly before using your Ross Co-Axial Plug Connector Kit and then retain for future reference



Assembly Instructions for TV/FM Plugs on Coax Cable:

- 1. Cut Coaxial cable to desired length (always use the shortest lengths possible for the best signal transfer)
- 2. Unscrew coax plug and open cable grip "jaws"
- 3. Slide cap and cable grip over Coax cable
- 4. Strip away 10cm of outer insulation
- 5. Peel back the braid and/or foil in order to uncover the inner insulation
- 6. Strip away 5mm of inner insulation to uncover the copper wire
- 7. Position the inner connector over the centre copper wire, and secure it be tightening the connector screw
- **8.** Position the outer plug connector over the inner plug connector and push the briad and/or foil back over the cable grip
- 9. Screw the plug cap back on the outer connector
- 10. Now repeat at the other end

The couple included allows you to join coaxial cables together or change the sex of the cable if required.

Coaxial plug wiring instructions:



Unscrew coax plug housing and slide cap over cable.



Strip 20mm of cable outer sheath.Gather copper braid,wrap around outer sheath,slide claw over braid 3





Strip 15mm of inner insulation to leave 5mm exposed

Undo screw on clamp,slide clamp over inner wire and tighten screw.Re-assemble plug

Tighten it until secure

