

COOL MIST HUMIDIFIER HUMECTADOR DE NIEBLA FRESCA HUMIDIFICATEUR À VAPEUR FROIDE



Model/Modelo/Modèle 1124 www.sunbeam.ca

READ AND SAVE THESE INSTRUCTIONS

LEA Y GUARDE ESTAS INSTRUCCIONES

LISEZ ET GARDEZ CES INSTRUCTIONS

P.N. 119428 9100030007741

READ AND SAVE THESE INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed. Failure to follow these safety precautions may result in personal injury or property damage, fire or shock.

- 1. Always have water in the water tank when operating unit.
- Use only clean, distilled or filtered tap water. Using tap water with a high mineral content (hard water) will result in the need for more frequent cleanings.
- 3. Be sure the filling cap of the tank is firmly tightened.
- Position the unit within the room so the air output from the top grill is aimed away from children, walls and furniture.
- When removing the Tank, use one hand on the Tank Handle and lift straight up. DO NOT use if tank is cracked.
- DO NOT place the appliance near heating devices. Keep the cord away from heated surfaces and areas where it can be stepped on or tripped over.
- Use only 120V AC outlet. Be sure unit is plugged in firmly and completely. As with any electrical device, plug and unplug unit with dry hands only.
- Turn the humidifier off and unplug the unit when: not in use, before moving or before cleaning. Please refer to the CARE AND MAINTENANCE section in this manual.
- To avoid the risk of fire, shock or personal injury, do not use an extension cord. WARNING: Never operate unit with a damaged cord or plug.
- Always place unit on a flat, level surface AWAY from direct sunlight or computers or other sensitive electronic equipment.
- 11. This product does not offer a medicine cup feature. DO NOT add medication of any type into the mist director, base or water tank. Do not cover or place anything over any opening. Never drop or insert any object into any openings.
- 12. The unit should not be left unattended in closed rooms as air could become saturated and leave condensation on walls or furniture. Always leave room door partly open.
- DANGER: To guard against electrical shock, NEVER immerse the humidifier motor unit (base) in water or other liquids.
- 14. Regular cleaning of the unit is needed. Please refer to the CARE AND MAINTENANCE section in this manual.
- 15. DO NOT use outdoors.
- 16. Turn the humidifier OFF if the relative humidity exceeds 60%, or if you notice condensation on the inside of your windows. For proper humidity reading use a hygrometer which is available in many retail stores.
- 17. Do not place the humidifier directly on wood furniture or other surfaces that can be damaged by water. For best results, place on a level, waterproof surface.
- 18. The unit contains no consumer serviceable parts. To reduce the risk of electrical shock, do not attempt to open the wiring cover.



To reduce the risk of electrical shock, this product has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit into the outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

PRE-OPERATING INSTRUCTIONS

- It is recommended that the water tray and humidifier tank be cleaned before first use. (See CARE AND MAINTENANCE instructions)
- Be sure the humidifier is switched OFF (0).
- 3. Select a location for your humidifier, on a flat level surface about 4" away from the wall. DO NOT place the humidifier on a finished floor or near furniture, which can be damaged by too much moisture or water. Place on a moisture resistant surface.
- 4. Remove the tank and the housing by lifting vertically off the base.
- 5. Make sure the wick is in place.
- Bring the tank to the sink, turn upside down and twist off the tank cap by turning counter clockwise. Fill tank with cool, tap water. DO NOT fill with warm water as this may cause leaking. Replace the cap on tank FIRMLY.
- Replace the humidifier housing and tank. The tank will immediately begin to empty into the base.
- 8. Plug power cord into a 120V AC wall outlet only

OPERATING INSTRUCTIONS

- To turn the humidifier on, switch the knob to desired setting. High will produce the maximum moisture and Low will produce the longest run time and quieter performance. It will take about 30 minutes for the humidifier to reach maximum output.
- 2. To turn the unit OFF, switch the knob to Off (0).

Extended Run Time Setting:

Your humidifier is equipped with an extended run time setting which increases the runtime between tank fillings. To take advantage of this setting, slide the switch on the water tray all the way to right to Max Runtime. Slide the switch back to the left for Max Output.

REPLACING THE FILTERS

Through normal use, waterborne minerals and sediment become trapped in the wick filter. The harder your water, the greater the amount of minerals in the water, and the more often you will need to change your filter. You will be able to monitor the life of the filter in your humidifier by checking the FilterCheck™ Indicator. The FilterCheck™ Indicator will only read the filter condition when the humidifier is in operation. After 60



minutes of use, FilterCheck™ Indicator will point to the current filter condition. A brand new wick filter will register in the purple section reading GOOD filter. After frequent use of your humidifier, the FilterCheck™ Indicator will let you know when the wick filter needs to be changed.

To replace the wick filter, follow the steps below:


- 1. Turn the humidifier OFF (O) and disconnect from the electrical outlet.
- 2. Remove the tank and housing by lifting vertically off the base.
- 3. Discard the old wick filter and follow WEEKLY MAINTENANCE instructions.
- 4. Insert new wick filter.
- Replace the tank and housing.
- Repeat Pre-Operating and Operating Instructions.

It is recommended that a replacement wick filter (Model 1175) is purchased for uninterrupted use. Replacement filter may be purchased at your local retailer or online at: www.sunbeam.ca

DANGER: Improper use of electric cords and plugs can cause a burn, fire or other electric shock hazard. Never "yank" on cord to remove from outlet, grip plug and pull from outlet. Check the power cord and plug for damage. A damaged cord or plug must be repaired before using the humidifier.

Instrucciones Antes de Utilizar el Humidificador

- Se recomienda limpiar la base y el tanque de agua del humectador antes de su primer uso. (Véase las instrucciones de CUIDADO Y MANTENIMIENTO).
- 2. Asegúrese de que el humidificador esté apagado (0).
- Coloque su humidificador sobre una superficie plana a 4" aproximadamente de la pared. NO coloque el humidificador sobre pisos pulidos o cerca de muebles, ya que pueden dañarse a causa del exceso de calor, humedad o agua. Colóquelo sobre una superficie resistente a la humedad.
- 4. Retire el tangue y la cubierta principal por levantándolo para sacarlo de la base.
- 5. Asegúrese de que el filtro esté en su lugar.
- 6. Coloque el depósito en el sumidero, délo vuelta y retire la tapa del depósito girándola en sentido horario. Llene el depósito con agua corriente fresca y fría. NO llene el depósito con agua tibia ya que puede ocasionar filtraciones. Coloque la tapa del depósito y ajústela firmemente.
- Retire el tanque. El depósito comenzará a vaciarse inmediatamente en la Bandeja de agua.
- 8. Enchufe el cordón de alimentación en un tomacorriente de pared de 120V CA solamente.



CARE AND MAINTENANCE

The following maintenance procedures must be routinely followed in order to ensure proper, efficient operation of your humidifier. The unit WILL NOT WORK CORRECTLY if it is not cleaned properly.

Daily Maintenance

- Before cleaning, turn off and unplug the humidifier from the electrical outlet...
- Benote the tank and housing by lifting vertically from the base of the humidifier and place in sink or tub.

 Carry the water tray to the sink, remove the wick, drain any remaining water and rinse thoroughly to remove any

 sediment or dirt. Wipe clean, and dry with a clean cloth or paper towel. The base is dishwasher safe (TOP RACK ONLY) for easy cleaning.

 Put wick filter back in the base, replace the housing, then refill tank with cool tap water. Follow the PRE-OPERATING and OPERATING INSTRUCTIONS.

Weekly Maintenance

- Repeal steps 1-3 in the Daily Maintenance section.

 Clean the water tray by partially filling the water tray with one 8-oz. cup of undiluted white vinegar. Let solution stand 20 minutes, cleaning all interior surfaces with a soft brush. Dampen a cloth with undiluted white vinegar and wipe out entire base to remove scale.

Rinse the base with water tray with warm water to remove any remaining scale and white vinegar solution before beginning to disinfect the tank.

Disinfect tank

- Fill humidifier tank 1/2 full with water and 1/2 tablespoon of chlorine bleach.
- Let the solution stand for 20 minutes, swishing every few minutes. Wet all surfaces.
- Carefully empty the tank after 20 minutes, and rinse well with warm water until you can not detect any bleach smell. Dry with a clean cloth or paper towel. Place wick filter back into the base, replace the housing, then refill the tank with cool tap water. Follow the PRE-OPERATING and OPERATING INSTRUCTIONS.

STORAGE INSTRUCTIONS When not using your humidifier for an extended period of time:

- Dispose of the wick filters. DO NOT leave in humidifier.
- Clean, rinse and thoroughly dry the humidifier as directed in WEEKLY MAINTENANCE. DO NOT leave any water in the humidifier when storing. Leaving water in the humidifier may render the humidifier inoperable for the following season.
- Place the humidifier in the original carton and store in a cool, dry place.

2 Years Limited Warranty

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of two years from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized JCS service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

JCS disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-888-264-9669 and a convenient service center address will be provided to you.

In Canada

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-888-264-9669 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business Jarden Consumer Solutions located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, located at 20 B Hereford Street, Brampton, Ontario L6Y 0M1. If you have any other problem or claim in connection with this product, please write our Consumer Service Department. PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.

© 2011 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved. Imported and distributed by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, 20 B Hereford Street, Brampton, Ontario L6Y 0M1.

Printed in China