


3. The seal ring diameter of the Shift is 17mm.

4. Remember to charge and fully discharge the battery between uses for optimal battery life.

5.If you encounter an issue or defect with your *Shift* unit CONTACT EHUQA - do not return to the store you bought it from.

6.Use only as directed with the products recommended. Deviations of usage can cause your warranty to be voided.



www.ehuga.com

info@ehuqa.com

25602 Alicia Pkwy #328 Laguna Hills CA 92653 United States

4. Enjoy!

through the sides

Using the included sealing rings (if needed), make sure the cylinder connector at the head of your hookah and the bottom of the Shift are connected tightly, letting no air

3. Making sure all connections in the system are air tight,

you can begin to puff on the hose of your hookah as you

normally would. The air pressure sensor in the *Shift* unit will turn on and begin to prime the Vapor Pods. After 2-3

"warm up puffs" the system will be ready.