MARS GAMING

MM5



Mars Gaming MM5 software installation and manual

Please connect your MARS GAMING MM5 mouse to the PC before the software installation.

- 1. Please click the setup.exe to start the software installation.
- 2. Click Next and follow the steps.
- 3. Click Finish

There are three main sections in this mouse control software which are GENERAL, DPI, and LIGHT settings. In the lower part of the software interface, you can create your own profile preferences and save into one of the five profile slots.

OK: Save setting and close dialog box.

Cancel: Exit the dialog box without saving.

Apply: Make changes to take effect but not close the dialog box.


GENERAL





KEY ASSIGNMENT

User can assign each of the 13 keys in this mouse with a specific function by selecting from a pull down menu. The functions are:



Click: Executing mouse click function

Right Click: Executing the right mouse click function

Middle Button: Executing general rolling function & click of mouse.

Forward: Executing the function of Forward action. **Backward:** Executing the function of Backward action.

Single Key: Assigning a single key from keyboard to a mouse key. **Combo key**: Assigning a combination of keys from keyboard to a single

mouse key

Basic: Select and assign a Windows action to a key **Advanced:** Select and assign a Windows action to a key

Media: Select and assign a media function to a key **Macro:** Select and assign a recorded Macro to a key

Fire Key...: Sets number of fire in one mouse click and the delay time between

each click

DPI switch: Executing dpi selection **DPI +:** Executing dpi up function **DPI -:** Executing dpi down function

Profile switch: Switch between saved profiles

Disable: Disable a key.

ACCELERATION

Adjust the pointer acceleration speed

POINTER SPEED

Adjust the pointer speed

SCROLL SPEED

Adjust the wheel rolling speed

DOUBLE CLICK SPEED


User can define the speed needed between the two clicks to perform a double-click action.

POLLING RATE

Setting the report rate of a mouse

MACRO MANAGER






- 1. Click MACRO MANAGER
- 2. Click NEW
- 3. Type in a new Macro name and press Enter
- Click

 to start recording and type in a combination of keys of your preference.

You have the options to:

- * Record delays between each action
- * Insert default delay
- * You can also set the number of Loop Times
- 5. Click **t** to stop recording.
- 6. Click OK

DPI



- * Adjust DPI
- * Enabling and disabling any of the five DPI settings
- * Selecting a default DPI setting

Remember to click APPLY or OK in order for the setting to take effect.

LIGHT



LIGHT COLOR: Select from a broad range of set colors **CUSTOME LIGHT COLOR:** Customize your own color **BRIGHTNESS LEVEL:** Set the intensity of the LED light **BREATHING SPEED:** Set the light pulsation speed

Remember to click APPLY or OK in order for the setting to take effect.

Profile selector

Press to fast select one of the five saved profile (without opening the software).

