

GOLDAIR

Operating Instructions

Electric Throw



Models: GEFT200 and GEFT220

General Care and Safety Guide

Thank you for choosing a Goldair Electric Throw. This Goldair Electric Throw has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, will give you years of useful service. Please read these instructions carefully.

1. Use only the voltage specified on the rating label of the Electric Throw.
2. Do not use an extension cord, power board or external timer with this product.
3. Do not operate this Electric Throw with a damaged cord, plug or after the Electric Throw malfunctions in any manner. Return to a qualified electrical person for examination, electrical service or repair.
4. This Electric Throw is intended for household use only and not for commercial or industrial use.
5. Use this Electric Throw only as described in this manual. Any other use is not recommended by the manufacturer and may cause fire, electrical shock or injury.
6. Do not operate with cord set coiled up as a heat build up is likely, which could be sufficient to become a hazard.
7. Do not use with heavy or dense over blankets as they may lead to overheating of the Electric Throw.
8. Do not trap or fold cords between bed slats, mattress, or springs, or against walls, headboards or bed frame as this may cause damage to the cord. Do not pinch, flex, or expose the heating wire. Damaged heating wire may cause a fire hazard or personal injury.
9. Do not use the Electric Throw on a bed used by an infant, incapacitated person, paraplegic, quadriplegic, diabetic, anyone sensitive to heat or anyone who can not clearly understand the instructions and/or operate the control.
10. This Electric Throw is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they are supervised or have been given instruction concerning the use of the Electric Throw by a person responsible for their safety.
11. This product is not intended for medical use in hospitals.
12. Do not use this product on a damp mattress or on a water bed.
13. If you find any damage to your Electric Throw, if your Electric Throw does not work, or is not working properly, contact the place of purchase or the Goldair Customer Services Team. Repair work on the Electric Throw by unqualified persons can cause serious risk to the user.
14. There are no user serviceable parts installed in the Electric Throw.
15. Do not use on an adjustable bed.
16. Turn off the Electric Throw and disconnect the power cord when not in use.
17. Do not dry clean the Electric Throw. Do not use bleach or harsh cleaning fluids as the cleaning liquid may damage the insulation of the heating element.
18. Do not use any pins, needles, safety pins or other sharp items on your Electric Throw as they will damage the electric wiring.
19. Keep all dogs, cats, and other pets away from the Electric Throw.
20. Do not tuck in the Electric Throw as this may cause over heating and/or fire.
21. The Electric Throw can be used only with the Electric Throw control provided by the manufacturer. Any other Electric Throw control may cause overheating and/or fire.
22. Indoor use only.
23. Children should be supervised to ensure that they do not play with the Electric Throw.
24. Do not unplug the product by the power cord while in use. Always turn the power off at the power outlet before you remove the plug. Remove by grasping the plug; do not pull on the cord.


TECHNICAL SPECIFICATION

Supply: 220-240VAC 50Hz
Wattage: 100W GEFT200, GEFT220



Overview of Goldair Electric Throw

Your Goldair Electric Throw is equipped with a 9 heat controller.



9 HEAT CONTROLLER

The control features an On/Off switch and two buttons to control the heat settings and the timer. It also has an LED readout for temperature and timer settings.

OPERATING INSTRUCTIONS

1. You can program your Electric Throw to work for 1-9 or 12 hours and with 1-9 heat settings.
2. Plug into the mains power supply and switch on the power mains.
3. Switch on the Electric Throw with "On/Off" button.
4. The LED for timer and temperature will be illuminated.
5. By pressing the Temp button you will be able to adjust the heat settings from 1-9, 1 being lowest and 9 being highest. This will be indicated with the left LED.
6. You can also set the timer to turn the Electric Throw off after a predetermined time being 1-9 hour or 12 hours. By pressing the Timer button you will be able to adjust the number of hours from 1-9 (press once for each hour), pressing one more time will show "H" illuminated on the heat controller which indicates the timer is set to 12 hours. This will be indicated with the right LED.

STORING YOUR THROW

Always allow the Electric Throw to cool before storing. Remove the control and roll or fold the Electric Throw loosely and store it in a bag or the bag it was supplied in. Avoid pressing sharp creases into the Electric Throw; for example do not store it under other items that may result in bending the wires of the Electric Throw.

BEFORE FIRST USE

Before using your Electric Throw for the first time:

- 1) The Electric Throw needs to be unfolded and laid flat before switching on.
- 2) We recommend that you switch your Electric Throw to the maximum setting for two to three hours before using then reduce the heat setting to your desired comfort level.

EVERYDAY USE

With normal use your Electric Throw will require 15 minutes of preheating before use.

IMPORTANT: Never sleep with Electric Throw turned on.

Care and Cleaning of your Goldair Electric Throw

CARE & CLEANING OF YOUR ELECTRIC THROW

Taking care of your Electric Throw is easy and safe as long as you follow the steps outlined below:

- DO NOT dry clean your Electric Throw. Dry cleaning will damage the wiring.
- DO NOT use bleach or dry cleaning fluids.
- DO NOT use a wringer.
- DO NOT iron the Electric Throw.
- DO NOT turn on the Electric Throw until it is completely dry.
- DO NOT use mothballs or sprays of any kind.

SPOT CLEANING

- Unplug and remove the control from the Electric Throw.
- Wet sponge the affected area using a mild soap and lukewarm water solution. Ensure the water temperature is less than 30°C.
- Gently sponge the affected area with clean water.
- Use a neutral coloured towel to absorb excess water.

PROOF OF PURCHASE

To receive warranty retain receipt as proof of purchase. (Refer to back of booklet).

- Unplug and remove the Electric Throw control.
- Fold and presoak the Electric Throw for 15 minutes in a mild soap and lukewarm water solution. Ensure the water temperature is less than 30°C.
- Gently squeeze the soap suds through for a few minutes.
- Rinse in fresh lukewarm water.

MACHINE WASHING

- Unplug and remove the Electric Throw control.
- Fold and presoak the Electric Throw for 15 minutes in a mild soap and lukewarm water solution. Ensure the water temperature is less than 30°C.
- Wash in mild soap and lukewarm water on the delicate or gentle cycle for 2 minutes.
- Rinse in fresh lukewarm water.

AIR DRYING

- Gently stretch the Electric Throw to its original size.
- Air dry over a clothes line or shower rod. (DO NOT use clothes pegs or clips of any kind).
- DO NOT use the Electric Throw until it is completely dry.

MACHINE DRY

- Preheat the dryer on the low temperature setting for 2 minutes.
- Place the throw into the dryer and tumble dry on low setting for a maximum of 20 minutes until damp.
- Remove the throw while it is still damp and gently stretch to its original size.
- Continue to air dry over a clothes line or shower rod. (DO NOT use clothes pegs or clips of any kind).
- Do not use the throw until it is completely dry.

GOLDAIR

SUPPORT AND TECHNICAL ADVICE

Goldair – New Zealand

Monday – Friday 8am-5pm

Phone +64 (0)9 917 4000

Phone 0800 232 633

info@cdb.co.nz

Goldair – Australia

Monday – Friday 8am-5pm

Phone +61 (0)3 9336 4423

Phone 1300 465 324

info@cdbgolair.com.au

Two Year Warranty

Thank you for purchasing this Goldair product. Your product is warranted against faults and manufacture when used in normal domestic use for a period of **two years**. In non-domestic use Goldair limits the voluntary warranty to **three months**.

Goldair undertake to repair or replace this product at no charge if found to be defective due to a manufacturing fault during the warranty period.

This warranty excludes damage caused by misuse, neglect, shipping accident, incorrect installation, or work carried out by anyone other than a qualified electrical service technician.

PLEASE KEEP YOUR RECEIPT AS THIS WILL HELP VERIFY YOUR WARRANTY.

The benefits given to you by this warranty are in addition to other rights and remedies available to you under law in relation to the goods or services to which this warranty relates.

In Australia, our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In New Zealand this warranty is additional to the conditions and guarantees of the Consumers Guarantee Act (1993).

Goldair – New Zealand

CDB Goldair
PO Box 100-707
N.S.M.C
Auckland

Phone +64 (0)9 917 4000
Phone 0800 232 633
www.goldair.co.nz

Goldair – Australia

CDB Goldair Australia Pty
PO Box 574
South Morang
Victoria, 3752

Phone +61 (0)3 9336 4423
Phone 1300 GOLDAIR (1300 465 324)
www.goldair.com.au

Goldair Two Year Warranty (IMPORTANT: Please complete and retain this warranty card)

Name

Address

Place Of Purchase Date Of Purchase

Name Of Product Model Number

Attach a copy of the purchase receipt to this warranty card