

Elite Fleet™

Rip Cord Flyer

User Manual

WARNING! Always use under direct adult supervision. For use by ages 5 and up. Please read instruction booklet carefully before operating Rip Cord Flyer. Please keep instruction booklet and display box for future reference.

Any Questions?

Email our Customer Service Dept.: customerservice@kidgalaxy.com

Call our Customer Service Dept.: Kid Galaxy Customer Service, Toll Free 1-800-816-1135



INTRODUCTION

- Rip Cord Flyer is a unique, ground breaking vertical take-off plane. Rip Cord Flyer rises vertically and, when at maximum altitude, smoothly translates to a gliding flight pattern back to a smooth landing.


PACKAGE CONTENTS



Rip Cord Flyer



Rip Cord Launcher




Instructions

HOW TO LAUNCH AND FLY!



1 Carefully insert flyer drive shaft into launcher port



2 Be sure that Flyer nose sits **BETWEEN** the launcher guide fins


HOW TO LAUNCH AND FLY.....CONTINUED!

- 3 Grab launcher firmly slightly tilt forwards as shown



Plane ready to launch!

- 4 Smoothly pull the rip cord grip back as shown



- 5 Rip Cord lifts off vertically and transitions to a normal horizontal flight pattern



OPERATION TIPS AND HELPFUL HINTS

- **Never** launch Rip Cord Flyer directly at people, animals and windows.
- Before launching, stand clear of trees and power wires as your Rip Cord Flyer will gain altitude quickly and might get stuck in overhanging tree branches and wires.
- Before flying, choose relatively calm days as wind can cause your Rip Cord Flyer to fly away from you.
- Rip Cord Flyer is NOT intended to be used indoors. It is specifically designed to be flown outdoors.
- Do not attempt to retrieve Rip Cord Flyer if stuck in trees, overhead wires or on top of buildings

KID GALAXY INC. LIMITED WARRANTY

- Kid Galaxy's products are covered under a 60 day limited warranty against manufacturer's defects. If a product is deemed defective and falls within the 60 day period, Kid Galaxy will repair or replace it at no charge. We require a copy of the original sales receipt to validate the purchase. Product must have been purchased within the US or Canada to be eligible. Please email us at:

customerservice@kidgalaxy.com or call us.

Toll Free Hot Line: 800-816-1135

www.kidgalaxy.com

Kid Galaxy, Inc. 150 Dow St., Ste. 425B, Manchester, NH 03101
Product Manufactured In China

⚠ WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years.

Kid Galaxy
☆☆☆

Copyright © 2010 Kid Galaxy, Inc.