

## Control Panel Options

The eight Control Panel Buttons displayed when viewing Technical Information documents from the Technical Information CD are as follows:

<b>RETURN</b>	Select this option to return to the “Select Return Destination” menu.
<b>PREVIOUS SCREEN</b>	Select this option to return to the previously displayed screen or document.
<b>CAMERA</b>	Select this button to turn pictures ON and OFF. T4 navigates through the display screens much faster when the images are switched off. To search for a particular image, it is quicker to turn the picture viewer off until the relevant display screen is found, then turn the picture viewer back on to study the image.
<b>PRINT</b>	Select to print the current document. It is possible either to print immediately, in which case a suitable printer must be connected to T4, or the document can be saved for printing later.
<b>HELP</b>	On-line help, providing information about the current screen.
<b>DETAILS</b>	<p>When active, documents related to the currently displayed topic can be viewed. When selected, a Pop-Up window showing a list of related documents appears. Use the scroll up and scroll down arrow buttons to select a related document from the Pop-Up Window, then select the “<b>CONTINUE</b>” button to view the highlighted document. Alternatively, select the “<b>CANCEL</b>” button to return to the picture being viewed previously. If the option button is faded grey, it is in-active and signifies that there are no related documents available.</p> <p> <b>NOTE: Pop-up windows disable the functionality of the rest of the display screen until a selection is made from the Pop-Up list.</b></p>
<b>PREVIOUS PAGE</b>	An alternative to the up arrow on the side of the display screen. Selection of this option will cause the document to be scrolled backwards by a single page (one page is equal to the size of the View area).
<b>NEXT PAGE</b>	An alternative to the down arrow on the side of the display screen. Selection of this option will cause the document to be scrolled forwards by a single page (one page is equal to the size of the View area).

In addition to the above Control Panel buttons, there are a number of “**HOT LINKS**” within the document which can be selected to move to an area providing related information. Any text or graphic with a shaded box around it signifies a “**HOT LINK**”.