

ELEGANT. EXCLUSIVE. HIGH-TECH.



LEX

USER'S GUIDE

Welcome to the world of Volish LEX, the exclusive e-cigarettes.

They were developed for e-smokers who stand out from the crowd and appreciate modern, non-standard design. You are holding a user's guide that will quickly introduce the 4th gen e-cigarette to you. It consists of five short sections.

1) You have made an excellent choice. Why?

Welcome to the world of Volish e-cigarettes! We wish to congratulate you on an excellent choice!

✓ You save your lungs

The research show that Volish e-cigarettes contain absolutely no tar substances and are more beneficial to your health than regular cigarettes. Moreover, it minimizes the effects of passive smoking.

✓ You save your money

E-smoking is cheap. Electronic cigarettes allow to reduce your smoking expenses by more than 80%. Check your savings on www.esmokingworld.com/calculator.

✓ You save your senses

No more unpleasant smells characteristic for the users of traditional cigarettes. Additionally, by changing to electronic cigarettes you will begin to feel smell and taste much more intensely, as these senses are dulled for regular cigarette smokers.

✓ Maintain your freedom

Electronic cigarettes are not covered by the smoking ban, which means you can feel at ease in the company of your friends or at work. You can also try to quit smoking by gradually reducing your nicotine intake without breaking the habit of "puffing".



LEX

2) How does your e-cigarette work?

Your kit includes:

- 1) 2 batteries 1100 mAh
- 2) 2 Atom clearomizers with replaceable heating units
- 3) USB charger and 230V/USB socket adaptor
- 4) User's manual and warranty card

Volish LEX consists of two basic parts – a 1100 mAh **battery** and an Atom **clearomizer**, into which the liquid is poured. The operating principle is to evaporate the nicotine liquid, which is heated up by the heating unit inside the clearomizer. This is how a smoke-like mist is produced, which – and here's the important part – contains no tar substances, thus saving your health and also the health of people around you.

3) How to use your e-cigarette?

Before you start your e-smoking experience, first prepare your e-cigarette. This takes a few simple steps:

STEP 1: Assemble the components

First, assemble all the pieces as shown on the illustration. Once the battery, the clearomizer's main part (sleeve) and the mouthpiece is assembled, the e-cigarette can be filled with special liquid. Your e-cigarette is currently in standby mode, which means it does not discharge.

STEP 2: Pour in the liquid

To enjoy a variety of aromas, refill the clearomizer's tank with special nicotine liquid; such liquids can be purchased separately. We recommend aromatic liquids available at eSmoking-World.com, tested to ensure highest quality by the eSmoking Institute. It only takes a moment to refill. To refill simply use the original bottle or a syringe. Remember about three, simple rules:

1. **BE CAREFUL** | The clearomizer's cutting edge design makes it impossible to flood the heating unit – the unit must be taken out before refilling. Remember to position the clearomizer with mouthpiece pointing down, before unscrewing the heating unit's thread. Read the liquid's leaflet carefully. Operate the heating unit's thread with care.
2. **POUR THE LIQUID ONTO A WALL** | Once the heating unit's thread is unscrewed, tilt the tank slightly and make sure the liquid is poured in onto a wall, up to a certain level that can be checked with the printed ruler. Do not aim the liquid into the central opening – this may cause the liquid to spill onto your hand. Then, carefully tighten the heating unit's thread. After first fill, wait about 5 minutes. This allows the liquid to spread evenly and soak the device, quickly roll the clearomizer in your hand.
3. **USE THE DEVICE SAFELY** | When soaked with liquid, the clearomizer should not be carried with the mouthpiece pointing down. This may cause the liquid to leak. Make sure the liquid is not below the permissible level, which can be checked with the tank's ruler (avoid dry e-smoking).

STEP 3: Click five times

To start the battery, just press the button on the battery. Caring for your safety and to save energy, we introduced a special safety measure – the “5-click” system. To turn the battery on or off again, press the button rapidly five times in succession. Did it blink twice? It means the battery is ready to work, or was turned off. If not – try again.

STEP 4: Enjoy e-smoking

Your e-cigarette is ready for use. Inhale by making slow, deep breaths, this creates much more “smoke”. After you inhale a few times, make a break to allow the liquid seep back to

the heater. If the taste changes, tilt the e-cigarette several times so that the nicotine liquid spreads evenly.

After a few days, the liquid in the tank may become darker. Unscrew the mouthpiece, pour out the remaining liquid and place the clearomizer horizontally for a few hours – so that the remaining liquid seeps out. You can also rinse it with warm water.

In the following sections you will learn how to charge your e-cigarette battery. Don't forget to become acquainted with the terms of warranty and safety!

4) Charging the battery? Safe and convenient

The battery is charged via a USB cable. Just attach it to the charger and connect it to the USB port – or use the 230V adaptor to connect it to the wall socket. The e-cigarettes button will blink 5 times and the diode's color will change from green to red. Once the battery is fully recharged, the diode will again light up in green. An empty battery takes about 5 hrs to fully recharge. If the charger diode flashes green earlier, continue charging until the above mentioned time passes.

CAUTION! Before first use, charge your e-cigarette for 8 hours! Charge the battery in room temperature. Store the battery in a dry place. Remember not to use other chargers which may have different voltage. Other chargers may use different voltages, which may damage the battery, reduce its life or even make it explode.

Your Volish features a system that informs you about the battery level. Depending on the battery's level, the button's colors change:

White – the battery's level is from 51% to 100%,

Blue – the battery is slowly depleting (11-50%),

Red – the battery is almost empty (< 10%); it should be connected to a charger soon.

The battery is equipped with a voltage regulator, which means it generates a constant voltage of 3.6V. The battery capacity is 1100 mAh.

5) Safety measures and warranty

Do not forget about fundamental safety measures. If you keep these safety precautions, e-smoking will deliver exceptional taste sensations and will be safe – both to you and people around you.

1. **Keep the e-cigarette clean and care about safety.** The latest Atom clearomizer can be fully disassembled and features a replaceable heater. It can be cleaned very easily with tissues or cotton buds. The liquid tank can be rinsed gently and left to dry. The heating unit gets used up in time. Which means it should be replaced after filling up the tank 5 times. Remember to keep the battery and clearomizer thread clean. Avoid keeping the battery in direct sunlight, extreme temperatures and high moisture. Keep your e-cigarette away from sharp items such as keys, etc., to prevent dents, scratches or even complete damage.
2. **Always observe the above mentioned instructions.** This prevents damage to your e-cigarette and enables you to use your e-smoking kit for a longer time. Remember that your complaint will not be accepted if the product was used not as intended or if components different than described in the manual are used.
3. **Consult the experts.** In case of any problems with the product, immediately contact the vendor (or the official Volish brand distributor). Do not attempt to repair any parts on your own – only Volish service personnel is authorized to do that. Damage to the product resulting from attempts to open will not be recognized as a legitimate complaint. Detailed terms of warranty can be found in the warranty card attached to your kit.

4. **Health comes first!** As you begin e-smoking, your body will require some time to adapt to the new way of nicotine delivery. If you experience any side effects, immediately stop using the e-cigarette and consult a physician.

CAUTION! Only original Volish are 100% compatible with each other. They ensure proper operation and long life of the e-cigarette. Non-original components may lower the efficiency of the device or even damage it. They may also turn out to be harmful to your health.

Difficulties with e-smoking? (not enough smoke, inhaling is difficult, burnt aftertaste)

If, after using the device for some time, the flavor changes, this may mean that the heater's fabric is not properly moisturized or there is not enough liquid. Refill the liquid or tip the clearomizer several times, roll it in your hand and wait for a while to allow the liquid to spread evenly. The taste should be back to normal after a moment.

If you still feel a burnt aftertaste or have difficulties inhaling, you probably need to replace the heating unit with a new one. Keep in mind that the heating unit is subject to wear and that its life depends on many factors, such as the way you inhale, how frequently you e-smoke or the type of liquid you use, etc. The average life of a heating unit is 2-4 weeks.

Exchanging the heating unit is as simple as refilling the liquid.

You can do it in a few simple steps:

1. Remember to turn the clearomizer with the mouthpiece pointing down – you will prevent the liquid from leaking.
2. Unscrew the heating unit thread from the clearomizer body.
3. Remove the heating unit.
4. Screw a new heating unit to the thread.
5. Twist all the parts of the clearomizer together.

CAUTION! We recommend using only branded and proven nicotine liquids. Such liquids have proper consistence, thickness and have been tested by trustworthy institutions, among else by the eSmoking Institute. We highly recommend nicotine liquids available at eSmokingWorld.com.

VOLISH LEX. FOR THOSE IN THE KNOW

