

Product Limited Warranty

Labelmate USA warrants to the original end-user customer that Labelmate USA products will be free from defects in materials and workmanship for the duration described herein below. Labelmate USA's Limited Warranty covers only those defects that arise as a result of normal use of the products and does not cover any other problems, including those that arise as a result of: (i) improper maintenance or modification; (ii) parts or supplies not provided or supported by Labelmate USA; (iii) operation outside the products' specifications; or (iv) unauthorized repair, modification or misuse. Use of any unauthorized accessory or attachment will void coverage.

The Warranty period for all products commences the date of shipment from Labelmate USA and accrues to the original end-user customer. Warranty coverage is non-transferable and terminates immediately upon rental, resale or any other change in ownership. Original purchase documentation should be retained for Warranty coverage verification.

In the event Labelmate USA substantiates, during the applicable Warranty period, a defect in any product which is covered by Labelmate USA's Warranty, Labelmate USA shall repair or replace the product, at Labelmate USA's option. Labelmate USA retains sole discretion to determine whether or not a product is defective. In no event shall Labelmate USA have any obligation to repair or replace until the customer returns the defective product to Labelmate USA. The customer assumes any and all responsibility and liability associated with transportation of products for service under this Warranty.

WARRANTY PERIOD	PRODUCTS COVERED
5-Years	"CAT" and "Mini CAT" Label Rewinders "UCAT" Label Unwinders
3-Years	Label Counters (<i>Excluding Counter Displays and Encoders</i>) Label Dispensers (<i>Excluding Counter Displays</i>) Label Slitters (<i>Mechanical Parts Only, and excluding Counter Displays</i>) Reel-to-Reel Machines (<i>Excluding Counter Displays and Encoders</i>) Print Mechanisms (<i>Excluding Counter Displays and Encoders</i>) Quick-Chucks
1-Year	Power Supplies, AC/DC Adaptors and Transformers Counter Displays Encoders Any other products or parts not specified herein
180-Days	Out-of-Warranty Repairs

In the event your product requires service or you have questions regarding Warranty coverage, please call toll-free (877) 833-7149 inside the United States, or +1 (702) 435-8535 outside the United States.

LABELMATE MAKES NO OTHER WARRANTY OF ANY KIND, WHETHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, AND/OR FITNESS FOR A PARTICULAR PURPOSE. NO OTHER PERSON, AGENT, DEALER OR RESELLER IS AUTHORIZED TO GIVE ANY WARRANTIES ON BEHALF OF LABELMATE. ANY OBLIGATION TO WARRANTY OTHER THAN THAT SPECIFICALLY ADDRESSED HEREIN IS EXPRESSLY DISCLAIMED.

LABELMATE USA LLC

12A Sunset Way, Henderson, NV 89014 USA
(702) 435-8535 FAX (702) 435-8536
Toll-Free (877) 833-7149 in USA!
support@labelmateusa.com

www.labelmateusa.com

LABELMATE USA LLC

S-100 & S-200

Label Slitter



S-100 Label Slitter

- In-line or Off-line Use
- Use with "QUICK-CHUCK" Rewinder

Remove all parts from shipping container and verify contents.

Package Contents

- User Manual (this document)
- Slitter Unit
- If ordered, Optional Counter with Power Supply Module

Retain the Shipping Container and Packaging for Storage and Transport.

• KEEP MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE •



WARNING

This product is for indoor use only.
Not for use in wet locations.
Unplug unit before removing waste material or
performing any cleaning or maintenance services.



WARNING!

Use caution and common sense to avoid personal injury or
damage to clothing when working with cutting blades or
around exposed blade surfaces.

SET-UP AND USE

1. Place the S-100 or S-200 Label Slitter so that it is perpendicular to the web of labels to be slit. Observe the Paper Path Label on the Slitter.
2. Loosen the Black Knob holding the red Blade Cover Shield and raise the Shield to the vertical position.
3. Rotate the Black Knob assembly approximately one-half turn so it is facing down and out of the way.
4. **See WARNING NOTICE above.** Rotate the blade holder shaft slightly to lift the Blade Holders from the round white Nylon Fixed Paper Guide.
5. Being careful to avoid contact with the cutting blades feed the label web under the Rotating Paper Guide and over the Fixed Paper Guide.
6. Adjust the position of the rings on the Rotating and Fixed Paper Guides to the width of your label web. Only finger tighten the screws. If you have the PC-1 Preset Counter, the labels must pass through the sensor slot.
7. Pull the label web through and affix it to the label rewind core on the Label Rewinder.
8. Being careful to avoid contact with the cutting Blades, adjust the position of the Blade Holders as desired. To do this, loosen the white Nylon set screw of the Blade Holders and slide the Blade Holders in or out as needed. Finger tighten the white Nylon set screw to hold the adjustment. Do not over tighten.
9. Extend the cutting blades as required using the black click-stop adjustment on the side of each knife. **THE BLADE TIP MUST EXTEND WELL PAST THE ROUND WHITE NYLON ROD SO THE CUTTING BLADE ITSELF IS RESTING ON THE WHITE NYLON.**
10. Being careful to avoid contact with the cutting Blades, rotate the Blade Holders down until the cutting blades rest lightly on the Fixed

Paper Guide. The Blades must pierce the label web to be slit.

11. Now lower the red Blade Shield to the Blade Holders.

12. Secure the red Blade Shield by rotating the small Black Knob assembly into the slot on the red Blade Shield and tightening the small Black Knob until it is snug. The Blades will press into the Nylon bar.

CAUTION: DO NOT OVERTIGHTEN.

NOTE: If the red Blade Shield does not press on all Blade Holders equally, loosen the mounting nuts for the Blade Shield Hinge on the Chassis and reposition them until the Blade Shield is “level” with the Blade Holders.

13. Start the Label Rewinder and the printer (if used). Adjust the speed of the Label Rewinder as required. See the CAT-3 User Manual for details.

14. To make fine adjustments to the position of the blades over the web AS A SET, use the large black adjustment knob marked “LIFT BLADES TO ADJUST.” NOTE: **ALWAYS LIFT THE BLADES FROM THE LABEL WEB TO MAKE ADJUSTMENTS. USE CAUTION TO AVOID CONTACT WITH THE CUTTING BLADES.**

MAINTENANCE: No maintenance is required other than to replace the Cutting Blades when they become dull.