



Dear User,
Thank you for purchasing BRIK **Equalizer Stage**.
Please read this User Manual before operating the machine to ensure its best performance and your safety.

Instructions:

Connecting Source

- Connect D/A Converter, Bluetooth Stage, Internet Radio, Phono Stage, CD Player, or other line level sources through **Input** on the rear panel.

Connecting Amplifier

- Connect the **Output** socket to a line input on an amplifier.

Connecting Power

- Before connecting, check the label to ensure the local power supply is compliant, and then connect the low voltage plug from the power supply to the **12V In** socket and switch the machine on.

Reinforcing Sound

Reinforce sound with the 10 selections on the front panel - Upward for plus ($\pm 10\text{dB} \pm 2\text{dB}$) & Downward for minus ($-10\text{dB} \pm 2\text{dB}$).

- Use the By Pass / EQ selection on the rear panel to bypass or pass the signals through Equalizer Stage.

Specifications:

INPUT OPTION
OUTPUT OPTION

OUTPUT LEVEL
DISTORTION
S/N

OUTPUT IMPEDANCE
CONTROL RANGE
DIMENSION
WEIGHT

ANALOGUE RCA INPUT x 1
ANALOGUE RCA OUTPUT x 1
BY PASS / EQ SELECTION x 1
2V
<0.035%
FLAT - 100 dB
A-WEIGHTED - 106 dB
< 650 OHM
 ± 10 dB
W 140 x H 48 x D160 mm
1000 g

NOTE

- BRIK **Equalizer Stage** operates in accordance with its specifications within environment temperature 40 degrees Celsius.

WARNING

- Never open the case of this item as this will invalidate the guarantee. There are no user adjustments inside. Please refer all service work to an authorized BRIK agent.
- This item shall not be exposed to dripping or splashing liquid, and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

