



CLOTHES AIRER

MODEL NO: EV1916CA

INSTRUCTION MANUAL
IMPORTANT INSTRUCTIONS RETAIN FOR FUTURE USE

READ FULLY BEFORE USE

USE

This attachment is designed to fit onto Oil Column Heaters only for the purpose of airing light articles of clothing.

Warning! Never place clothing articles directly onto any heater. Risk of overheating, fire or electric shock.

OPERATION

Set the heater in a suitable place. Switch heater on using a low setting and place the airing attachment onto the heater top. Ensure it is attached securely. Place articles of clothing carefully onto the airing rack only. Do not overload the rack. Allow sufficient space around the area. For use with damp articles only, always remove excessive liquid from any article before placing on this airing rack. Do not place articles that are wet onto the rack as water may enter the heating appliance.

Warning! Refer to specific safety instructions for use of your heater and those listed in this instruction sheet before use.



SAFETY INSTRUCTIONS

Carefully read this manual in full before using this attachment.

Maintain and operate any heater used in accordance with its instructions to ensure that it functions properly.

Keep this manual in a safe place. If the attachment is to be used by a third party, this instruction manual must be supplied with it.

No liability can be accepted for any damage caused by non-compliance with these instructions or any other improper use or mishandling.

Warning! Do not use this attachment or any heater if it has been damaged in any way. Return it immediately to the retailer. Heaters in particular should be checked annually for electrical safety in order to limit the risk of electric shock or fire.

Warning! Always unplug from mains supply any heater when not in use. Do not abuse or damage the power cord. Fully unwind the cord before use as a coiled cord may overheat.

Warning! Caution. Be aware of the danger to young children of any electrical appliance. Keep out of reach of young children. This airing attachment and any heater used with it are not intended for use by young children or infirm persons. Young children must be supervised to ensure that they do not play with the appliance.

Warning! Do not use any heater in the immediate surroundings of a bath, a shower or a swimming pool.

Warning! Do not use any heater near curtains or other combustible materials. Do not use outdoors. Do not use near a hot gas or electrical burner.

Warning! A heater must not be located directly below or in front of a socket outlet.

Warning! Do not use any heater in locations where flammable vapour or explosive dust is likely to exist.

Warning! Do not cover any heater. Always leave a gap around the heater.