



Wholehog 3 v2.0 Release Notes

Current version: 2.0 (1201) October 16, 2006



New Features

Version 2.0 (build 1201)

Connectivity

This release focuses on network connectivity between products of the Wholehog 3 family. The Wholehog 3 console as well as Hog 3PC now use the same version and build numbers. Hog 3PC and the Hog iPC are now be able to connect to the Wholehog 3 console and vice versa.

Hog 3PC DP and IOP Support

The Hog 3PC software (stand alone and Hog iPC) now connects directly with DPs and IOPs in the same manner as the Wholehog 3 console. This functionality allows an unlimited number of DMX universes from all Wholehog 3 products.

Wings Manager

Playback and Expansion wings must now be configured within the Wing Manager. Auto configuration is no longer supported, however the new interface simplifies the addition and removal process.

Expansion Wing

Support for the new Expansion Wing allows connection of multiple expansion wings, and also includes a rework of the Wing Management interface.

Network Adaptor Selection

When using Hog 3PC stand alone or on a Hog iPC, you are now able to select the active network adaptor in the Control Panel/Network pane. See the on-line help or User Manual for instructions.

Updated User Manual

The Wholehog 3 User Manual has been updated regarding networking, Hog 3PC, and visualizer support. Many other sections have also been edited and revised to reflect recent software changes.

Spanish Language User Manual

A Spanish language version of the on-line help has been added.

Hog 3PC Support for MSD and Capture

All Wholehog 3 systems now support direct visualization with ESP Vision, WYSIWYG, MSD, and Capture.

Note:

Hog 3PC Control Panel Network Settings

Adjusting network settings such as IP settings in the **Control Panel/Network** window will alter the network settings of your Windows Operating System.

Wholehog 3 v2.0 (Build 1201) Bug Fixes

Bug Fixes as of October 16, 2006

- 4131 Error on merging show
- 5011 Incorrect NIC selection on windows platform
- 6251 Memory/Resource Leak during playback for extended uptime
- 6863 DTLB in malloc() during show load
- 7998 Wing desklight illumination problems
- 8249 LIVE @ (level) causes desktop to crash
- 8273 Playbase for Master Failure error when selecting a List from the List Directory with and without GUARD on
- 8339 No library for the Coemar Regoled
- 8448 Hog 3PC: Front Panel GUI Encoder resolution problems
- 8588 No libraries for the Elektralite 'my' series fixtures.
- 8696 Cues do not follow Fader values when already crossfading
- 8758 Encoder wheels causing jumpy color and gobo output
- 8978 Hog iPC - can not beacon superwidget from Control Panel
- 9046 Add Network Compatibility with console and PC versions
- 9131 Virtual Faders Option only working for 1-8
- 9168 Action of Go When Looping: "Stop At Next" damages the loop
- 9216 Add library for JB Lighting VaryLED 384
- 9217 Add library for JB Lighting Varyscan P6
- 9218 Add library for JB Lighting Varyscan P3
- 9232 Scrolling Editor Window Croaker
- 9273 active cuelists are halted when a DP is reset and begins loading show data
- 9281 Can not enter symbols from keyboard
- 9284 Color FX encoder requires too many encoder turns
- 9328 clicking on buttons in autoupdate causes network error
- 9347 Config Panel doesn't come back after exiting LTC and FP tests
- 9351 Add library for Martin Wizard
- 9355 Add link to missing Manuals in console code
- 9384 Recalling Palettes on client Hog iPC is messy can cause crash
- 9413 Manual Backup during Auto-backup causes show file corruption
- 9431 Recording Cuelist over a Scene on the same fader kills desktop .
- 9433 Studio Command has extra control setting
- 9445 Right Click in Cuelist window can crash Hog 3PC
- 9465 v1.3.8.9 Hog3 iso CD does not autorun
- 9467 Enable Hog 3PC connectivity with all Nodes (DPs, IOPs, etc)
- 9469 Cannot change iPC network (TCP/IP) settings
- 9470 Hidden main playback bar when loading a show
- 9488 PC should include ob and iop bin files from BRANCH_v1-3-8
- 9494 Stack Trace with Next in Cue Editor
- 9498 Wing panel and Fader prefs panel fight over wing updates
- 9506 Update Russian Help File / User Manual
- 9512 Active Scenes do not update their state when changed by record remove
- 9516 Follow cues start when previous cue is executed and not when previous is cue is finished
- 9534 PC: Re-enable the software update button in network window
- 9543 Add Spanish Online Help
- 9551 Console as Client to iPC will not affect fixtures
- 9612 DPs and IOPs can fail to upgrade properly to 1.3.9
- 9628 Auto-Backup field on Hog iPC should not display full path
- 9629 Auto-Backup path should wrap when very long
- 9650 Event Monitor opens behind Parent Windows
- 9679 Timecode toolbar disappears when parent window is minimized
- 9727 Hog iPC Help File: Extra Image in the wrong place
- 9733 Hog 3PC won't send MIDI Strings
- 9745 Hog 3PC library folder should be saved in My Documents
- 9755 New ELO touchscreens do not allow for held button presses
- 9757 Hog 3PC is missing Use Internal Keyboard Preference
- 9760 Wing Desklight level should be off at 0% and not at 70%
- 9772 Hog3PC: DMX Window Crasher

Wholehog 3 v2.0 (Build 1201) Bug Fixes

Bug Fixes continued

- 9780 Fatal Trap when changing the "action of go" while looping during an active loop
- 9787 Varilite 1K incorrect DMX range for gobo rotation.
- 9816 Win32 drivers must be versioned after each driver change.
- 9819 Remove Hog 3PC Handbook from Hog 3PC installer
- 9823 Right-click in palette directory opens front panel right-click menu.
- 9826 Error Assert when changing un-assigning wings
- 9831 Catalyst v3 & v4 XYZ Rotate ranges incorrect
- 9833 Hog iPC: most recent changes not saved on shutdown or reboot.
- 9876 Found Touchscreens list does not populate
- 9877 Maxedia Base Library - Incorrect definition for Transition channel
- 9886 Novalight Novaflower Colour Problems
- 9897 Update DL2 Libraries
- 9898 Fader always locks on page change if cuelist/scene intensity is at 0% but other parameters are active
- 9905 Wheelset toolbar doesn't display properly on Hog 3PC
- 9909 Playback Bar 1 comes up below the main playback bar on startup
- 9912 Cannot renumber from client console
- 9915 Add "Lightning Strikes" fixtures to library
- 9922 Virtual Faders options overrides console faders
- 9924 Hog3 PC platform does not work with some visualizers
- 9926 Hog3PC does not retain DHCP settings correctly
- 9933 Remember Fader Value doesn't work if there isn't a cuelist on same master on subsequent pages
- 9945 The highest numbered playback bar gets redocked on show load
- 9958 Switching between SVideo and Camera crashes desktop
- 9960 Add image of console front panel to user manual
- 9972 Right Hand Screen Toolbars are get ugly when turning encoder wheel
- 9978 If Hog3PC fails if it is set to obtain IP address from DHCP Server and a DHCP server isn't present
- 9987 Hog3 Console does not ignore PC v1.3.9 xtti file version 11
- 10005 Fader levels get set to FULL on show load regardless of front panel levels
- 10009 Server process does not bind to configured adapter
- 10016 Add MS Loopback Adapter to image
- 10025 Add Library for Martin MAC TW1 (tungsten moving head wash)
- 10028 Remove Lamp Strike & Lamp Douse from HES Studio Command H protocol
- 10029 Remove extra Strobe modes from HES Studio Command H protocol
- 10030 Remove Strobe from slots toolbar for HES Studio Command H protocol
- 10031 Add Library for HES Studio Command 1200
- 10039 add installation check for release 7.x
- 10040 Add check to installer for image 7.x
- 10067 Robe fixtures - incorrect DMX values for 0Hz strobe features
- 10086 Slotted parameters jump backwards with delay times