

Anaren®

What'll we think of next?®



Anaren Integrated Radio

A8520E24A91 User's Manual

Release Date: 03/26/12



Anaren Integrated Radio

THIS PAGE INTENTIONALLY LEFT BLANK

USER'S MANUAL

Model A8520E24A91

Contents

| | | |
|----------|---|----|
| 1. | Overview | 5 |
| 1.1. | Features..... | 6 |
| 1.2. | Theory of Operation..... | 6 |
| 1.2.1. | Network Topology and Nomenclature | 8 |
| 1.2.2. | Adaptive Frequency Hopping | 9 |
| 1.3. | Applications | 10 |
| 2. | Approvals and Usage | 11 |
| 2.1. | Product Approvals..... | 11 |
| 2.1.1. | USA (Federal Communications Commission, FCC)..... | 11 |
| 2.1.1.1. | FCC Labeling Requirements | 11 |
| 2.1.1.2. | End User Manual | 12 |
| 2.1.1.3. | RF Exposure..... | 12 |
| 2.1.2. | Canada (Industry Canada, IC)..... | 13 |
| 2.1.2.1. | IC Labeling Requirements | 13 |
| 2.1.2.2. | RF Exposure..... | 14 |
| 2.1.3. | Europe (Conformité Européenne, CE)..... | 15 |
| 2.2. | Potential Interference Sources | 16 |
| 2.3. | Approved Usage | 16 |
| 2.3.1. | USA and Canada..... | 16 |
| 2.3.2. | Europe | 17 |
| 3. | Electrical Characteristics | 18 |
| 3.1. | Absolute Maximum Ratings | 18 |
| 3.2. | Operating Conditions | 19 |
| 3.3. | Pin Out..... | 19 |
| 3.4. | Recommended Layout (dimensions in mm) | 21 |
| 3.5. | Power Supply Considerations..... | 22 |
| 4. | Mechanical and Process..... | 24 |
| 4.1. | Radio Module Details (dimensions in mm)..... | 24 |
| 4.2. | Packaging Details (dimensions in mm)..... | 24 |
| 4.2.1. | Matrix Tray Packaging | 25 |
| 4.2.2. | Tape-Reel Packaging | 25 |
| 4.3. | Soldering..... | 26 |
| 4.3.1. | Manual Mounting Procedure | 26 |
| 4.3.2. | Automated Mounting Procedure | 27 |
| 5. | Configuration and Programming | 29 |
| 5.1. | Calibrating Transmit Power | 29 |
| 5.2. | Programming | 30 |



THIS PAGE INTENTIONALLY LEFT BLANK

1. Overview

The A8520E24A91 module is a surface mount module integrating a CC8520PurePath™ wireless audio transceiver with the CC2591 PA/LNA device for increased range and an integral antenna. The module incorporates a crystal, the required RF matching and filtering for regulatory compliance as well as filtering on all digital lines for noise reduction and sensitivity. The module operates in the global non-licensed 2.4GHz ISM/SRD frequency band. This radio module is ideal for achieving low power, long range wireless connectivity without having to deal with extensive protocol, RF, antenna design and regulatory compliance, allowing quick time to market. The modules are 100% tested to provide consistent performance.

The A8520E24A91 module has received regulatory approvals for modular devices in the United States (FCC), Canada (IC) and Europe (ETSI). The modular approval allows the end user to place an A8520E24A91 module inside a finished product without having to perform costly regulatory testing for an intentional RF radiator. Section 2.3 has information on the requirements for the end user/integrator to fulfill in order to use the modules without intentional radiator regulatory testing.

This manual applies to both current and prior versions of the A8520E24A91 module, with the following conditions:

Table 1 Module versions

| FCC ID IC ID | European Usage | Operating Temperature | Max PurePath Power setting |
|----------------------------------|-------------------|--------------------------|-------------------------------|
| X7J-A10051702 8975A-A10051701 | YES (CE mark) | As listed | As listed |
| X7J-A10051701 8975A-A10051701 | NO | -20°C to +85°C | 0 (USA/CA) |

The A8520E24A91 is based on the CC8520 transceiver and the CC2591 range extender chips, both from Texas Instruments (TI). All control lines are provided at module level for full control of its operation. Please see the datasheets for CC8520 and CC2591 (www.ti.com) for how to operate, program and control the module. The PurePath™ protocol is developed, by TI, specifically for the CC85xx series chips and specifically for digital audio distribution. At the extremes of its range, the protocol provides graceful degradation of the audio signal using algorithms like interpolation, to make intermittent connectivity inaudible. Thus the A8520E24A91 module is not suitable for strict data transport.

The module/protocol must be configured and programmed by the OEM/Integrator to setup the specific Codec chip used for audio conversion, and to setup control buttons and manufacturer/network addresses. This is described in detail in the CC8520 datasheet, users' guide and PurePath™ documentation on TI website (www.ti.com). Specifics pertaining to calibrating the transmit power from the module is covered in section 5.1.

The A8520E24A91 module measures 11 mm x 19 mm x 2.5 mm.



1.1. Features

Features:

- Un-Compressed Wireless Audio Connectivity
- Pre-defined protocol
- Configurable human interface
- Autonomous or Hosted mode
- 2.2 to 3.6 V operation
- Programmable output power up to +19 dBm
- RoHS Compliant
- Very small package size: 11mm x 19mm x 2.5mm

Benefits Summary:

- Operating temperature -40 to +85°C
- 100% RF Tested in production for repeatable performance
- No RF engineering experience necessary
- No protocol experience necessary
- Only requires a 2 layer Host PCB implementation
- FCC & IC certified, ETSI compliant
- No regulatory “Intentional radiator” testing required for integrating module into end product. Simple certification labeling replaces testing.

1.2. Theory of Operation

The A8520E24A91 interfaces directly to an audio Codec chip through the I²S for audio data and I²C for volume control and other Codec chip settings.

A block diagram is given for the A8520E24A91 module in Figure 1.

- Antenna
 - The antenna couples energy between the air and the module. The integral antenna ($f_c = 2441.75$ MHz) provides a near omni-directional antenna pattern with high efficiency such that the application will work equally well in any direction. Note that the end radiation pattern depends not only on the antenna, but also the ground plane, enclosure and installation environment.
- Filtering
 - Filtering removes spurious signals to comply with regulatory intentional radiator requirements, provides reduced susceptibility to power supply and digital noise, and filters out RF and high frequency noise from the digital audio and control link (I²S, I²C).
- Matching
 - The matching provides the correct loading of the transmit amplifier to achieve the highest output power as well as the correct loading for the receive LNA to achieve the best sensitivity.
- Protocol
 - The protocol implements an entire wireless audio transport mechanism with adaptive frequency usage, retransmission of lost packets as well as a low data rate link for remote control purposes.






Figure 1 The functionality of the A8520E24A91, using an integral antenna

Table 2 Approved Antenna

| Item | Part Number | Manufacturer | Type | Gain dBi) |
|------|------------------------------|--------------|------------------|-----------|
| 1 | Integral part of A8520E24A91 | Anaren | Integral Antenna | 2 |



1.2.1. Network Topology and Nomenclature

An A8520E24A91 network consists of one Protocol Master (PM) and one or two Protocol Slave(s) (PS). The PM provides the audio reference clock and controls network association. The PS regenerates the audio reference clock based on the packets received. Audio can be transmitted from the PM to the PS. The device receiving the audio is called an Audio Sink, and the device sending the audio is called an Audio Source. A device can be both an Audio Sink and an Audio Source at the same time (bidirectional audio will be supported in future revisions of the TI PurePath firmware). The A8520E24A91 network also includes a Data Side-Channel which is a bi-directional data link between the PM and all PSs in the network.




Figure 2 A8520E24A91 topologies supported for different A8520E24A91 firmware revisions.
See TI website for latest releases



1.2.2. Adaptive Frequency Hopping

The purpose of using frequency hopping in a radio system is to provide diversity that allows data throughput to be maintained even if the interfering radio systems or the physical environment (e.g. multipath fading) renders some RF channels unusable. In the 2.4 GHz ISM band, the sheer amount of radio systems and the severity and dynamic nature of indoor fading phenomena in typical operating environments require the use of this kind of diversity if a minimum data throughput is to be guaranteed (as audio streaming requires). Frequency hopping systems can either implement a fixed sequence of channel hops or adapt its hopping sequence dynamically to the changing environment it operates in. In order to maximize its own chances of delivering audio data in time and to co-exist amicably with other fixed-frequency or adaptive frequency hopping systems, PurePath™ Wireless uses an adaptive frequency hopping (AFH) scheme that adapts to changing conditions within tens of milliseconds. PurePath Wireless divides the 2.4 GHz band into 18 RF channels with 4 MHz bandwidth. A protocol master that controls the adaptive frequency hopping scheme for the audio network, maintains a table with an entry for each RF channel and an associated quality-of-service (QoS) estimate for each. Each time an RF channel is used the QoS estimate is updated based on what happens during the timeslot. The frequency hopping algorithm separates the 18 RF channels into two sets:

- A set of 4 active channels
- A set of 14 trial channels


The active channel set contains the preferred RF channels that have proven that they provide sufficiently good quality-of-service. The trial channel set contains the remaining RF channels that are only evaluated occasionally in order to be able to maintain an accurate picture of their quality-of-service. If the QoS estimate of an RF channel in the active set goes beyond a minimum threshold this channel is swapped out with the RF channel in the trial channel set that has the best QoS estimate. Other factors play in when selecting a new RF channel to the active channel set, such as trying to maintain a certain minimum distance in frequency between the different active channels.

The frequency hopping algorithm, when no swaps between the active and trial channel sets occur, goes through a sequence of 70 hops over the course of which every RF channel has been used.

- This 70-hop macrosequence consists of 14 repetitions of a
 - 5-hop microsequence during which
 - Each of the four active RF channels are used once
 - One of the trial RF channels is used once (cycling through all trial channels over the course of a macrosequence)

Figure 3 illustrates this concept. This gives an average steady-state RF channel usage in an audio network of:

- Each of the four active channels are used 20% of the time
- Each trial channel is used 1.43% of the time






Figure 3 Example of AFH hop sequence (active set in color, trial set in black/gray)
The channels correspond to center frequencies as given in Table 3.

Table 3 Channel to center frequency

| Channel | Center Frequency [MHz] | Channel | Center Frequency [MHz] |
|---------|------------------------|---------|------------------------|
| 1 | 2406 | 10 | 2442 |
| 2 | 2410 | 11 | 2446 |
| 3 | 2414 | 12 | 2450 |
| 4 | 2418 | 13 | 2454 |
| 5 | 2422 | 14 | 2458 |
| 6 | 2426 | 15 | 2462 |
| 7 | 2430 | 16 | 2466 |
| 8 | 2434 | 17 | 2470 |
| 9 | 2438 | 18 | 2474 |

1.3. Applications

- Wireless headphones
- Wireless headsets
- Wireless speakers
- Wireless studio equipment
- Wireless microphones



Anaren Integrated Radio

2. Approvals and Usage

The A8520E24A91 has been designed to meet FCC (US), IC (Canada) and ETSI (Europe) regulations. In particular the radio modules have been certified to the following.

2.1. Product Approvals

2.1.1. USA (Federal Communications Commission, FCC)

The A8520E24A91 with integrated antenna has been tested to comply with FCC CFR47 Part 15 sub-part C “Intentional Radiators. The devices meet the requirements for modular transmitter approval as detailed in FCC public notice DA 00-1407 Released: June 26, 2000. The A8520E24A91 module eliminates the need to re-perform ‘intentional radiator’ testing when submitting an end product for certification.

(15.19a3) The module complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

2.1.1.1. FCC Labeling Requirements

The A8520E24A91 modules have been labeled with their own FCC ID number and if the FCC ID is not visible when the module is installed inside another device, then the outside of the finished product into which the module is installed must also display a label referring to the enclosed module. This exterior label can use wording such as the following:

Contains Transmitter Module FCC ID: X7J-A10051702

-or-

Contains FCC ID: X7J-A10051702

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

It is the user’s responsibility to ensure the proper FCC identification number is used when marking the exterior of the unit.



Anaren Integrated Radio

2.1.1.2. End User Manual

The end user manual should include the following statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2.1.1.3. RF Exposure

All transmitters regulated by FCC must comply with RF exposure requirements. OET Bulletin 65 “Evaluating Compliance with FCC Guidelines for Human Exposure to Radio Frequency Electromagnetic Fields” provides assistance in determining whether proposed or existing transmitting facilities, operations or devices comply with limits for human exposure to Radio Frequency (RF) fields adopted by the Federal Communications Commission (FCC). The bulletin offers guidelines and suggestions for evaluating compliance.

If appropriate, compliance with exposure guidelines for mobile and unlicensed devices can be accomplished by the use of warning labels and by providing users with information concerning minimum separation distances from transmitting structures and proper installation of antennas.

The following statement must be included as a CAUTION statement in manuals and OEM products to alert users of FCC RF Exposure compliance:

To satisfy FCC RF Exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

If the A8520E24A91 module is used in a portable application (antenna is less than 20 cm from persons during operation), the integrator/OEM is responsible for performing Specific Absorption Rate (SAR) testing in accordance with FCC rules 2.1093.



Anaren Integrated Radio

2.1.2. Canada (Industry Canada, IC)

The A8520E24A91 modules have been certified for use in Canada under Industry Canada (IC) Radio Standards Specification (RSS) RSS-210 and RSS-Gen.

From section 3.2 RSS-Gen, Issue 3, December 2010, Modular Approval for Category I Equipment or Category II Equipment:

“Modular approval permits the installation of the same module in a host device or multiple host devices without the need to recertify the device. Equipment certification for a modular device may be sought for either Category I equipment or Category II equipment.

Transmitters designed as modules for the installation in a host device may obtain equipment certification as a modular device provided that the applicable RSS is met and the following conditions in this section are met.”

In section 7.1.2 Transmitter Antenna, it has been mentioned that the user manuals for transmitters shall display the following notice in a conspicuous location:

Notice: *Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.*

Avis: *Sous la réglementation d'Industrie Canada, ce transmetteur radio ne peut fonctionner qu'en utilisant seulement une antenne d'un type et d'un maximum (ou moins) de gain approuvé pour l'émetteur par Industrie Canada. Pour réduire des potentielles interférences radio pour les autres utilisateurs, le type d'antenne et son gain doivent être choisis de sorte que la puissance isotrope rayonnée équivalente (PIRE) ne dépasse pas ce qui est nécessaire pour une communication réussie.*

2.1.2.1. IC Labeling Requirements

From section 3.2.1 RSS-Gen, Issue 3, December 2010, Labeling Requirements for the Host Device:

The host device shall be properly labeled to identify the modules within the host device. The Industry Canada certification label of a module shall be clearly visible at all times when installed in the host device, otherwise the host device must be labeled to display the Industry Canada certification number of the module, preceded by the words “Contains transmitter module”, or the word “Contains”, or similar wording expressing the same meaning.

From section 5.2, RSS-Gen, Issue 3, December 2010, Equipment Certification Numbers and Labels: Every unit of Category I radio apparatus certified for marketing and use in Canada shall



Anaren Integrated Radio

bear a permanent label on which is indelibly displayed the model number and Industry Canada certification number of the equipment model (transmitter, receiver, or inseparable combination thereof). Each model shall be identified by a unique combination of a model number and a certification number, which are assigned as described below in this section.

The label shall be securely affixed to a permanently attached part of the device, in a location where it is visible or easily accessible to the user, and shall not be readily detachable. The label shall be sufficiently durable to remain fully legible and intact on the device in all normal conditions of use throughout the device's expected lifetime. These requirements may be met either by a separate label or nameplate permanently attached to the device or by permanently imprinting or impressing the label directly onto the device.

The label text shall be legible without the aid of magnification, but is not required to be larger than 8-point font size. If the device is too small to meet this condition, the label information may be included in the user manual upon agreement with Industry Canada.

Label:

Contains/Contient IC: 8975A- A10051701

Notice: This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Avis: Cet appareil est conforme avec Industrie Canada RSS standard exempts de licence (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne peut pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.

For more information see: Industry Canada <http://www.ic.gc.ca/>

2.1.2.2. RF Exposure

All transmitters regulated by IC must comply with RF exposure limits as set forth in RSS-102, Issue 4, section 4, "Exposure Limits". Furthermore RSS-102, Issue 4, Section 2 "Certification Requirements", provides assistance in determining the specific requirements for compliance. If appropriate, compliance with exposure guidelines for mobile and unlicensed devices can be accomplished by the use of warning labels and by providing users with information concerning minimum separation distances from transmitting structures and proper installation of antennas.



Anaren Integrated Radio

The following statement must be included as a CAUTION statement in manuals and OEM products to alert users of IC RF Exposure compliance:

Notice: To satisfy IC RF Exposure requirements for mobile and base station transmission devices, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during operation. To ensure compliance, operation at closer than this distance is not recommended. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Avis: Pour répondre à la IC d'exposition pour les besoins de base et mobiles dispositifs de transmission de la station, sur une distance de séparation de 20 cm ou plus doit être maintenue entre l'antenne de cet appareil et les personnes en cours de fonctionnement. Pour assurer le respect, l'exploitation de plus près à cette distance n'est pas recommandée. L'antenne (s) utilisé pour cet émetteur ne doit pas être co-localisés ou fonctionner conjointement avec une autre antenne ou transmetteur.

If the A8520E24A91 module is used in a portable application (antenna is less than 20 cm from persons during operation), the integrator/OEM is responsible for performing Specific Absorption Rate (SAR) testing in accordance with IC rules and methods of RSS-102.

2.1.3. Europe (Conformité Européenne, C€)

The A8520E24A91 module has been certified for use in European countries. The following tests have been performed and the module found to be compliant to the requirements:


Test standard ETSI EN 300 328 V1.7.1 (2006-10)

- Maximum Isotropic Radiated Power (Normal and Extreme Conditions)
- Maximum e.i.r.p. Spectral Density
- Frequency Range (Normal and Extreme Conditions)
- Transmitter Spurious Emissions
- Receiver Spurious Emissions

Test standards ETSI EN 301 489-1:2008 and ETSI EN 301 489-17:2008

- Radiated Emissions
- Electro-Static Discharge
- Radiated RF Susceptibility

A helpful document that can be used as a starting point in understanding the use of short range devices (SRD) in Europe is the European Radio Communications Committee (ERC) Recommendation 70-03 E, downloadable from the European Radio Communications Office (ERO) <http://www.ero.dk>.



The end user is responsible for ensuring compliance with harmonized frequencies and labeling requirements for each country the end device is marketed and sold.

For more information see:

- Radio And Telecommunications Terminal Equipment (R&TTE) http://ec.europa.eu/enterprise/rtte/index_en.htm
- European Conference of Postal and Telecommunications Administrations (CEPT) <http://www.cept.org/>
- European Telecommunications Standards Institute (ETSI) <http://www.etsi.org/>
- European Radio Communications Office (ERO) <http://www.ero.dk/>

2.2. Potential Interference Sources

The two main mechanisms that allow a PurePath wireless system to co-exist amicably in close proximity to other 2.4 GHz radio systems are:

- The adaptive frequency hopping scheme described in section 2.2 that ensures that RF channels used by other radio systems are avoided
- Adaptive listen-before-talk mechanism that measures energy in RF channel before transmitting and avoids transmitting if the channel is already in use

These mechanisms together ensure that other radio systems are minimally impacted by a PurePath Wireless audio network in normal circumstances. However, since a low-latency audio network by its very nature transports a very time-critical data stream, both mechanisms have adaptive thresholds to ensure that the audio network is given its fair share of RF spectrum in very crowded RF environments.

2.3. Approved Usage

The A8520E24A91 module has been approved for use in the US, Canada and Europe. The user is encouraged to use minimum power required to establish a link, thus minimizing interference.

Changes or modifications to the module and/or operation outside the limits are prohibited and could void the user's authority to operate the modules.

2.3.1. USA and Canada

Within the USA and Canada, the A8520E24A91 modules have been approved for use as digitally modulated transmitters, for which they conform to the BW (a minimum of 500 kHz 6-dB BW for US, a maximum BW of 0.5% of the carrier frequency for Canada), power spectral density (max of 8 dBm / 3 kHz), total output power (max of 1W including the antenna gain) and spurious radiation (harmonics and others including the restricted bands) requirements.




Anaren Integrated Radio

The A8520E24A91 module has been approved for use up to the max available power level that the module can give (power setting 4), however, the user is encouraged to use minimum power required to establish a link in order to minimize interference.

2.3.2. Europe

For Europe, the maximum power is 100mW with a maximum spectral power density of 10mW/MHz. In order to meet the power spectral density requirements, the A8520E24A91 module's output power level must be reduced and kept at a maximum power setting of -3. This setting corresponds to an output power level of 11.3 dBm.


NOTE: Prior versions of the A8520E24A91 **without** CE mark are not permitted for use in the European Union.



3. Electrical Characteristics

3.1. Absolute Maximum Ratings

Under no circumstances must the absolute maximum ratings given in Table 4 be violated. Stress exceeding one or more of the limiting values may cause permanent damage to the device.



Caution!
ESD sensitive device. Precaution should be used when handling the device in order to prevent permanent damage.



Caution!
This assembly contains moisture sensitive devices and requires proper handling per IPC/JEDEC J-STD-033

Table 4 Absolute Maximum Ratings

| Parameter | Min | Max | Unit | Condition/Note |
|----------------------------|------|------------------|------|--|
| Supply Voltage (Vdd) | -0.3 | 3.6 | V | |
| Voltage on any digital pin | -0.3 | Vdd+0.3, max 3.6 | V | |
| RF input power | | 0 | dBm | |
| Storage Temperature | -50 | 150 | °C | |
| Solder reflow temperature | | 260 | °C | According to IPC/JEDEC J-STD-020D |
| ESD | | <500 | V | According to JEDEC STD 22, method A114, Human body model |
| ESD | | 400 | V | According to JEDEC STD 22, C101C, Charged Device Model (CDM) |



Anaren Integrated Radio


3.2. Operating Conditions

Table 5 Operating conditions

| Parameter | Min | Max | Unit | Condition/Note |
|----------------------|-----|-----|------|--|
| Supply Voltage (Vdd) | 2.2 | 3.6 | V | |
| Supply Voltage IOVdd | 1.8 | 3.6 | V | |
| Temperature Range | -40 | +85 | °C | For prior versions, see Table 1 for lowest operating temperature |

3.3. Pin Out

The A8520E24A91 radios share a common pin-out and foot print, thus enabling the use of the same application PCB layout for US/Europe and low power (short range) versus higher power (long range). Below the footprint is shown.



NC = NO Connection. Pin is NOT connected internally.

DNC = Do Not Connect. Internal connection used during assembly, do not connect.

Figure 4 Module pin-out view



Table 6 pin-out table, with references to chip pins

| Pin Number | Pin Name | Pin Type | Description | CC259x Pin | CC85xx Pin |
|------------|------------|-------------------------|---|------------|------------|
| 1 | GND | Common Ground | | | |
| 2 | DNC | | Do Not Connect. Connecting this pin to anything will significantly affect the performance of the module and may void the end users right, under FCC, to operate the module | | |
| 3 | GND | Common Ground | | | |
| 4 | DNC | Power/Decoupling | Do Not Connect. This pin should not be used unless deemed necessary in particular noisy power supply environments, See "power supply consideration" section for more information | | |
| 5 | VBAT | Analog Input | Battery voltage supervisor (threshold level programmable by external resistor to positive battery terminal) | | 29 |
| 6 | SCL, GIO10 | Digital I/O | I2C master clock line. Must be connected to external pull-up, General-purpose digital I/O pin 10 | | 32 |
| 7 | SDA, GIO11 | Digital I/O | Digital I/O1 I2C master data line. Must be connected to external pull-up, General-purpose | | 33 |
| 8 | GIO12 | Digital I/O | General-purpose digital I/O pin 12 | | 34 |
| 9 | GIO13 | Digital I/O | General-purpose digital I/O pin 13 | | 35 |
| 10 | XPAEN/PAEN | Digital Out | The CC85xx asserts this pin high to turn on the CC259x power amplifier for transmit. The pin can be used to detect the radio state to synchronize other system events e.g. to smooth out power consumption or minimize noise injection. A high indicates that the PA is on. At no time will both XPAEN and XLNAEN be high at the same time. | 5 | 36 |
| 11 | XLNAEN/EN | Digital Out | The CC85xx asserts this pin high to turn on the CC259x low noise amplifier. The pin can be used to detect the radio state to synchronize other system events e.g. to turn of noise/switching sources for better sensitivity. At no time will both XPAEN and XLNAEN be high at the same time. | 6 | 38 |
| 12 | GND | Common Ground | | | |
| 13 | DNC | Digital I/O | Do Not Connect (future antenna diversity control or USB interface) | | 1 |
| 14 | DNC | Digital I/O | Do Not Connect (future antenna diversity control or USB interface) | | 2 |
| 15 | CS_N | Digital Input (Pull-up) | Serial SPI configuration interface, active low chip select | | 3 |
| 16 | SCLK | Digital I/O | Serial SPI configuration interface, clock input/output | | 4 |
| 17 | MOSI | Digital I/O | Serial SPI configuration interface, master data input, slave data output | | 5 |
| 18 | MISO, GIO0 | Digital I/O | Serial SPI configuration interface, master data output, slave data input GIO0 output when CS_N is deasserted. General-purpose digital I/O pin 0 | | 6 |
| 19 | GIO1 | Digital I/O | General-purpose digital I/O pin 1, Configurable with PurePath™ Wireless Configurator | | 7 |
| 20 | GIO2 | Digital I/O | General-purpose digital I/O pin 2 | | 8 |
| 21 | GIO3 | Digital I/O | General-purpose digital I/O pin 3, Configurable with PurePath™ Wireless Configurator | | 9 |
| 22 | GND | Common Ground | | | |
| 23 | RSTN | Digital Input (Pull-up) | Active-low device reset | | 11 |
| 24 | MCLK | Digital I/O | Digital I/O1 Master clock output for external audio devices (GIO4). | | 13 |
| 25 | BCLK | Digital I/O | Digital I/O1 I2S/DSP audio interface bit clock (in/out) (GIO5). | | 14 |
| 26 | WCLK | Digital I/O | Digital I/O1 I2S/DSP audio interface word clock (in/out) (GIO6). | | 15 |
| 27 | AD0 | Digital I/O | Digital I/O1 I2S/DSP audio interface data line 0 (in/out) (GIO7). | | 16 |
| 28 | AD1 | Digital I/O | Digital I/O1 I2S/DSP audio interface data line 1 (in/out) (GIO8). | | 17 |
| 29 | AD2, GIO9 | Digital I/O | Digital I/O2 I2S/DSP audio interface data line 2 (in/out), Configurable with PurePath™ Wireless Configurator | | 19 |
| 30 | GND | Common Ground | | | |
| 31 | HGM | Digital Input | Digital control pin. HGM=1 → CC259x LNA is in High Gain Mode (~10dB gain), HGM=0 → CC259x LNA is in Low Gain Mode (~0dB gain). Can be used to avoid overdriving the receiver in case the transmitter is in very close proximity to the receiver, otherwise do not connect. | 7 | |
| 32 | IOVDD | Power (I/O pins) | Digital power supply for the digital core, GIO's SPI, I2C and I2S (1.8V to 3.6V) | | 10 |
| 33 | AVDD | Power (Analog) | Analog power supply connection for the Radio and PA/LNA (2.0V to 3.6V) | | 20 |
| 34 | GND | Common Ground | | | |



3.4. Recommended Layout (dimensions in mm)





Figure 5 Recommended PCB layout.





3.5. Power Supply Considerations

Noise on the power supply line reduces the sensitivity of a receiver and can modulate onto a transmitters signal, both of which causes a degradation of link quality and hence a reduction in range.

The A8520E24A91 radio modules have integral noise reduction in the supply line from pins 33 (Vdd) and 32 (IOVdd), consisting of ferrite beads and decoupling capacitances. This arrangement will take care of most supply voltage noise. For optimal performance in particular noisy environments (switching regulators, motor controls, etc.) it may be necessary to add additional noise reduction means, which can consist of a low noise LDO or additional LC filtering.

Pin 4 (AVdd_CC259x) is connected to the modules internal supply line after the ferrite bead and decoupling capacitors and can be used to probe the noise at module level. The noise level measured on pin 4 should not exceed 150mVpp when in transmit or receive mode, it may however exceed this value when not in either transmit or receive mode or in the transition itself (i.e. it may exceed this if synchronized to the XPAEN and XLNAEN signals).

If the level measured is exceeding the above limit means should be taken to ensure maximum range:

- Add decoupling capacitance to pin 4 (AVdd_CC259x), 1uF to 2.2uF ceramic capacitor is suggested (do not use Tantalum).
- Add decoupling capacitance to pin 33 (AVdd), 1uF to 2.2uF ceramic capacitor is suggested (do not use Tantalum).
- Add a low noise LDO in the supply line to pin 33 (AVdd) (the TPS731xx low Dropout Regulator from TI is recommended).



Note that if operated from a battery source there is no need for additional noise reduction. Also note that if the noise source can be synchronized to be off whenever the module is transmitting or receiving (using XPAEN and XLNAEN) then that will also suffice.



4. Mechanical and Process

4.1. Radio Module Details (dimensions in mm)




Figure 8 A8520E24A91 dimensions

4.2. Packaging Details (dimensions in mm)

AIR modules are available in Matrix Tray and Tape & Reel packaging for high-volume assembly. Details of packaging provided below:



4.2.1. Matrix Tray Packaging




Figure 9 A8520E24A91GM Matrix Tray Packaging Detail (27/Tray)

4.2.2. Tape-Reel Packaging




Figure 10 A8520E24A91GR Tape-Reel Packaging Detail (500/Reel)



4.3. Soldering

AIR Modules may be mounted either manually (for prototyping or low volume production), or automatically for high-volume production.

A no-clean tin/silver/copper (SAC) solder is recommended, however lead based no-clean pastes may also be used.

CAUTION: AIR Modules are designed for no-clean fluxes only. DO NOT use water-based fluxes that require aqueous cleaning after solder. Spot cleaning with a flux remover and toothbrush may be performed with care.

4.3.1. Manual Mounting Procedure

The recommended soldering method is reflowing of a paste solder on a hot plate. This method works provided the bottom of the board where the AIR module is to be mounted is accessible, and there are no bottom-side components in the way.

An aluminum or copper block may be placed on the hot plate surface to transfer heat to a localized area on the board where the AIR module is mounted

- Set the hot plate to the reflow temperature solder manufacturer's recommended
- Apply solder paste to the pads on the board receiving the AIR module
- Place the AIR module carefully onto the dispensed solder
- Using tweezers or another holding device, carefully place board with AIR module onto the hot plate surface (or metal block)
- Apply heat until reflow occurs, per solder paste manufacturer's recommendations
- Carefully remove the board and place on a heat-resistant surface to cool
- Check assembly electrically to confirm there are no opens or shorts



4.3.2. Automated Mounting Procedure


The AIR Radio Module recommended solder reflow profile is based on IPC/JEDEC J-STD-020.

Table 5-2 Classification Reflow Profiles

| Profile Feature | Sn-Pb Eutectic Assembly | Pb-Free Assembly |
|---|-------------------------|------------------|
| Average ramp-up rate (T _{smax} to T _p) | 3° C/second max. | 3° C/second max. |
| Preheat | | |
| - Temperature Min (T _{smin}) | 100 °C | 150 °C |
| - Temperature Max (T _{smax}) | 150 °C | 200 °C |
| - Time (T _{smin} to T _{smax}) (t _s) | 60-120 seconds | 60-180 seconds |
| Time maintained above: | | |
| - Temperature (T _L) | 183 °C | 217 °C |
| - Time (t _L) | 60-150 seconds | 60-150 seconds |
| Peak Temperature (T _p) | See Table 4.1 | See Table 4.2 |
| Time within 5°C of actual Peak Temperature (t _p) ² | 10-30 seconds | 20-40 seconds |
| Ramp-down Rate | 6 °C/second max. | 6 °C/second max. |
| Time 25°C to Peak Temperature | 6 minutes max. | 8 minutes max. |

Note 1: All temperatures refer to topside of the package, measured on the package body surface.

Note 2: Time within 5 °C of actual peak temperature (t_p) specified for the reflow profiles is a “supplier” minimum and “user” maximum.



Classification Reflow Profile



SnPb Eutectic Process - Package Peak Reflow Temperatures

| Package Thickness | Volume mm ³ <350 | Volume mm ³ ≥ 350 |
|-------------------|--------------------------------|---------------------------------|
| <2.5 mm | 240 +0/-5 °C | 225 +0/-5 °C |
| ≥ 2.5 mm | 225 +0/-5 °C | 225 +0/-5 °C |

Pb-free Process - Package Peak Reflow Temperatures

| Package Thickness | Volume mm ³ < 350 | Volume mm ³ 350 - 2000 | Volume mm ³ > 2000 |
|-------------------|---------------------------------|--------------------------------------|----------------------------------|
| < 1.6 mm | 260 °C * | 260 °C * | 260 °C * |
| 1.6 mm - 2.5 mm | 260 °C * | 250 °C * | 245 °C * |
| > 2.5 mm | 250 °C * | 245 °C * | 245 °C * |

* Tolerance: The device manufacturer/supplier shall assure process compatibility up to and including the stated classification temperature at the rated MSL level



5. Configuration and Programming

The integrator of this module into an application must program the module to match both the Codec chip used and the human interface methods employed. To do this the integrator must use the PurePath™ software from TI to configure the module

5.1. Calibrating Transmit Power

This power calibration number is an approximate power output value in dBm for the CC85xx chip – however the module CC2591 adds additional 16dB amplification.

It can be useful to set a lower power for systems that do not require the full range and thus save on power consumption. The typical power consumption at 3.3v supply for a A8520E24A91 module is shown below depending on the output power setting.

NOTE: For prior versions, see Table 1 for the maximum permitted PurePath power setting

Table 7 Transmit power settings

| PurePath Power Setting | Module Output Power (Approximate) | Peak Current Consumption | Average Current Consumption [mA] | |
|------------------------|-----------------------------------|--------------------------|----------------------------------|-------|
| | | | @ 3.3V AVdd,IOVdd, Ambient* | |
| [dBm] | [dBm] | [dBm] | Master | Slave |
| 4 | 20 | 184 | 78 | 36 |
| 3 | 19 | 174 | 72 | 35 |
| 2 | 17 | 147 | 64 | 34 |
| 1 | 15 | 143 | 63 | 34 |
| 0 | 13 | 118 | 55 | 32 |
| -1 | 13 | 118 | 54 | 32 |
| -2 | 12 | 113 | 52 | 32 |
| -3 | 11 | 106 | 50 | 32 |
| -4 | 11 | 106 | 50 | 32 |
| -5 | 10 | 99 | 48 | 31 |
| -6 | 10 | 97 | 47 | 31 |
| -7 | 10 | 97 | 47 | 31 |
| -8 | 8 | 94 | 46 | 31 |
| -9 | 7 | 92 | 46 | 31 |
| -10 | 6 | 91 | 46 | 31 |

* PurePath application state set to “stereo audio”

In the PurePath™ configurator when creating the application image, in the “Radio” page for both master and slave the target Tx power must be set to the max allowed power level, or lower, (note that the max allowed power setting for US and Canada is 4. However for Europe, only the power settings up to -3 are allowed due to power spectral density limits). Figure 11 indicates the location for setting the module output power. PurePath Wireless Configurator 1.3.0.36447 has been used for the current measurements.






Figure 11 PurePath Wireless Configurator window

Alternatively the power calibration can be done immediately after programming of each module using the SPI host controller interface, using the `CAL_SET_DATA` function. This option is useful if the same image will be used in multiple equipment, of which some have the power turned down further than the max allowed power level to save current consumption, however it requires a host processor.

5.2. Programming

The desired application image can be programmed into the module either using the PurePath™ software and the included CC-Debugger. Or the PurePath™ software can be used to create the desired image, which is saved and the integrator can use an in-house developed production programmer to upload the image.

If developing an in-house programmer there are a few things to consider to successfully program the CC8520 chip. Programming procedure:

```
// Enter the bootloader
BOOT_RESET();
BL_UNLOCK_SPI();
Check SWR Proceed only if SWR matches required value (Reset device and Restart
programming again)
// Erase the flash
```



Anaren Integrated Radio

```
BL_FLASH_MASS_ERASE();  
Check SWR Proceed only if SWR matches required value (Reset device and Restart  
programming again)  
// For each flash page  
for (int n = 0; n < 31; n++) {  
// Write page data to the start of the available RAM area  
SET_ADDR(0x6000, sw);  
WRITE(0x400, data to be programmed into flash page n , sw);  
/* While using the image generated by TI- Purepath Wireless Configurator, note that the entire  
image file generated by PWC-TI is Intel_hex format. For programming 8520 module use only  
the data and discard additional data/information */  
// Program the page  
BL_FLASH_PROG_PAGE(RAM_ADDR = 0x6000, FLASH_ADDR = 0x8000+(n*0x400))  
Check SWR Proceed only if SWR matches required value wait till the block is completely  
transferred  
}  
// Verify the flash contents  
BL_FLASH_VERIFY(BYTE_COUNT = value read from the HEX file );  
/* The flash verify byte count data is 4 byte value stored from location &h 8010 within the image  
file */  
Check SWR Proceed only if SWR matches required value (Reset device and Restart  
programming again)  
SYS_RESET()  
// Done, perform SYS_RESET() to start the application
```

If the status word read fails immediately after execution of `BOOT_RESET` or `BL_UNLOCK_SPI` then it is most likely due to the special SPI requirement during these instructions as MISO must go low and then high after the SPI clock sequence as shown in the figure below.




Figure 12 SPI clock sequence

If the SPI bus controller is unable to perform this wait, then use the SPI pins as GPIO's and manually program the bit sequences as described below for the `BOOT_RESET()`.

Procedure for programming `Boot_Reset()`

1. Assert CSn Low and then clock the SCL with each negative edge of clock asset the logic level to high or low on MOSI pin.



2. After sending &H B0 00 on MOSI pin. Wait till MISO pin goes high. Note: Status check/update is done between MISO and CSn pin going high. If this time is not sufficient. This will lead to error in SWR read value.

Once BOOT_RESET is successful then switch to normal SPI operation mode.

Please refer to the TI CC8520 PurePath documentation for more information.



DOCUMENT HISTORY


| Date | Author | Change Note No./Notes |
|----------|------------|---|
| 08/08/10 | Kirkeby | Initial Draft |
| 12/01/10 | Kirkeby | Initial Release, formatting and content chg. |
| 12/13/10 | Kirkeby | Programming and Tx power setting. |
| 08/09/11 | Stockwell | Updated fig. 5 sec 4.4, misc grammatical |
| 10/14/11 | Sula | Updated FCC/IC usage, and added ETSI section |
| 10/19/11 | Sula | Formatting in section 3.1.1. |
| 12/21/11 | Sula | Updated sections related to the approved power levels (section 5.1). |
| 01/31/12 | Sula | Added Chapter 5 – Mechanical and Process chapter, Configuration and Programming section was moved to Chapter 6 Updated Figure 5 Section 5.1 was modified with updated current values and PurePath screen shot |
| 02/03/12 | Sula | Figure 4 and Table 6 modified Some formatting applied Section 5.2 modified |
| 02/08/12 | Sula | Sub-section 5.2 is modified |
| 02/27/12 | Richardson | Updated theory of operation and block diagram |
| 03/07/12 | Richardson | Updated to clarify permissible operation of prior module versions |
| 03/26/12 | Richardson | Updated formats |



Attach distributor contact information
here

If you have additional questions, need samples, or would like a quote –
please email the AIR team at AIR@anaren.com .

For a full list of our franchised distributors, please visit our website:
<http://www.anaren.com/air/>



Anaren Microwave, Inc.
6635 Kirkville Road
East Syracuse, NY 13057
Tel: +1 315 432 8909
+1 800 411 6596
Fax: +1 315 432 8970

Anaren Microwave (Europe), Inc.
12 Somerset House, Suite 16 & 17
Hussar Court, Waterlooville
Hampshire, England P07-7SG
Tel: +44 2392 232392
Fax: +44 2392 251369

Anaren Communication Suzhou Co. Ltd.
No. 5 Chun Hui Road
Wei Ting, Suzhou Industrial Park
Suzhou 215122, PR China
Tel: +86 512 6287 6400
Fax: +86 512 6274 9283
