

**Spark 266**  
**User Guide**

---

# Table of Contents

|                                   |                              |
|-----------------------------------|------------------------------|
| <b>1 Know Your Phone</b> .....    | <b>4</b>                     |
| <b>2 Basic Operations</b> .....   | <b>6</b>                     |
| <b>3 Notable Features</b> .....   | <b>7</b>                     |
| 3.1 Secure your Phone .....       | 7                            |
| 3.2 Blacklist and Whitelist.....  | 8                            |
| 3.3 Manage Your Files .....       | 8                            |
| 3.4 Applications .....            | 8                            |
| 3.5 Connect to Internet.....      | 9                            |
| <b>4 Call Logs</b> .....          | <b>9</b>                     |
| <b>5 Lava Space</b> .....         | <b>10</b>                    |
| <b>6 Phonebook Features</b> ..... | <b>10</b>                    |
| <b>7 Lava Zone</b> .....          | <b>13</b>                    |
| <b>8 Multimedia</b> .....         | <b>13</b>                    |
| 8.1 Camera.....                   | 13                           |
| 8.2 Camcorder .....               | 13                           |
| 8.3 Audio Player .....            | 14                           |
| 8.4 Video Player .....            | 14                           |
| 8.5 Recorder .....                | 14                           |
| 8.6 KingMovie.....                | Error! Bookmark not defined. |
| 8.7 FM Radio.....                 | 15                           |
| 8.8 My Images .....               | 15                           |
| <b>9 Messages</b> .....           | <b>15</b>                    |
| 9.1 Write message .....           | 15                           |
| 9.2 Use message Templates .....   | 16                           |
| 9.3 Voice mail server.....        | 16                           |
| 9.4 Settings.....                 | 16                           |

---

|   |                              |
|---|------------------------------|
| 9.5 Delete all.....                           | 16                           |
| 9.6 Message capacity .....                    | 16                           |
| <b>10 Services .....</b>                      | <b>17</b>                    |
| 10.1 Internet.....                            | 17                           |
| 10.2 Facebook.....                            | Error! Bookmark not defined. |
| 10.3 Yahoo .....                              | Error! Bookmark not defined. |
| 10.4 SIM tool kit.....                        | 17                           |
| <b>11 Settings .....</b>                      | <b>17</b>                    |
| <b>12 Games .....</b>                         | <b>17</b>                    |
| <b>13 Health and Safety Precautions .....</b> | <b>18</b>                    |
| <b>14 Taking Care of Your Device.....</b>     | <b>20</b>                    |

# 1 Know Your Phone

## 1.1 Keys and Parts

Important keys and parts are listed here for you to use the phone better.



1. Speaker

4. Right key

7. Navigation key

10. Camera

12. USB socket

2. Screen

5. Dial key

8. OK key

11. Earphone Jack

13. Receiver


3. Left key

6. End key

9. Keypad


---

## 1.2 Insert SIM Card



1. Insert the SIM card correctly in the SIM slot(s).
2. Finally, insert the battery and replace the rear cover of the mobile phone.

## 1.3 Insert Memory Card



1. Switch off the phone and remove the rear cover and the battery.
2. Insert the memory card into the slot.
3. Finally, insert the battery and the rear cover of the mobile phone.

Note: Use only compatible memory cards approved by Spark 266. Incompatible cards may damage the slot or corrupt the data stored in the card.

## 2 Basic Operations

### 2.1 Switch Phone ON/OFF

To switch ON/OFF your phone, press and hold the **End key** for a few seconds.

---

## 2.2 Unlock the phone

If you do not use the phone for a while, the screen is replaced with a locked screen.

1. Press any key to activate the screen.
2. Press **Left** key, and then press Right key.

## 2.3 Make a call

You can make a call in the following ways:

- Enter the desired number in standby mode and press the **Call key** to make the call.
- Go to **Menu > Contacts** and then select and dial the desired number.
- Just press the **Call key** to dial the contacts listed in Call History.
- You can also dial a contact from the messages.

## 2.4 Choose User Profiles

### Menu > Profiles

You can choose your profile such as Silent mode, Normal, Meeting, Outdoor, earphone and so on.

# 3 Notable Features

## 3.1 Secure your Phone

Menu > Settings > Security > Phone Locked

---

Let you lock/unlock your phone via a security password which you can change anytime.

The default security code to unlock the phone is **4321**.

Note: After you activate the phone lock, you would be asked for a password when you power on your phone next time.

### **3.2 Blacklist and Whitelist**

#### **Menu > Settings > Call settings > Blacklist**

Blacklist undesired SMS senders and caller so that you do not receive SMS and calling from them.

#### **Menu > Settings > Call settings > Whitelist**

When you check the Whitelist settings, that only the list in the Whitelist can call and send messages.

### **3.3 Manage Your Files**

#### **Menu >Gallery**

You can view and manage your files available in the phone or memory card from the gallery. You can rename, view details, move, delete files and so on via the File manager.

### **3.4 Applications**

#### **Menu > Applications**

Your phone provides you with the capability to organize your routines, tasks and much more with the following:

- **Calendar:** Lets you view the calendar and schedule tasks on selected dates.
- **Torch:** You can turn on/off the Flashlight in this



---

menu.

- **Clock:** Include World Clock, Alarm, Stopwatch, Timer.
- **Calculator:** Use the calculator.
- **E-book:** You can read the E-Book in the memory card by this function.
- **Unit Conversion:** Use the currency converter.
- **Answer machine:** Do not have time to answer the phone, can help you recording.
- **Bluetooth:** Use Bluetooth to exchange information with other Bluetooth devices. Select Bluetooth to have a host of options for scanning for and using Bluetooth feature.

### 3.5 Connect to Internet

#### Menu > Settings>Connections

You can connect to the Internet via GPRS connection.

To identify network data automatically based on your SIM card.

## 4 Call Logs

### 4.1 View Call History

#### Menu > Call Logs

Tip: Directly access the call logs of by pressing the **Call** key in idle mode.

The Call log lists the calls you have recently dialed, received, missed for SIM1 and SIM 2.

Press the Left/Right navigation keys to access various

---

call logs and work on the call logs.

## 5 Lava Space

### 5.1 Lava Space

#### Menu > Lava Space

Your device is supported Lava Space included Naughty Jokes, Cricket Alerts, Breaking News, Mehfill-Time Pass, Daal me Kaala, Friends Chat.

## 6 Phonebook Features

Your phonebook stores all your saved contacts for anytime use. Your phonebook data can be stored in your SIM card or your phone memory. You can manage your contacts from here.

#### Menu > Contacts

### 6.1 Add New Contact

#### Menu > Contacts > Left Key > New

### 6.2 Send SMS

#### Menu > Contacts > Left Key > Write message > SMS/MMS

### 6.3 Call a Contact

#### Menu > Contacts > Left Key > Call > Voice call

Allow you to make a call to the contact you are viewing. Or you can just highlight a number and press the **Call** key.

---

## 6.4 Delete Contacts

**Menu > Contacts > Left Key> Delete**

In the Contacts list, select the entry you want to delete.

## 6.5 Delete multiple contacts

**Menu > Contacts > Left Key> Delete multiple**

In the Contacts list, select the entry you want to delete.

## 6.6 Delete Phone contacts

**Menu > Contacts > Left Key> Delete from Phone**

In the Contacts list, select the entry you want to delete in phone.

## 6.7 Delete SIM1 contacts

**Menu > Contacts > Left Key> Delete from SIM1**

In the Contacts list, select the entry you want to delete in SIM1.

## 6.8 Delete SIM2 contacts

**Menu > Contacts > Left Key> Delete from SIM2**

In the Contacts list, select the entry you want to delete in SIM2.

## 6.9 Move contacts

**Menu > Contacts > Left Key> Move**

In the Contacts list, select the entry you want to move to SIM or phone.

---

## 6.10 Add to blacklist

**Menu > Contacts > Left Key > Add to blacklist**

Allow you to black list selected numbers. In this case the contact will be blocked from calling you up.

## 6.11 Import/Export Contacts

**Menu > Contacts > Left Key > Import/Export/Copy**

You can Import, Export or Copy contacts entries stored in the SIM card to the phone memory and vice-versa.

## 6.12 Send vCard

**Menu > Contacts > Left Key > Send vCard**

Allow you to send vCard to other numbers and export vCard.

## 6.13 Others

**Speed dial**

**Menu > Contacts > Left Key >Others> Speed dial**

Set speed dial and view memory status.

**Owner number**

**Menu > Contacts > Left Key >Others> Own number**

Set names of your own number.

**Memory status**

**Menu > Contacts > Left Key >Others> Memory status**

Check the memory status of SIM, and Phone.

---

## 6.14 Most used

**Menu > Contacts > Right Key > Most used**

View the contacts that most used.

## 6.15 Groups

**Menu > Contacts > Right Key > Groups**

Press the Left/Right navigation key to access the Group tab. Set up a list of numbers with similar preferences such as ringtone, profile etc.

# 7 Lava Zone

## 7.1 Lava Zone

**Menu > Lava Space**

Your device supports Lava Zone.

# 8 Multimedia

## 8.1 Camera

**Menu > Multimedia > Camera**

Press the left key in camera mode to choose various settings

Shortcut keys: Press the number keys on the phone's keypad to choose various settings.

## 8.2 Camcorder

**Menu > Multimedia > Camcorder**

---

Press the **OK** Key to start recording.

- You can press **Options** switch to **Camera** and vice versa.
- You can also press **Options** key to choose memory
- Press Left key to choose various settings

Shortcut keys: Press the number keys as shortcuts on the phone's keypad to choose various video settings.

### 8.3 Audio Player

#### Menu > Multimedia > Audio Player

The phone comes with an inbuilt audio player that plays all your favorite songs stored in the phone memory or memory card.

- While in music mode, press the Left key to choose various music options
- **Adjust Volume:** Press Up (\*) and Down (#) keys to adjust volume.

### 8.4 Video Player

#### Menu > Multimedia > Video Player

Let you play videos stored in your phone or memory card.

Press 2 key while playing a video to change the display mode.

### 8.5 Recorder

#### Menu > Multimedia > Recorder

---

You can record surrounding sounds using this feature.

## 8.6 FM Radio

### Menu > Multimedia > FM Radio

Your phone comes with an FM radio to let you listen to FM channels.

- Go to Options> Search Channels> Auto Search to fill up the channels.
- Press the number keys on your keypad in accordance to the channel list.
- Press OK key to start/stop the radio.
- Press the Up (\*) or Down (#) key to increase/decrease the volume.
- Press the Left key for various radio options.

## 8.7 My Images

### Menu > Multimedia > My Images

Let you to view your saved images. You can also send the images via MMS or Bluetooth or use it as contact icon or wallpaper, etc.

# 9 Messages

## 9.1 Write message

### Menu > Messages > Write message > New SMS/New MMS

You can compose and send SMS/MMS. Pressing the **Left Key** during/after composing the message gives you

---

a host of messaging features.

## **9.2 Use message Templates**

### **Menu > Messages > Templates**

Enter into preset message templates and use them. These preset templates can save you time if the theme of your message is the same as those existing in the template.

## **9.3 Voice mail server**

### **Menu > Messages > Voice mail server**

*You can activate voicemail service to redirect your incoming calls (based on your call settings) to a voicemail server and retrieve them later via SMS alerts.*

*To divert incoming calls to a voicemail server, go to Settings>Phone tab > Call Divert> Voice> (choose the desired call divert condition)> Activate> Phone Number/Voicemail Number.*

## **9.4 Settings**

### **Menu > Messages > Options>Settings**

You can set your desired parameters for SMS/MMS and push message.

## **9.5 Delete all**

You can choose all messages in boxes or others to delete.

## **9.6 Message capacity**

### **Menu > Messages >Options> Message capacity**

View the memory status of your SMS/MMS/Phone.



---

## 10 Services

### 10.1 Internet

#### **Menu > Services> Internet**

To access this menu, enter the Main Menu in the standby mode and then select Internet. You can use the network-related services with this function.

### 10.2 SIM tool kit

#### **Menu > Services> SIM tool kit**

It offers some extra function depend on your SIM cards.

## 11 Settings

Choose various preferences to customize your handset according to your requirements. You can set:

- Phone Settings include Restore factory setting
- Display
- Security
- Call settings
- Connections
- Dual-SIM

## 12 Games

### 12.1 Games

#### **Menu > Games**

Your device is supported Sokoban, Snake Tetris and

---

Java App to take your free time.

## 13 Health and Safety Precautions

Please read these simple guidelines. Not following them may be dangerous or illegal.

### SAR Compliance

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories or other accessories.
- The highest SAR value of the device at the head is 0.721 W/kg and body is 0.832 W/kg respectively averaged over 1 gm of human tissue.

### SAR Recommendations

- Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women
- Prefer to use your cell phone when the signal quality is good.

- 
- People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.
  - Maintain a preferable distance of 15 mm from the device.

### **Safe Driving**

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

### **During Flight**

- Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

### **In Hospitals**

- Your Phone's radio waves may interfere with the functioning of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.
- To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter defibrillator:
- Always keep your phone at least 15.3 centimeters (6 inches) from the medical device.

- 
- Do not carry the wireless device in a breast pocket.
  - Turn off the phone if there is any reason to suspect that interference is taking place.
  - Follow the manufacturer directions for the implanted medical device.
  - If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

### **Unsafe Areas**

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

## **14 Taking Care of Your Device**

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery without turning on the device, wipe it with a dry cloth and take it the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be

---

damaged.

- Do not attempt to open the device other than as instructed in this guide. Repairing this phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.

#### **Battery Recommendations:**

- Please put the battery in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the battery at room temperature range.
- Batteries have life cycles. If the time that the battery powers equipment becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.
- Use manufacturer approved batteries, chargers, accessories and supplies. Spark 266 will not be held responsible for user's safety when using unapproved accessories or supplies.

---

## Recycle Your Handset



The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed off or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling. of such hazardous waste.

Specified collection points for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipments at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment.

## Disclaimers

1. The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
2. Spark 266 keeps the right to make modifications to any of the content in this user guide without public announcement in advance. The content of this

---

manual may vary from the actual content displayed in the mobile phone. In such a case, the latter shall govern.

3.

### **Copyrights**

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Spark 266 is strictly prohibited.

## **LAVA WARRANTY CERTIFICATE**

### **Limited warranty:**

LAVA international Ltd. (LAVA) provides limited warranty for your mobile phone and original accessories delivered with your mobile phone (hereinafter referred to as "product")

The warranty period for the transceiver is one (1) year and for battery, charger and headset is six (6) months from the date of purchase.

### **LAVA Warranty**

Subject to the conditions of this Limited Warranty, LAVA warrants a product to be free from defects in design, material and workmanship at the time of its original purchase by you, and for a subsequent period of one (1) year for transceiver and six (6) months for battery & charger.

---

You shall have to coverage or benefits under this warranty in the event that any of the following conditions are applicable:

- The product has been subjected to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive temperature, unauthorized modification, unauthorized repair (including but not limited to use of unauthorized spare parts in repairs), abuse, accidents, Acts of God, spills of food or liquids, improper installation
- You have not notified Lava of the defect in the product during the applicable warranty period.
- The product serial no. code or the accessories date code has been removed, defaced or altered.
- The product has been used with or connected to an accessory (i) Not supplied by Lava or its affiliates, (ii) Not fit for use with the product or (iii) Used otherwise than in manner intended.
- The seals of the product's battery enclosure have been broken or shown evidence of tempering or the product's battery has been used in equipment other than that for which it has been specified usable by LAVA.
  - All plastic surfaces and all other externally exposed part that is scratched or damaged due to normal use.

To get maximum of your new product, we recommend you to:



- 
- Read the guidelines for safe and efficient use as mentioned in the manual.
  - Read the terms and conditions of your Lava warranty in the manual.
  - Keep your original receipt; you will need it for warranty services if asked to produce.
  - Present this Lava Warranty Certificate along with original proof of purchase whenever you require any warranty services.

In case Lava product needs service, please visit the nearest Lava service centers given in the service guide. Please visit our Website [www.lavamobiles.com](http://www.lavamobiles.com) for updated list of Authorized Service Centers near to your location.

Important note: for your warranty to be valid, all information on the warranty certificate has to be completed including the stamp from the authorized distributor/retailer.

All warranty information, product features and specifications are subject to change without notice.

IMEI No. ....  
Dealers Stamp .....  
Date of purchase .....  
Model No. ....