

Quick Start Guide

For more information about how to use the phone, please go to www.alcatelone-touch.com to download complete user manual (English version only). Moreover, from the website you can also consult FAQ (English version only).

SAR
www.sar-tick.com

This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 22 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

Warning: Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

Your mobile.....



1.1 Keys

- Navigation key
Confirm an option (press the middle of the key)
Activate music player (long press the middle of key)
Scroll widget bar (press the right or left of the key)
- Pick up
Send a call
In idle screen:
Access call log (Redial) (short keypress)
Activate fake call (long keypress)
During MP3 Playing:
Switch between Headset and speaker (long keypress)
- Switch on/Switch off the telephone (long keypress)
End call
Return to idle screen
- Left softkey
- Right softkey
- Access your voicemail (long keypress)
- In Edit mode:
- Short keypress: access the language list
- Long keypress: enter zero

- In Edit mode:
- Short keypress: change input methods
- Long keypress: access the Symbols table
- In idle screen:
- Short keypress: #
- Long keypress: activate/deactivate the vibrate mode
In Edit mode:
- Short keypress: (space)

Camera key: access "Camera" (short keypress)

1.2 Main screen icons ⁽¹⁾

In one touch 506:

- Battery charge level
- Vibrate alert: your phone vibrates, but does not ring or beep.
- Bluetooth status (Activated).
- Bluetooth status (Connected to an audio device).
- Headset connected.
- Keypad locked.
- Call forwarding activated: your calls are forwarded.

⁽¹⁾ The icons and illustrations in this guide are provided for information purposes only.

- Alarm or appointments programmed.
- Level of network reception.
- Voicemail message arrived.
- Missed calls.
- Radio is on.
- WAP alerts ⁽¹⁾.
- Roaming.
- SIM card missing.
- GPRS connection status (Activated).
- GPRS connecting.
- Sending a MMS.
- MMS receiving.
- Silence mode: your phone does not ring, beep or vibrate with the exception of the alarm.
- SMS unread.
- MMS unread.
- Flight mode.

⁽¹⁾ Depending on your network operator.

ALCATELone touch.

3 Calls.....

3.1 Making a call

Dial the desired number then press the key to place the call. For dual SIM model, you can select either SIM1 or SIM2 when you wish to place a call ⁽¹⁾. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the key.

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Calling your voicemail ⁽²⁾

To access your voicemail, hold down the key.

3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

3.4 Available functions during the call

During a call, you can use your directory, your calendar, short messages, etc. without losing your correspondent.

4 Contacts.....

4.1 Consulting your contacts

To access the **contacts** from the main screen, press the key and select the icon from the menu.

For dual SIM model, the complete contacts of both SIM1 and SIM2 are available in this menu ⁽¹⁾.

4.2 Adding a contact

Select the directory in which you wish to add contact, press the **"Options"** softkey, select **"Add contact"**.

5 Messaging.....

5.1 Create message

From the main menu select **"Messaging"** to create text/multimedia message. For dual SIM model, you can type a message and select to send it to a recipient in either the SIM1 or SIM2 directory ⁽¹⁾. You can type a message and you can also modify a predefined message in **Templates** or customise your message by adding pictures, photos, sounds, titles, etc (only available while editing a MMS). While writing a message, select **"Options"** to access all the messaging options. You can save your messages that you send often to **Draft** or **Templates** (MMS only).

Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

6 Email.....

Your phone has an email client with the settings predefined for a few popular email services like – GoogleMail, Windows live, Yahoo, AOL, etc. Besides this, you can set up other POP3 or IMAP4 email accounts that you may be using.

7 Opera Mini.....

Not only does Opera Mini give you the full Web experience where you stay in touch with your friends, obtain information, do your online banking etc., but it is also designed to save time by using compressed web pages.

8 Facebook.....

Facebook is a social utility that connects people with friends and others who work, study and live around them. It provides a number of features with which users interact, such as Wall, Pokes, etc.

To open an account online, please go to: <http://www.facebook.com/>.

9 mTweet.....

Twitter is a social networking and microblogging service that has gained notability and popularity worldwide. This feature enables phone users to exchange news updates and ideas with a community in the form of messages or posts. Posts are displayed on the author's profile page and delivered to the author's subscribers or followers.

To open an account online, please go to: <http://twitter.com/>.

10 Camera.....

Your mobile phone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them in your **"File manager/My creations"**.
- send them in a multimedia message (MMS) to a mobile phone or an email address.
- send them directly by Email or Bluetooth.
- customise your main screen.
- select them as incoming call image to a contact in your directory.

To open an account online, please go to: <http://www.facebook.com/>.

11 Media.....

11.1 Music
Access this feature from the main menu by selecting **"Music"**. You will have full flexibility of managing music both on your mobile and memory card.

11.2 Video

"My videos" album contains video clips recorded, received or downloaded.

11.3 Radio

Your phone is equipped with a radio ⁽¹⁾ with RDS functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

12 My friends.....

It migrates self-contained sub-trees of the websites to let you stay in touch with your friends by flicking through Friendster, Hi5, etc.

13 Settings.....

From the main menu, select the menu icon and select the function of your choice in order to customise your telephone: **Phone settings, Call settings, Security, Network, Connectivity.**

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

- In one touch 506D:**
- Call forwarding activated: your calls are forwarded.
 - Level of network reception.
 - Voicemail message arrived.
 - GPRS connection status (Activated).
 - GPRS connecting.

Dual SIM settings ⁽¹⁾

- **Dual SIM activated** Keep both of your SIM cards active.
- **Only SIM1 activated** Only keep SIM1 active.
- **Only SIM2 activated** Only keep SIM2 active.

14 Call log.....

You can access your call memory by pressing from the idle screen, and you will see Outgoing call(s), Missed call(s) and Answered call(s).

15 Tools.....

15.1 Calendar

Once you enter this menu from the main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

15.2 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

⁽¹⁾ one touch 506D only.

2 Getting started.....

2.1 Set-up

Removing and installing the back cover



Removing and installing the battery



Inserting and removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out. one touch 506D, two SIM cards can be inserted.

Charging the battery



Connect the battery charger to your phone and mains socket respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Bluetooth when not in use; reduce the backlight time, etc.

The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the main screen.

Inserting the memory card:



To release the microSD card holder, slide it in the direction of the arrow and lift it. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder and slide it in the opposite direction to lock it.

15.7 World clock

The World clock shows current local time and the time zone in different cities.

15.8 Converter

Unit converter and Currency converter.

15.9 Stopwatch

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement.

16 Java.....

Your Alcatel phone may include ⁽¹⁾ some Java™ applications and games. You can also download new applications and games to your phone.

⁽¹⁾ Depending on your network operator.

⁽¹⁾ one touch 506D only.

⁽²⁾ Contact your network operator to check service availability.
English - CJB22B0ALAAA

⁽¹⁾ one touch 506D only.

