

FOLDABLE LIGHT
Quintezz® LED

User's Manual

GB

NL

FR

D



ILLUSTRATION 1




ILLUSTRATION 2



PACKAGE CONTENTS

The Foldable LED light packaging includes:

- Foldable LED Light
- USB charging cable
- Mount with 3M VHB tape

PARTS

See illustration I

CHARGING

See illustration II

Connect one end of the USB charging cable to the lamp's power port. Plug the other side of the cable into your computer's USB port, a USB adapter (f.e. smartphone), portable power charger, etc.

Note:

- Charging time when using USB cable + PC/laptop is up to 20 hours. Charging time using USB cable + USB travel charger (not included, optionally available at www.quintezz.com) is 8~10 hours.
- When charging, the red LED indicator will light up. When the battery is fully charged the LED indicator will turn off.

OPERATIONTurning the lamp ON/OFF

Press the ON/OFF button (1):

- 1x to turn the lamp ON. First level of brightness is shown.
- 2x to activate the 2nd brightness level (DIM).
- 3x to turn the lamp OFF.



Setting the date and time

1. Press the SET button (3) in normal mode. The "Hour" digit will flash. Press the UP (4) or DOWN (5) button to adjust, and press SET (3) to confirm.
2. The "Minute" digit will flash. Repeat the same procedure to complete the time & date setting: Hour-minute-year-month-day. The day of the week will be set automatically.
3. During the setting mode, press the MODE button (2) to return to normal time display.
4. If no buttons are pressed for 60 seconds, the clock will return to normal time display.
5. Press the UP button (4) in normal mode to switch between 12 hour and 24 hour time format.

Temperature

Press the DOWN button (5) in normal mode to switch between Celsius and Fahrenheit for the temperature setting.

Alarm & Snooze function

1. In normal mode, press MODE (2) to enter the alarm mode. The alarm icon  will be shown in the display.
2. Press the SET button (3) to enter alarm setting. Follow the same procedure to set the alarm time as described above for the time settings.
3. After you have set the "Minutes", the "Snooze" digit will flash. Set the desired snooze time in minutes (01=1 min., 02=2 min. etc.), and press SET (3).
4. The alarm sound options (1-8) will flash. Choose an alarm sound and press SET (3) to confirm.
5. In ALARM mode, press the UP (4) or DOWN (5) button to turn the alarm and snooze functions On or Off.
 - Press UP or DOWN 1x to activate the alarm. The  icon will be shown.
 - Press UP or DOWN again to turn the snooze function on. The **Zz** icon will be shown.
6. Press MODE (2) to return to the normal time mode. If the alarm and snooze functions are both on, the display will show both icons.

When the alarm time is reached the alarm will sound.

- ➔ Press MODE (2) or DOWN (5) button to activate the snooze and the **Zz** icon will start flashing. The alarm will ring again at the snooze interval. The snooze function will only work 3 times before shutting off.
- ➔ Press the SET (3) or UP (4) button to stop the (snooze) alarm completely.

Note:

The alarm will last for 1 minute and then stop automatically if no button is pressed.

To deactivate the alarm, press the MODE button (2) to enter alarm setting mode, and press the UP or DOWN button until the alarm/snooze icons disappear.

Note: If the alarm is not deactivated, it will be automatically set as an alarm at the same time the next day.

SAFETY INSTRUCTIONS

- Never touch the plug contacts with sharp or metal objects.
- Use only the original power supply and original accessories.
- Never place the device in the vicinity of heat sources.
- Never place the unit on surfaces that are heat sensitive.
- Protect the device from special liquids and vapors.
- Do not use any solvent based cleaning agents, only a soft, dry anti-static cloth.
- Do not attempt repairs yourself.
- If the unit is not properly installed or operated Quintezz® cannot accept liability.

SUPPORT

For more information, technical questions and return requests concerning this product, you should contact: support@quintezz.com.

GUARANTEE

Copyright © Quintezz®. Quintezz® is a registered trademark of TE-Group NV. The Quintezz® brand stands for superior product quality and outstanding customer service. That is why Quintezz® warrants this product against all defects in material and workmanship for a period of **two (2) years** from the date of original purchase of the product. The terms of this guarantee and the extent of responsibility of Quintezz® under this warranty can be downloaded from the website: www.quintezz.com