


August International Ltd
United Kingdom
Tel: +44 (0)845 250 0586
www.augustint.com



AUGUST®

User Manual

SE30



- EN** Portable Bluetooth Speaker System
- FR** Enceinte Bluetooth
- DE** Bluetooth Lautsprecher
- IT** Altoparlante Bluetooth
- ES** Altavoz Portátil Bluetooth

User Manual

Thank you for purchasing the August SE30 Portable Bluetooth Speaker System. This user manual is designed to familiarize you with all the features of this device. Please take the time to read this user manual carefully, even if you are already familiar with a similar product.

Safety

To ensure the safety of you and others, please read the Safety Instructions before using this device. Please do not disassemble the SE30, it can be unsafe and will invalidate the manufacturer's warranty.

Disposal







Please ensure the product and accessories are disposed of in compliance with the WEEE (Waste Electrical and Electronic Equipment) Directive and any other regulations applicable to your country. Always check with the environment agency and any other relevant authorities for current disposal regulations.

Customer Service:

You can contact us by phone on:
+44 (0)845 250 0586
or by email at: service@augustint.com
should you require further technical support or customer service.



1. Safety Instructions

■ Storage and Use

	Keep this device away from extreme temperatures.		Keep the device away from wet or damp environment.
	Never expose the device to moisture, dust, oil or smoke.		Avoid dropping or exposing to impacts.
	When carrying this device as part of your luggage please ensure it is securely stored to avoid impact damage		Never strike or scratch this device with any sharp object.

■ Maintenance

Please unplug all leads before cleaning this device.

	Wipe the device and buttons with a soft cloth.		Never wipe this device with an abrasive cloth or apply detergent, alcohol or chemical based cleaning products.
---	--	---	--

2. Main Features

- 1) Play Music Wirelessly from Bluetooth Devices
- 2) Standard 3.5mm Audio-In Socket


3. Accessories

- 1) USB charging cable
- 2) 3.5mm audio cable
- 3) User manual




4. Part Names and Functions

Top:



1. Previous track (short press) / Volume down (press and hold)
2. Play / Pause
3. Next track (short press) / Volume up (press and hold)

Right side:



4. Power switch
5. Power socket
6. Audio-in socket

5. Operations

5.1 Switch On / Off

The power switch is on the right hand side of the SE30, slide it back towards the power socket to turn the device on. To turn the SE30 off, slide the power switch forward again.

5.2 Bluetooth Connection

After switching on the SE30, the device will enter Bluetooth mode and prepare for pairing automatically. Whilst in pairing mode the status LED flashes blue quickly..

Note:

The SE30 will automatically reconnect to the last paired Bluetooth device if it is in range. To pair the SE30 with another device, please disconnect the current Bluetooth connection first.

-For mobile phones

- 1) Scan for available Bluetooth devices on your mobile phone (see your mobile phone user manual for instructions if needed).
- 2) Select "SE30" from the available devices.
- 3) Once successfully paired and connected, the status LED will slowly flash blue.

-For computers

- 1) Enable Bluetooth on your PC.
- 2) Select "Devices and Printers" from the Control Panel and click "Add a Device".
- 3) Select "SE30" from the available devices to install drivers.

Note: For Windows XP and Vista, a third-party Bluetooth driver is needed (not included).

- 4) If the SE30 is not automatically set as your output device, select "Sound" from the control panel then highlight the SE30 and select "Set Default".

5.3 Music Control

The SE30 is able to control music playing on either a mobile phone or a computer through a Bluetooth connection.

Tap the "◀◀" or "▶▶" buttons to select the previous or next track, or press and hold them to adjust the volume and press "⏸" to pause or resume playback.

Note: Music control is only compatible with devices that support A2DP, please refer to your mobile phone user manual for the A2DP compatibility of your phone.

5.4 Audio-In

To use the SE30 as a wired speaker, use a 3.5mm audio cable to connect the SE30 with your source device. Once the audio cable is connected to the SE30, the device automatically switches to Audio-in mode.

6. Charging

To charge the SE30, connect the micro USB lead to the device's power socket, and the other end of the USB cable to a powered USB port.

The LED lights red whilst charging and turns off once the battery is fully charged.

7. Specifications

Speaker	2 x 3W
Frequency Response	150Hz-20KHz
SNR	70 ± 6dB
Distortion	<0.5%
Power Input	DC 5V 500mA
Built-in Battery	3.7V 800mAh Li-ion Battery
Charging Time	About 2 hours
Working Time	Up to 9.5 hours
Working Distance	Up to 10m (Class II)
Dimensions	150x58x39mm
Weight	225g

8. Troubleshooting

Problem	Solution
Won't turn on.	Please charge the SE30
Can't find the SE30.	Confirm the SE30 is in pairing mode and within 10 meters from the device.
No sound.	Check the volume on both the source device and the SE30.

9. Warranty

This product is guaranteed for twelve months from the date of the original purchase. In the unlikely event of any defect arising due to faulty materials or workmanship, the unit will be either replaced or repaired free of charge (where possible) during this period. An alternative product will be offered in case the product is no longer available or repairable.

This warranty is subject to the following conditions:

- The warranty is only valid within the country where the product is purchased.
- The product must be correctly installed and operated in accordance to the instructions given in this user manual.
- The product must be used solely for domestic purposes.
- The warranty only covers the main unit, and does not cover the accessories.
- The warranty does not cover the damage caused by misuse, negligence, accident and natural disaster.
- The warranty will be rendered invalid if the product is resold or has been damaged by inexpert repairs. The manufactures disclaim any liability for incidental or consequential damages.
- Please consult our customer adviser before returning any product; we are not responsible for any unexpected product returns.
- Any faulty product must be kept and returned in the original packaging with all the accessories and the original copy of the purchase receipt.

The warranty is in addition to, and does not diminish, your statutory or legal rights.

Customer Service:

Telephone: +44 (0) 845 250 0586

Email: service@augustint.com

This product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at August International Ltd, Unit 5 Swains Mill, Crane Mead, Ware SG12 9PY, England.



Industry Canada Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

No Unauthorized Modifications: Do not make any changes or modifications to this product without the prior express written approval of August International Ltd. Any changes or modifications made without express written approval could void the user's authority to operate this product.



For details of further relevant technical standards, please contact us at the address above.