

ZTE Kis3 max
Mobile Phone
Quick Start Guide

LEGAL INFORMATION

Copyright © 2014 ZTE CORPORATION.


All rights reserved.

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this guide without prior notice.

Trademarks

ZTE and the ZTE logos are trademarks of the ZTE Corporation. Google and Android are trademarks of Google, Inc. The *Bluetooth*[®] trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by ZTE Corporation is under license.

 microSDHC Logo is a trademark of SD-3C, LLC.

Other trademarks and trade names are the property of their respective owners.

We offer self-service for our smart terminal device users. Please visit the ZTE official website (at www.ztedevice.com) for more information on self-service and supported product models. Information on the website takes precedence.

Visit <http://www.ztedevice.com> to download the user manual. Just click **Support > Manuals** from the home page and then select your location, product type, and name to search for related support information.














Disclaimer






ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software.

Version No. : R1.0


Edition Time : 2014.08


Product Safety Information

	Do not use hand-held while driving
	Do not use while re-fuelling
	For body-worn operation maintain a separation of 15 mm
	This device may produce a bright or flashing light
	Small parts may cause a choking hazard
	Do not dispose of it in a fire
	This device may produce a loud sound
	To prevent possible hearing damage, do not listen at high volume levels for long periods.
	Avoid contact with magnetic media
	Avoid Extreme Temperatures
	Keep away from pacemakers and other personal medical devices
	Avoid any contact with liquid, keep it dry
	Switch off when instructed in hospitals and medical facilities

	Do not attempt to disassemble
	Switch off when instructed in aircrafts and airports
	Only use approved accessories
	Switch off in explosive environments
	Do not rely on this device for emergency communications

Getting to Know Your Phone





Power Key

- Hold to turn on or off Silent or vibrate or Airplane mode, or to power off or Reboot Device.
- Press to switch your phone to Sleep mode. Press to wake up your phone.

Home Key

- Press to return to the Home Screen from any application or screen.
- Hold to see Google search.

Menu Key

- Press to get the options for the current screen.
- Hold to see recently used applications.

Back Key


- Press to go to the previous screen.

Volume Up/Volume Down


- Press or hold to turn the volume up or down.

Starting Up

Removing the Back Cover




Installing the SIM Card



Notes:


- SIM card 1 (the figure to the left of the main card) support WCDMA and GSM networks; SIM card 2 only supports GSM networks
- If you're using a small card, please use the SIM card Dedicated card sets, and then the whole into the slot Normal use.
- please buy standardization SIM dedicated card sets from the formal channels, otherwise the slot shrapnel may be pulled off when taking cards

Installing the microSD Card



Notes: Some applications may require a microSD card to work normally or may store certain data on it. Therefore, it is recommended that you keep a microSD card installed and not remove or replace it randomly.

Charging the Battery



When you first get your new phone you'll need to charge the battery like this:

1. Connect the adapter to the charging jack.
2. Connect the charger to a standard AC power outlet.
3. Disconnect the charger when the battery is fully charged.

Notes: If excessive discharge of the battery, the charging icon will display delay


CAUTION: Do not change the built-in rechargeable battery in your phone by yourself. The battery can only be changed by ZTE or ZTE authorised service provider.

Powering On/Off Your Phone

Make sure the battery is charged before powering on.

- Press and hold the **Power Key** to turn on your phone.
- To turn it off, press and hold the **Power Key** to open the options menu. Touch **Power off** > **OK**.

Waking Up Your Phone

1. Press the **Power Key** to activate your screen display.
2. Touch and hold  at the center of the screen.

NOTE:

If you have set an 'unlock pattern', or a PIN/ password for your phone, you'll need to draw the pattern or enter the PIN/password to unlock your screen.

Using the Touch Screen

Your phone's touch screen lets you control actions through a variety of touch gestures.

- Touch

When you want to type using the onscreen keyboard, select items onscreen such as application and settings icons, or press onscreen buttons, simply touch them with your finger.

- Touch and Hold

To open the available options for an item (for example, a message or link in a Web page), touch and hold the item.

- Drag

To drag, press and hold your finger with some pressure before you start to move your finger. While dragging, do not release your finger until you have reached the target position.

- Pinch

In some apps (such as Maps, Browser, and Gallery), you can zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in).

- Rotate the screen

For most screens, you can automatically change the screen orientation from portrait to landscape by turning the phone sideways.