


DRC6272E22

EN

ES

FR



Scan for more user manual details or visit www.RCAav.com

Consulte para obtener más detalles del manual del usuario o visite www.RCAav.com

Scanner pour détails supplémentaires indiqués dans le manuel d'utilisation ou visiter www.RCAav.com

CAUTION
INVISIBLE LASER RADIATION
WHEN OPEN AND INTERLOCKS
DEFEATED.
AVOID EXPOSURE TO BEAM.

PRECAUCIÓN
RADIACIÓN LÁSER INVISIBLE EN
CASO DE APERTURAY DESBLOQUEO
DE CIERRE. EVITE CUALQUIER
EXPOSICIÓN AL RAYO

MISE EN GARDE
RADIATION LASER INVISIBLE, SI
L'APPAREIL EST OUVERT ET SI LE
DISPOSITIF DE VERROUILLAGE EST
NEUTRALISÉ. ÉVITER L'EXPOSITION
AU FAISCEAU LASER.

CLASS 1 LASER
PRODUCT
Producto láser
Clase 1
Appareil à laser
de classe 1



This product contains a low power
laser device.
Este producto contiene un dispositivo
láser de baja potencia.
Cet appareil contient un dispositif à
laser de faible puissance.

It is important to read this instruction book prior to using your new product for the first time.
Es importante que lea este libro de instrucciones antes de comenzar a usar su nuevo producto.
Il est important de lire ce manuel d'utilisation avant l'utilisation initiale de ce nouveau produit.

Safety Instructions



** SEE BOTTOM OF UNIT FOR GRAPHIC SYMBOLS **

EN

WARNING:

- Should any trouble occur, disconnect the car power adaptor and refer servicing to a qualified technician.
- TO PREVENT FIRE OR SHOCK HAZARD, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.
- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE. DO NOT PLACE OBJECTS FILLED WITH LIQUIDS ON OR NEAR THIS UNIT.
- TO BE COMPLETELY DISCONNECTED FROM THE POWER INPUT, THE UNIT'S CAR POWER ADAPTER SHOULD BE DISCONNECTED FROM THE VEHICLE. THE CAR POWER ADAPTER SHOULD NOT BE OBSTRUCTED AND SHOULD BE EASILY ACCESSIBLE DURING INTENDED USE.

CAUTION:

- Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

On Placement

- Do not use the unit in places that are extremely hot, cold, dusty or humid.
- Place the unit on a flat and even surface.
- Do not restrict the air flow of the unit by placing it in a place with poor air flow, by covering it with a cloth, or by placing it on carpeting.
- To avoid magnetizing, do not place the unit near speakers or magnets.
- Do not use this unit in direct sunlight or leave the unit in a closed automobile (or similar environments) where it would be exposed to high temperatures above 104°F (40°C).
- No naked flame sources such as lighted candles should be placed on the car power adaptor or the unit.
- The car power adaptor and apparatus should not be exposed to splashing or dripping liquids, and no objects filled with liquids, such



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

as vases, should be placed on the car power adaptor and apparatus.

- The apparatus should not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, should be placed on apparatus.

On Safety

- When connecting or disconnecting the car power adapter, grip the plug and not the cord itself. Pulling the cord may damage it and create a hazard.
- When you are not going to use the unit for a long period of time, disconnect the car power adapter.

On Remote Control



- The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Do not dispose of the battery in a fire or it may leak and or explode.
- Batteries should not be exposed to excessive heat such as sunshine, fire or the like.

On Condensation

- When left in a heated room where it is warm and damp, water droplets or condensation may form inside the unit. When there is condensation inside the unit, the unit may not function normally. Let the unit stand for 1 to 2 hours before turning the power on, or gradually heat the room and allow the unit to dry before use.

Ventilation Warning

- Do not block the ventilation openings or

holes. If the ventilation openings or holes are blocked by a newspaper or cloth, etc., the heat may not be able to get out.

- Do not operate the unit in a confined space, such as a bookcase or built-in cabinet. Allow about 4 inches (10cm) of free space all around the unit for adequate ventilation.

Rating Plate Location

- The rating plate is located on the bottom of unit.

Notes on Copyright

It is forbidden by law to copy, broadcast, show, broadcast on cable, play in public, or rent copyrighted material without permission.

This item incorporates copy protection technology that is protected by U.S. patents and other intellectual property rights of Rovi Corporation. Reverse engineering and disassembly are prohibited.

FCC Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-003(B)

Trademark Notice

Dolby Digital
Manufactured under license from Dolby Laboratories.

Dolby and the double-D symbol are trademarks of Dolby Laboratories.



IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type. A polarized power plug has two blades with one wider than the other. A grounding type power plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. When the provided power cord does not fit into your AC power outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the AC power cord from being walked on or pinched particularly at the power plug,

convenience receptacles, and the point where they exit from the apparatus.

11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as the AC power cord is damaged, liquid has spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.




**Portable Cart
Warning**




Control Reference Guide - Remote Control

EN



GREEN remote control




BLUE remote control

1	VIDEO MODE	Press to adjust brightness, contrast or screen size.
2	◀◀ (previous)	Press to go to the previous chapter or title on a DVD, or track on a CD.
3	SEARCH ◀◀ or ▶▶	Press to fast reverse or fast forward playback.
4	GOTO	Press to go directly to a location on a DVD or CD.
5	▼▲◀▶	Press to navigate the setup menus or to adjust settings. Press ▼ to turn volume down or press ▶ to turn volume up.
	ENTER	Press to confirm selections on the menu.
6	MEMORY	In playing mode, sets titles /chapters in a favorite order.
7	Number (0 - 9)	Press to save titles or chapters in a favorite order.
8	REPEAT A-B	Press to repeat a specific portion (from point A to point B) of a disc.
	REPEAT DISC	Press to repeat a DVD current title, chapter, a CD track, or entire discs of a CD.
	SETUP	In stop mode, press to bring up the Setup menu.
9	MENU	Press to enter and exit the main DVD menu. This option works only if the DVD has a main menu.
10	▶▶ (next)	Press to skip forward to the next chapter or title on a DVD, or track on a CD.
11	■ STOP	Press once to stop playback. Your player remembers where you stopped. If you press PLAY, your player starts playing at the point where you stopped. Press twice to stop playback. If you press PLAY, your player starts playing at the beginning of the disc.
	▶ PLAY	Press to start playback. When a disc is paused press to resume playback.
	▬ PAUSE	When a disc is playing, press to pause playback.
12	DISPLAY	Press to display information about the disc, such as title, chapter number, track number and time.
13	ANGLE	Press to switch between multiple camera angles, if available on the DVD.
14	AUDIO	Press to select the DVD audio language. This option works only if the DVD has multiple audio languages.
15	SUBTITLE	Press to turn subtitles on and off, or press to select the subtitle language. This option works only if the DVD has subtitles.
	RETURN	Press to return to normal operation after using the Setup menu of a DVD.



Control Reference Guide



EN

1	▲ OPEN	Press to open the disc door. Hold the front panel when open the disc door.
2	⏮ (previous)	Press to go to the previous chapter, title or track during the disc playback or to navigate left on a menu.
	⏭ (next)	Press to go to the next chapter, title or track during the disc playback or to navigate right on a menu.
	⏸ PLAY/PAUSE	Press to start or pause playback.
	■ STOP/ AV IN (in Unit A only)	Press to stop playback Press and hold for 3 seconds to change to AV IN or DVD mode.
	- / +	Press to adjust volume up and down.
3	Headphone Jack	Plug headphones into this jack. When headphones are plugged in, sound does not come out of your player's speakers.
4	STANDBY / ON switch	Slide to change your DVD player to standby mode or to turn it on.
5	To Unit A / To Unit B	Connect 2 units together via the connection cable.
6	DC IN Jack	Connect the car power adapter to this jack.
7	Remote Control sensor	Receives signals from the remote control. Do not block.

Accessories

The following accessories are included.


1. Remote control (with battery)x 2
2. Car power adapter with splitter.....x 1
3. Connection cable.....x 1
4. Mounting Straps.....x 2

Using the Remote Controls

Remote controls have different color keys to identify which unit they operate. The remote control with green keys operates Unit A which has a green stripe on the front of the unit.

The remote control with blue keys operates Unit B with a similar blue stripe on the front of the unit.


EN




Using your unit

1. Slide the **STANDBY / ON** switch on the side of the unit to "**ON**".
2. To watch same DVD on 2 DVD players, press the **DVD / AV IN** button on the GREEN remote control or press and hold the **STOP / AV IN** button for 3 seconds on the Unit A to select **AV IN** mode. "AV IN" will be shown on the screen of Unit A for a while.
3. To watch different DVDs on 2 DVD players, press the **DVD / AV IN** button on the GREEN remote control or press and hold the **STOP / AV IN** button for 3 seconds on the Unit A to select **DVD** mode.

On GREEN remote control



On Unit A





Note: Most DVDs and your player have region codes that help control illegal distribution of DVDs. The region code of your player is 1. You can only play DVDs with a region code of **1** or **ALL**. The region code for a DVD is printed on the DVD or the DVD packaging.

TIP: Press the STOP button once before turning off the car power or switching off the unit. This will allow you to resume DVD playback at the same place the next time the unit is turned on.


Using in a Vehicle

Connect the connection cable and car power adapter with splitter to both units, make sure to use correct remote for each unit (green rubber keys remote for green Unit (Unit A), blue rubber keys remote for blue Unit (Unit B) .)

Mounting Strap



Mount in the car headrest



SAFETY WARNING!

- This unit should never be used by the vehicle's driver or left unsecured in the vehicle while driving.
- If this unit is being used in your vehicle, be sure that it is secured or held safely, and does not obstruct any safety device, including air bags or seat belts.
- All passengers should wear seat belts when using this unit in a moving vehicle.
- If in doubt, please contact your vehicle manufacturer for further advice.

AVC MULTIMEDIA ("AVC") makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to non-commercial use of the product.

One Year Parts & Labor Warranty

AVC products purchased in the United States are warranted to be free from defects in materials or workmanship for a period of one year from the date of their original retail purchase. If the unit fails to conform to this warranty, we will service the product using new or refurbished parts and products, at AVC's sole discretion.

During a period of one year from the effective warranty date, AVC will provide, when needed, service labor to repair a manufacturing defect at its designated Service Center. To obtain warranty service in the United States, you must first call our **Customer Support Center at 1-800-506-5746 or 1-877-252-6873, during the hours listed in the box below.** The determination of service will be made by AVC Customer Support. **PLEASE DO NOT RETURN YOUR UNIT TO AVC WITHOUT PRIOR AUTHORIZATION.** New or remanufactured replacements for defective parts or products will be used for repairs by AVC at its designated Service Center for one year from the effective warranty date. Such replacement parts or products are warranted for an additional one year from the date of repair or replacement. The Customer will be required to ship the unit to the Service Center indicated at the time Customer Support is contacted to make the necessary repairs. The customer is responsible for all transportation charges to the service facility.

Packaging and Shipping Instruction

When you send the product to the AVC service facility you must use the original carton box and packing material or an equivalent as designated by AVC.

LIMITED WARRANTY

Your Responsibility

- (1) You must retain the original sale receipt to provide proof of purchase.
- (2) These warranties are effective only if the product is purchased and operated in the U.S.A. or Canada.
- (3) Warranties extend only to defects in material or workmanship, and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of AVC, or to products or parts thereof which have had the serial number removed or changed.

Out of Warranty

In the event your product requires repair after the limited warranty period has expired, please contact our Customer Support Center at **1-800-506-5746, 1-877-252-6873 or www.RCAav.com**

Hours: Monday–Thursday: 9am–7pm, Friday: 9am–5pm, Saturday: 9am–NOON Eastern time.

Important: You are responsible for any transportation, shipping or insurance relative to the return of product to our Product Returns Center.

All warranties implied by state law, including the implied warranties of merchantability and fitness for a particular purpose, are expressly limited to the duration of the limited warranties set forth above. With the exception of any warranties implied by state law as hereby limited, the foregoing warranty is exclusive and in lieu of all other warranties, guarantees, agreements and similar obligations of manufacturer or seller with respect to the repair or replacement of any parts. In no event shall AVC be liable for consequential or incidental damages.

No person, agent, distributor, dealer or company is authorized to change, modify or extend the terms of these warranties in any manner whatsoever. The time within action must be commenced to enforce any obligation of AVC arising under the warranty or under any statute, or law of the United States or any state thereof, is hereby limited to one year from the date of purchase. This limitation does not apply to implied warranties arising under state law.

This warranty gives you specific legal rights and you may also have other rights, which may vary, from state to state. Some states do not allow limitation on how long an implied warranty lasts, when an action may be brought, or the exclusion or limitation of incidental or consequential damages, so the above provisions may not apply to you.

For more information on other products and services, please visit our web site at **www.RCAav.com**.

Important: Also keep your "Bill of Sale" as proof of purchase.

Serial no..... Invoice no.....

Date purchased..... Dealer name.....

FOR SERVICE AND REPAIR, PLEASE VISIT **www.RCAav.com**

Specifications and external appearance are subject to change without notice.