


# User Manual Wilms® Forest Shower

## Assembly:

1. Wilms Forest Shower is simply installed between fittings and shower hose of your shower. Structural changes are not necessary.
2. However, in order to ensure comfortable operation, you should ascertain whether there is **enough space in your shower (see figure)** and a firm fit of the fittings. No liability is assumed for damages arising from insufficiently secured fittings.



3. Alignment of the housing is freely selectable. However, the lid should be opened to that side which offers most space.
4. For assembly, disconnect shower hose from fittings and screw on housing of forest shower. Gasket is enclosed.
5. Screw on shower hose with gasket at the lower end of the housing.
6. The cover, which is provided with the shower, can be mounted or removed by simply sliding it on or pulling it off.  
**Advice: Recessed grips provided at the back facilitate pulling off.**



Should you have any problems installing it, your plumber will be happy to assist you.

## How to operate it:

1. Pull off cover from housing in order to change pine heartwood packet.
2. Open lid by releasing clamping lever.  
**Advice: In order to facilitate pulling out the heartwood packet a grip edge has been provided.**



3. Please support the housing with your free hand when closing the lid and pushing down the clamping lever so as not to exert unnecessary pressure on the fittings.  
**Make sure that nothing is jammed.**
4. Remount the cover, please.  
**Do not operate the forest shower without cover.**
5. The forest shower is activated via the green lateral rotary knob. If it is in vertical position, the forest shower function is not active. You are having a normal shower.
6. If you turn the rotary knob into horizontal position, you activate the forest shower function.  
**Advice: If you turn the knob quickly, the water will initially become colder. Turning the knob slowly = less cold water.**
7. Even if the forest shower is not activated, small amounts of the heartwood ingredients can be given off to the water, provided a heartwood packet has been put in.
8. Remove the packet, if the shower is not used for a longer period of time.

## Maintenance:



In case the cover does not seal properly anymore, the upper side can be readjusted via the handle of the clamping lever and the lower side via its hinges. This has also an impact on the closing effort.

## Tips for using the forest shower:

- You will obtain maximum benefit from the natural, antibacterial and germ-reducing pine heartwood ingredients, when you activate the forest shower at the end of the normal showering for one minute using warm water. This is enough to give your skin optimal care. If these recommendations are followed, the heartwood packet is sufficient for about 30 – 40 showers.
- In the event of **colds** and suchlike, you can use the forest shower function for a longer period of time.
- You can find out, if the heartwood packet is leached out, when there is no pine scent when switching from normal water to forest shower function.
- Due to the installation of the forest shower, a little water will run after changing the settings (this is normal). So, when you change temperature or volume of water, wait for a moment, as the new state will arrive with a little delay.



## Disposal:

Used heartwood packets can be safely disposed of with normal domestic waste.

**We wish you lots of vitality and health with Wilms Forest Shower!**

