



106620

# 20" Box Fan with Thermostat User's Guide

For product service, call customer service at 877-207-0923.

Item Stock Number: 106620  
UPC: 681131066204


## Important Safety Instructions

This fan is for residential use only. It is not intended to be used in commercial or industrial settings.

### CAUTION:

Attach feet before operating. Do not operate with feet missing.


1. Break apart the two plastic feet as shown.
2. Slide feet into slots in bottom of fan until they snap into position.
3. Never insert fingers, pencils, or other foreign objects through the grill.
4. Disconnect fan when moving it from one location to another.
5. Be sure that the fan is on a stable surface when operating to avoid the chance of it overturning.
6. Do not use this fan in a window. Rain may cause an electrical fire.



### For Your Safety

The AC power plug is polarized (one blade is wider than the other) and only fits into AC power outlets one way. If the plug won't go into the outlet completely, turn the plug over and try to insert it the other way. If it still won't fit, contact a qualified electrician to change the outlet, or use a different one.

Do not attempt to bypass this safety feature.



THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF DANGEROUS VOLTAGE INSIDE THE PRODUCT.

**CAUTION**  
RISK OF ELECTRIC SHOCK  
DO NOT OPEN  
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE MOTOR COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.

### WARNING:

To prevent fire or electrical shock hazard, do not expose this product to rain or moisture.



## Operation

1. Be sure fan is in OFF position.
2. Plug fan into any standard 120v Ac household outlet.
3. Turn Thermostat to the highest setting (Cooler).
4. Turn Fan on to desired speed - **high (III)**, **med (II)** or **low (I)**.
5. When a desired temperature has been reached, adjust the thermostat until the fan stops. Your fan will now turn on and off to maintain the desired comfort level. As an added safety feature, the thermostat light will come on to let you know that your fan is still in the **on** position and the fan can turn itself back on.



**IMPORTANT:** Your 20" Box Fan with Thermostat is equipped with a climate control thermostat. This thermostat functions by sensing the temperature in the room and will turn the fan on or off AUTOMATICALLY as the temperature changes.

## Maintenance

**Always unplug cord before cleaning or disassembly.**

**Cleaning:** IMPORTANT! DO NOT immerse electrical parts in water! Disassembled grills may be immersed to be cleaned with a mild detergent and water. Wipe all other parts with soft cloth moistened with water and mild detergent only. DRY ALL PARTS COMPLETELY BEFORE REASSEMBLING AND RECONNECTING TO POWER SOURCE.

**Lubrication:** Motor is permanently lubricated.



# Troubleshooting Guide

Trouble	Probable Cause	Suggested Remedy
1. Fan will not start	1. Thermostat knob turned to low 2. Fuse or circuit breaker blown or off	1. Adjust thermostat knob to higher setting (towards cooler) 2. Check main and branch fuse or circuit breaker
1. Fan turns off automatically	1. Thermostat has reached desired temperature	1. Change thermostat setting towards cooler for fan to come on again
1. Fan stays on	1. Thermostat knob is turned to high (cooler) position	1. Adjust thermostat knob till fan goes off

## Warranty

### What does your warranty cover?

- Any defect in material or workmanship.

### For how long after the original purchase?

- 1 year.

### What will we do?

- Provide you with a new product or refund original purchase price.
- The exchange unit is warranted for the remainder of your product's original one-year warranty period.

### How do you make a warranty claim?

- Properly pack your unit. Include all parts, which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package a copy of the sales receipt or other evidence of date of original purchase. Also print your name and address and a description of the defect. Return product to your nearest Wal-Mart store for replacement or refund.
- For product service or replacement parts, call customer service at 877-207-0923.

### What does your warranty not cover?

- Customer instruction. Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.
- Installation and set-up service adjustments.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Product purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

### How does state law relate to this warranty?

- This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

### What if you purchased your product outside the United States?

- This warranty does not apply. See your dealer for details.







# 20 Pulgadas, Ventilador de Caja con Termostato

## Guía del Usuario

Para servicio del producto llamar servicio al cliente, al 877-207-0923.

Numero del artículo en reserva: UPC:  
106620 681131066204

## Instrucciones Importantes de Seguridad

Este Ventilador es para uso residencial únicamente. No está destinado para uso en ambientes comerciales o industriales.

1. Separe las dos Patas de Plástico, tal como se muestra.
2. Deslice las Patas dentro de las Ranuras en el fondo de la caja de metal hasta que estén en su posición.
3. Nunca meta los dedos, lápices u otros objetos extraños a través de la rejilla.
4. Desconecte el ventilador cuando lo traslade de un lugar otro.
5. Asegúrese que el ventilador esté en una superficie estable cuando está funcionando, para evitar la posibilidad de volcarse.
6. No use el ventilador en una ventana, ya que la lluvia podría crear un peligro eléctrico.



### Para Su Seguridad

El enchufe de alimentación eléctrica de corriente alterna está polarizado (es decir, una hoja es más ancha que la otra) y sólo encaja en la toma eléctrica de corriente alterna de una sola manera. Si el enchufe no entra completamente en la toma, gírelo e intente insertarlo de la otra manera. Si aún así no encaja en la toma, entre en contacto con un electricista cualificado y cambie la toma o utilice una toma diferente. **No intente saltarse esta característica de seguridad.**



**ADVERTENCIA:**  
Para prevenir el riesgo de un fuego o de una sacudida eléctrica, no exponga este aparato a la lluvia o a la humedad.

## Operación

1. Asegúrese de que el ventilador esté apagado.
2. Enchufe el ventilador en cualquier toma de corriente casero normal de C.A. de 120V.
3. Poner el termostato en el punto más alto (a la derecha).
4. Poner el ventilador a la velocidad deseada: **alta (III), media (II) o baja (I).**
5. Cuando se haya llegado a la temperatura deseada, regular el termostato hasta que el ventilador pare. ahora su ventilador se encenderá y se apagará para mantener el nivel de comodidad deseado. Como característica de seguridad agregada, la luz del termostato se encenderá para avisarle que su ventilador todavía está en la posición de encendido y que el ventilador se puede volver a encender por sí solo.



**IMPORTANTE:** Su Ventilador de Caja con Termostato está equipado con termostato de control de clima. Este termostato funciona detectando la temperatura de la habitación y encenderá el Ventilador AUTOMÁTICAMENTE a medida que cambie la temperatura.

## Mantenimiento

**Siempre desconecte antes de limpiar o desmantelar el ventilador.**

**Limpieza:** ¡IMPORTANTE! NO sumerja las piezas electricas en agua. Para limpiar rejillas se pueden sumerjir en agua con jabon suave. Use un paño suave humedecido con una solución de jabon suave para limpiar otras partes. SEQUE TODAS LAS PARTES COMPLETAMENTE ANTES DE ARMAR Y ENCHUFAR EL VENTILADOR.

**Lubricacion:** Los rodamientos estan lubricados permanentemente de por vida.



## Guía Para Descubrir y Corregir Anormalidades

Anormalidad	Causa Probable	Solución Sugerida
1. El Ventilador no arranca	<ol style="list-style-type: none"> <li>1. Perilla del Termostato puesta en bajo</li> <li>2. Fusible o interruptor automático quemado o desconectado</li> </ol>	<ol style="list-style-type: none"> <li>1. Regular la perilla del Termostato hasta un punto más alto (a la derecha)</li> <li>2. Revisar el fusible o el interruptor automático principal o el derivado</li> </ol>
1. El Ventilador se apaga automáticamente	1. El Termostat ha llegado al punto deseado	1. Regular la perilla del Termostato a la derecha para que el Ventilador arranque otra vez
1. El Ventilador se queda	1. La perilla del Termostato está puesta en la posición de alto (a la derecha)	1. Regular la perilla del Termostato hasta que el Ventilador se apague

### Garantía Limitada de un Año

#### Qué le cubre la garantía?

- Cualquier defecto de mano de obra material.

#### Por cuánto tiempo después de la compra original?

- Un año.

#### Qué vamos a hacer nosotros?

- Proveerle a Ud. con un producto nuevo o le reembolsaremos el valor del precio de compra original.
- La unidad cambiada estará garantizada por el tiempo restante del año de garantía de la unidad original que Ud. com pro.

#### Cómo hacer un reclamo de la garantía?

- Empaquete la unidad correctamente. Incluya todas las piezas, que haya sido originalmente proveidos con el producto. Nosotros recomendamos usar las cajas originales y materiales de empaquetar.
- Incluya en el paquete una copia del recibo de compra o otra evidencia con la fecha de compra. Devuelva su producto al Wal-Mart más próxima a usted para reemplazo o reembolso.
- Para servicio del producto llamar servicio al cliente, al 877-207-0923.

#### Qué no le cubre la garantía?

- Instrucciones del consumidor. El manual del Propietario le provee a Ud. con información relacionada a instrucciones de operación y controles del usuario. Para información adicional, consulte con su concesionario.
- Instalaciones y ajustes de la unidad.
- Desperfectos por mal uso o negligencia.
- Productos que hayan sido modificados o incorporados dentro de otros productos.
- Productos comprados o reparados fuera de los Estados Unidos.
- Obras de Dios tales como, pero no limitados a, los daños causados por rayos.

#### Cómo las leyes del estado están relacionadas a esta garantía?

- Este garantía le da a Ud. derechos legales específicos. Ud tal vez tenga otros derechos, los cuales varían de es tado a estado.

#### Si este producto ha sido adquirido fuera de los Estados Unidos?

- Consulte al distribuidor para cualquier información necesaria.

