


WakeMEup

Alarm Clock

INSTRUCTION MANUAL

A guaranteed to wake up a deepest sleeper.

The WakeMEup Alarm Clock comes with a strong bed shaker, jumbo size red LED display, adjustable loud audible buzzer and lamp outlet. You can choose to turn on or off the bed shaker or lamp to match your life-style or adjust the buzzer volume to your comfort level. The adjustable display dimmer will give you the option to lower the brightness of the LED display. WakeMEup will be sure to wake you up every morning.



INSTALLATION

Plug the Bed Shaker connector into the DC-12V jack on the rear side of the clock. Set the shaker under your pillow or mattress. Plug the AC cord to the nearest AC outlet. The digits on the display will light up.

SET TIME

Hold the TIME key down. Press the HOUR or MIN key until the correct hour and minutes are shown. Release the TIME button.

SET ALARM

Hold the ALARM key down. Press the HOUR or MIN key until correct hour and minutes is shown. Release the ALARM button.

FUNCTION SWITCHES

Volume control: Set the alarm for a minute ahead from the current time setting. When the alarm triggers, turn the knob clockwise to increase the volume of the buzzer. Stop at the level you feel comfortable with. Turn it counter clockwise to reduce the sound.

Bed shaker: Set the alarm for a minutes ahead from the correct time setting. Move the shaker ON/OFF switch to the ON position. The shaker will shake to wake you up.

Lamp mode selector:

- ON: Turn on lamp to read at night
- OFF: Turn off lamp
- Auto1: Turn on lamp when alarm triggers.
(Recommended for use with radio.)
- Auto2: Flash the lamp when alarm triggers.

Alarm:

When alarm is activated, the ALARM indicator (on the top left of the display) is illuminated.

Snooze:

By pressing the "Snooze" button, this delays the alarm for a 9-minute interval.

Dimmer switch:


Change the brightness of the display.

BATTERY BACKUP (battery not included)

The Backup Battery is not necessary for the clock to function. During a power outage, the clock will not display the time and alarm will not function. However, with a 9V backup battery installed, the clock will keep the time and alarm setting if the electric power is cut or the user unplugs the AC adapter. Check the battery condition after one year. Replace the battery when necessary. A leaking or faulty battery can destroy your clock.

CLEANING

Only clean the clock with a damp cloth. Never use strong or abrasive liquids. Do not place the clock under direct sunlight, outdoors, or in excessive heat conditions.



TROUBLESHOOTING:

- Q. No digits in the display**
 A. Check to see if the AC plug is connected to the AC power outlet.
 Check the breaker for the outlet to make sure the outlet is functioning properly.
- Q. Vibrator does not shake**
 A. Make sure the vibrator is firmly connected to the shaker jack on the rear of the clock and the shaker switch is ON.
- Q. No alarm sound**
 A. Turn VOLUME knob to HI (High).
 Try to set a new alarm for 1 minute later. Adjust the volume to your hearing comfort.
- Q. No lamp activity when alarm is triggered**
 A. Check lamp mode selector

WARRANTY

Krown manufacturing Inc. warrants that the WakeMEup clock and bed shaker sold by Krown Manufacturing Inc. is free from defects in materials and workmanship under normal use and service for one year. This warranty is applicable only to the original purchaser of the WakeMEup clock and bed shaker when accompanied by a sales receipt stating the date of purchase and the name of the company from which purchased. This warranty is in lieu and excludes all other warranties expressed or implied including any implied warranty of merchantability or fitness any of any obligations on the part of Krown manufacturing, Inc. shall either replace or repair the WakeMEup clock and bed shaker at no cost to the original purchaser within one year of the date of purchase. During a one year period the purchaser may return the WakeMEup clock to Krown Manufacturing Inc. at the following address:

Krown Manufacturing, Inc.
3408 Indale Road
Fort Worth, TX 76116

Shipping charges are at the customer's expense. Please include a check or money order made out to Krown Manufacturing, Inc. in the amount of \$7.50 to cover shipping and handling. This warranty does extend to any WakeMEup clock and bed shaker made by Krown Manufacturing, Inc. which has been subjected to abuse, neglect, accident, improper applications, improper installation, or to use in violation of the instruction furnished by Krown Manufacturing, Inc. This warranty does not extend to or apply to any WakeMEup clock and/or bed shaker which has been repaired or altered by any person who has not been expressly approved by Krown Manufacturing, Inc.

Krown Manufacturing, Inc. shall not be liable for any special or consequential damages or for loss or expense directly or indirectly arising from use of the products or any inability to use them either separately or in combination with other equipment or product accessories or from any other cause. This warranty is only applicable to a product purchased through Krown Manufacturing, Inc. or a Compu-TTY, Inc. Dealer. Other than as stated herein, there are no other warranties whether by sample or model, by description or quantity, whether expressed or implied and there are no implied warranties of fitness for a particular purpose or of merchantability.

