



ECTACO[®] Partner[®] LUX

**LANGUAGE LEARNING SYSTEM &
UNIVERSAL TRAVEL COMPANION**

USER MANUAL

ENG

More manuals are available at www.ectaco.com/support/manuals

ECTACO, Inc. assumes no responsibility for any damage or loss resulting from the use of this manual.

ECTACO, Inc. assumes no responsibility for any loss or claims by third parties which may arise through the use of this product.

ECTACO, Inc. assumes no responsibility for any damage or loss caused by deletion of data as a result of malfunction, repairs, or battery replacement. Be sure to back up all important data on other media to avoid data loss.

The contents of this manual as well as software functionality are subject to change without prior notice.

No part of this manual shall be reproduced, stored in a retrieval system, or transmitted by any means, electronic, mechanical, photocopying, recording, or otherwise, without permission from ECTACO, Inc.

jetBook®, Partner®, iTRAVL®, Language Teacher®, Lingvobit®, LingvoCompass®, Audio PhraseBook™, Vector Ultima™, U-Learn™, and MorphoFinder™ are trademarks of ECTACO, Inc.

Android is a registered trademark of Google, Inc.

The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

© 1990–2012 ECTACO, Inc., New York, USA.
All rights reserved.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CONTENTS

INTRODUCTION 6
 Highlights 6

GENERAL DESCRIPTION 7
 General View 7
 Keyboard 7
 Power Supply 9
 Turning the Device on/off 9
 Display and Main Menu 9
 Sidebar 11
 On-screen Keyboard 11
 Application Menu 11
 Context Menu 12
 Notifications Panel 12
 Pronunciation of Words and Sentences 12
 Voice Input 12
 MicroSD Card 13
 PC Communication 13

FOREIGN LANGUAGES 13
 Dictionary 13
 English Dictionary 16
 Language Teacher® 16
 Audio Phrasebook™ 17
 Usage of Audio PhraseBook for Foreign Language Studies 20
 Text Translation 20
 English Grammar 21
 Video Courses 21
 American Idioms 21
 Irregular Verbs 21
 Picture Dictionary 21
 Let's Talk American 22

ADDITIONAL RESOURCES 22
 Universal Translator 22
 Linguistic FlashCards 23

Spell-It-Right 23

Translation Test 23

Pockets 24

U-Learn™ 25

ECTACO® Market 25

Settings 25

INTRODUCTION

Congratulations on your purchase of the Language Learning System & Universal Travel Companion – ECTACO® Partner® LUX! The product you have purchased is the result of the combined efforts of the ECTACO team of linguists, engineers, and programmers. You are now the owner of one of the most advanced electronic devices ever produced for translation purposes and language studies.

Highlights


- ❖ *Talking Dictionary*
- ❖ *Voice input of text*
- ❖ *Audio PhraseBook™ with speech recognition*
- ❖ *Foreign language course, irregular verbs, idioms, English grammar guide*
- ❖ *Language Teacher® – a Language Learning System*
- ❖ *U-Learn™ – a hands-free/eyes-free Language Learning System*
- ❖ *Picture Dictionary, Universal Translator, Text Translator*
- ❖ *Reading text aloud*
- ❖ *Games*
- ❖ *Built-in memory for loading ebooks, music files and images*
- ❖ *Installing of third-party applications compatible with Android OS*
- ❖ *microSD slot for up to 64 GB cards*

The functionality of a particular model depends on the set of languages included, and it may partially differ from the device description in this manual. For more information about a particular model, please visit our Web site at **www.ectaco.com**.

The device is powered by a rechargeable battery, AC/DC adapter, or a PC via USB cable.

GENERAL DESCRIPTION


General View



















Due to the rotary screen, the device can be easily transformed into a handy tablet. Just turn the device screen 180° clockwise from its original position. To restore the screen to its original position, turn it 180° counterclockwise.

Note: To avoid damaging the device and invalidation of the warranty, do not rotate the screen by an angle exceeding 180°. Rotate the screen from its original position only in the direction of the arrow shown in the General View picture.

Keyboard

Key	Function(s)
	Close application and go to the <i>Home Screen</i> . Cancel.

	Use speech recognition (in applications featuring this function): press the key, say your phrase and then release the key.
	Switch to the <i>Home Screen</i> . Press and hold: show recently used applications.
	Show or hide the application menu. When in the <i>Home Screen</i> , press this key to activate the menu with the following commands: <i>Add, Manage apps, Wallpaper, Search</i> and <i>Settings</i> .
	Search. In the search window, enter the desired word or title you want to find. Press and hold: voice search by Google.
	Open the <i>Dictionary</i> window.
	Listen to the pronunciation of the source item, its translation, or a selected portion of text (in applications featuring this function).
	Turn the device on or off. Press and hold: open the menu to choose from one of the following options: <i>Silent mode</i> and <i>Power off</i> .
Shift	To type letters in uppercase, press Shift and then press the desired letter key. To turn on the <i>Caps Lock</i> mode, press Shift twice. To turn off the <i>Caps Lock</i> mode, press Shift once.
 or ¹ 	Switch language or translation direction.
Ctrl	Key assignment depends on the application.
Alt	Change input language – for example, from English to Russian or from Russian to English. The languages available depend on product model. Enter additional letters. For example, press Alt + L to enter ł in the Polish-English dictionary. Alternatively, press & hold a letter key to open a window where you can select additional characters.
Fn +key	Used in combination with the keys that have green marks. For example, you can increase the volume by holding down the Fn key and then pressing the key marked Vol Up .
	Display <i>User Manual</i> or application <i>Help</i> (in applications featuring this function).
	Show the on-screen keyboard. To hide the on-screen keyboard, press the  key once again or use the  key.
	Delete the character before the cursor (in applications featuring text input).
	Move cursor or highlight. Scroll lines.
	The Enter key. Data input; confirm the action you have selected.

¹ Symbol depends on product model.

RESET

Re-initialize system. The **RESET** button is located on the back of the device under the battery compartment cover.

Power Supply

ECTACO® Partner® LUX is powered by a special Li-Polymer rechargeable battery. When the battery becomes low, a warning message will be displayed. To restore full functionality of the device, recharge the battery as soon as possible.

The battery compartment is located on the back of the device and is covered with a plastic cover. To open the battery compartment, remove the battery compartment cover by sliding it away from the device.

How to Recharge the Battery


Only a special charger may be used with your ECTACO® Partner® LUX. Use of an inappropriate external power supply may cause failure of the device and will void the warranty.

Battery charging is performed via mini-USB port by using the AC/DC adapter or by a computer with USB-cable. The specified port is located on the lateral face of the device.

Note: Charge the battery for at least 5 hours prior to the first use of the device.

When the battery is fully discharged, the device might not turn on even if you connect it to the AC/DC adapter. You may need to charge the battery for 2 hours before turning on the device.

Turning the Device on/off

To turn the device on or off, press the  key. If the screen remains blank, connect the AC/DC adapter to your device via the mini-USB port. The red LED signal shows that the battery is recharging.


The battery can also be recharged through the USB port on your computer using the special USB to mini-USB cable.

Note: Use of an inappropriate external power supply may cause failure of the device and will void the warranty.

Tap the screen with the supplied pointing device called the stylus which, when not in use, is conveniently kept in a special slot at the side of the device's back panel.

Display and Main Menu










ECTACO® Partner® LUX features a large-size touch screen (800×480 pixels) with a responsive and efficient graphical interface. The *Home Screen* consists of five sections, which visually organize access to the ECTACO® Partner® LUX applications.

- To display the *Home Screen*, turn the device on, and/or exit the currently running application. You can also navigate to the *Home Screen* by pressing the  key.

Four sections of the *Home Screen* are completed: **Internet and Social Networking**, **Foreign Languages** (main section), **Additional Resources**, as well as **News, Weather and Games**. The remaining section doesn't contain any items until you add them.

- To open the desired item, tap it on the *Home Screen*. Touch and hold an empty location on the *Home Screen* to add a shortcut to an application, a widget, and so on.

The contents of the *Home Screen* depend on product model.

- To move between sections, press the arrow keys or drag the stylus across the screen to the left or right. To see all the sections of the *Home Screen*, tap one of the lower corners of the screen and hold the stylus down for a second.
- To view all your applications, tap the  icon at the right of the screen. To return to the sections view, tap the  icon at the right of the screen.
- To find the application you are looking for, start typing its name from the keyboard.
- When in a section, tap the desired application name. Alternatively, use the arrow keys , , ,  to highlight it and then press . The application will then open.
- To close an application, use the  key. In some applications, you will need to press the  key and then select the *Exit* or *Close* command in the application menu.

In certain applications (such as *QuickPic*), you can zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in). Additionally, in some applications you can double-tap the screen to change zoom level.


The status bar, which appears at the top of the screen, shows the time, Wi-Fi signal strength, battery status, and other information. It also displays notification icons.

Scrolling is used when the contents do not all fit on the screen. To scroll through the displayed content, drag the stylus across the screen or use the arrow keys.

The orientation of the screen rotates with the device as you turn it from upright to its side and back again. You can turn this feature on and off as described in the *Settings* section on page 26.




Sidebar

ECTACO® Partner® LUX provides easy access to frequently used tools. Just tap the respective touch button on the sidebar.




On-screen Keyboard


The on-screen keyboard is a set of virtual keys displayed on the screen. This set of keys simulates the conventional physical keyboard or part of it.

- In applications featuring text input, press the  key to activate the on-screen keyboard.
- To hide the on-screen keyboard, press the  key once again or use the  key.

Application Menu


The application menu contains items that apply to the current screen or to the application you are currently using. This menu is available in most applications.

- To activate the application menu, press the  key.




Context Menu

With the help of context menu you can choose an action to perform on the selected item. For example, you can copy a text onto the clipboard. To paste the text you have copied, place the cursor in a text input field and then select *Paste* in the context menu.

- To open the context menu, tap an item on the screen and hold the stylus down on it.
- When the pop-up menu appears, lift the stylus and then select the desired action. You can close the context menu by tapping the  icon on the sidebar.



Notifications Panel

Notification icons report the current actions and events, such as connection or disconnection of USB mass storage device.

- To open the *Notifications Panel*, drag the status bar down from the top of the screen by using the stylus. The status bar is a narrow strip at the top of the screen that shows various indicators.
- To close the *Notifications Panel*, press .

Pronunciation of Words and Sentences

ECTACO® Partner® LUX speaks *Dictionary* and *PhraseBook* entries out loud with a real human voice.

- To hear the word or phrase pronounced, tap the  icon, or press the  key.

In the *Text Translation* and *Translate* applications, the device employs the TTS (Text-to-Speech) technology which allows you to listen to the pronunciation of text.

Voice Input

Voice input is an experimental feature that uses the speech recognition service provided by Google. You must have a Wi-Fi connection to use this feature. You can enter text by speaking in the *Translate* and *Google Search* applications.

- Place the cursor in the text input field.
- Tap the microphone icon on the screen (if you set the microphone button to appear on the symbols keyboard, tap the *Symbol* key first).
- When prompted to speak, say your word or phrase.

MicroSD Card

ECTACO® Partner® LUX has a slot for microSD cards. It is located next to the mini-USB port on the right-hand side of the device.

- Slide the card into the slot – the contacts of the card face up. Push the card gently until it clicks into place. To eject the card, push it in slightly.

PC Communication

You need to install the appropriate USB driver to connect ECTACO® Partner® LUX to a Windows-powered computer. Please check product description on our Web site at www.ectaco.com.

- Ensure the microSD card is installed into the device.
- Turn the device on.
- Connect the device to your PC using the special USB cable. Please wait while your PC detects the device.
- Navigate to the newly detected removable disk on your PC to browse through the files stored on the microSD card.


Note: Always back up your important data! Neither the manufacturer nor the dealers assume any responsibility for lost or corrupted data.

FOREIGN LANGUAGES

Dictionary

ECTACO® Partner® LUX contains an electronic dictionary that speaks entries out loud with a real human voice.

- To find the selected word in the dictionary, enter it from the keyboard.



The commands assigned to the application menu buttons are listed below.



– Change the translation direction. For example, English to Spanish or Spanish to English.



– Activate spell-checker.



– Get the definition of the selected English word.



– Search. The search function allows you to find words, expressions or letter combinations in the dictionary.




– History. Show the list of the words you recently viewed.



– Settings. You can hide slang words or phrases contained in the dictionary. To disable *Slang Lock*, please use this password: *showslan*.



- When viewing entries, press the  key to activate the menu:



– return;



– go to the previous entry;



– go to the next entry.

Parts of Speech, Gender Labels, Abbreviations

Translations or definitions of a headword are shown with their parts of speech:

A – adjective

ABBR – abbreviation

ADV – adverb

ART – article

AUX – auxiliary

CONJ – conjunction

ID – idiom

NPR – proper noun

NUM – numeral

PART – particle

PHR – phrase

PREF – prefix

PREP – preposition

PRON – pronoun

INTRJ – interjection**SUFF** – suffix**N** – noun**V** – verb

Nouns may be marked with gender and number labels:

F – feminine**FPL** – feminine plural**M** – masculine**MF** – masculine or feminine**MFPL** – masculine or feminine plural**MN** – masculine or neuter**MNPL** – masculine or neuter plural**MPL** – masculine plural**N** – neuter**NF** – neuter or feminine**NFPL** – neuter or feminine plural**NPL** – neuter plural**PL** – plural

Certain words and expressions in the dictionary may be marked with specific abbreviations in English and other languages.

anat. – anatomy

fin. – finance

bact. – bacteriology

jur. – law

biochem. – biochemistry

mech. – mechanics

biol. – biology

med. – medicine

bot. – botany

opt. – optics

chem. – chemistry

pharm. – pharmacy

comm. – commerce

physiol. – physiology

comp. – computers

psychol. – psychology



econ. – economics


stomat. – stomatology

el. – electrical

vet. – veterinary

Pronunciation of Words and Sentences

ECTACO® Partner® LUX speaks dictionary and phrasebook entries out loud with a real human voice. To hear the word pronounced, tap the  icon, or press the  key.

The presence of human voice recording is marked by the blue color of the  icon. If the icon is black, a speech synthesizer is used.

English Dictionary

ECTACO® Partner® LUX includes an advanced English explanatory dictionary.

- To define a word, enter it from the keyboard.


The  icon to the right of a headword indicates that it has a voiceover.

Navigation within dictionary is performed as described in the *Dictionary* section on page 13.




Language Teacher®



ECTACO® Partner® LUX features the Language Teacher® – a language learning system. It is an extremely powerful linguistic tool for those who want to master a foreign language and learn to communicate fluently. With the help of *Language Teacher*®, you will learn a language quickly and easily.

There are four steps in *Language Teacher*®: *Alphabet*, *Words*, *Phrases*, and *Dialogs*. Each step comprises several stages.

- Select the desired step to start or continue learning.
- Follow the instructions announced.
- Select  to go to the next item, stage, or step. You may quickly jump to the desired step by tapping the respective icon in the primary menu of the application.

The *Words*, *Phrases*, and *Dialogs* options are powered through speech recognition and a graphical testing system. The phrase you have said will be recorded, automatically recognized and compared to the model pronunciation.

The smileys (, , ) along with a voiceover will guide you to improve your articulation skills.

- When using the speech recognition function, press and hold the  button on the screen to activate the microphone. Say your word or phrase and then release the  button.

Alphabet

- Listen to the alphabet. Select the desired letter's icon to listen to its pronunciation again.
- Listen to the sample words by selecting the appropriate on-screen keys.

Words

You will see words illustrated by pictures. Each word will be announced by voice.

- Follow the instructions announced and try to memorize the words.

Phrases

The phrases will be displayed and pronounced line by line. Some of the phrases have changeable parts. These are underlined.

- Follow the instructions announced and try to memorize the phrases.


Dialogs

Listen to the dialogs and master your pronunciation skills.





Audio Phrasebook™

ECTACO® Partner® LUX substitutes for an interpreter in standard situations such as registering at a hotel, shopping, visiting bank etc. You simply choose the appropriate phrase and the device will pronounce its translation.

For easy reference, the phrases are arranged by topics.



All topics contain a number of subtopics.

- To change subtopic, tap the current subtopic name. You will see the subtopics list. Select the desired subtopic.
- To change the translation direction, press the  key (marked as  on some models).
- To listen to the pronunciation of the phrase or its translation, tap the  icon or use the  key.

Some of the phrases have changeable parts. These are underlined. For example, when viewing the phrase *How frequent are the flights?* you can tap the flights and change it to trains. The phrase translation will change accordingly. To open the respective menu, hold the stylus down on the phrase within 1–2 seconds.

Categories: Useful Words and “You May Hear”

In the *Useful Words* section, the application shows useful words and speech patterns pertaining to the topic, if available.

- In the subtopics list, select *You may hear* to view a list of possible replies you may hear from your interlocutor.



Learning

The *Learning* subsection is built into *Audio Phrasebook™* to help you learn phrases pertaining to the topic.

- Listen to the pronunciation of the phrase.
- When training, use the following on-screen buttons: *Remember* and *Next phrase*.



Finding Phrases

With the *Search* command you will find a phrase in no time.

- Press the  key or tap the  icon. You may input a whole phrase (for example, *Thank you*) or a single word (*thank*).

Speech Recognition

The *Audio PhraseBook™* application features speech recognition functionality.





- Open the desired topic. You will see the list of its phrases.
- Press and hold the microphone button . Say your phrase and then release the  button. If the phrase is on the list, the highlight will move to it.

User Topic





The option allowing you to add new phrases is a very useful feature expanding the device phrase bank. You can add frequently used phrases from other sections of *Audio PhraseBook™*; you can also type your personal phrases with their translations. The *User Topic* includes the ability to edit phrases and translations.

Note: Before you use the *User Topic*, select the appropriate translation direction in *Audio PhraseBook™*. For example, phrases that you added to this section in the Spanish-English direction will not appear when you change it to English-Spanish. Later, if you open the *User Topic* and don't see the phrases you added, try changing the translation direction.





Adding Arbitrary Phrases

- To open the *User Topic*, tap the  icon at the bottom of the screen.
- Tap the  icon. Enter your phrase and its translation.
- Press and hold the  button. Say your phrase and then release the button. Record the phrase translation in the same way.
- Tap the  icon. Your phrase and its translation will be added to the *User Topic*.


Adding Phrases from Other Sections

- Open the desired section in *Audio PhraseBook™*, set the appropriate translation direction and select the phrase.
- Tap the  icon.
- Tap the  icon to confirm that you want to add the phrase.
- Tap the  icon. You will see the phrase you have added.
- To exit the *User Topic*, press the  key.



Editing a Phrase

- To open the *User Topic* section, tap the  icon at the bottom of the screen.
- In the *User Topic* section, highlight the desired phrase and then tap the  icon.
- Edit your phrase and its translation.
- You can re-record the voiceover for the phrase and its translation. Press and hold the  button. Say your phrase and then release the button. Record the phrase translation in the same way.
- To save changes, tap the  icon.

Deleting a Phrase

- Open the *User Topic* and select the phrase you want to delete.
- Tap the  icon.

Settings

- Press the  key on the top of the keyboard to activate the application menu.
- Tap the  icon to go to the application settings.

By specifying *male* or *female* in the *Speaker* and *Interlocutor* fields you can achieve greater translation flexibility and accuracy. They affect the way ECTACO® Partner® LUX translates certain words and phrases, not the voiceover. You cannot change the voice from male to female or vice versa.



Use the *Show translation* check box to turn on or off the display of phrase translation in the *Learning mode*.

If you notice poor accuracy of speech recognition, try choosing different options in the *Noise level* and *Low pass filter* settings.

By default the application pronounces phrase translation. You can opt to repeat the *Recorded Voice* instead.

Usage of Audio PhraseBook for Foreign Language Studies

First, listen to a phrase as recorded by a native foreign language speaker and then pronounce it by yourself. The device then compares the phrase you have spoken with the prerecorded sample helping you to improve your pronunciation.

- Select the desired topic and subtopic.
- If necessary, change the source language. The source language should be your native tongue.
- Select the desired phrase.
- To hear the phrase translation pronounced, tap the  icon in the translation area.
- Repeat this several times until you learn the correct pronunciation.
- Change the translation direction.
- Press and hold the  button.
- Say the newly learned phrase into the microphone. Position your mouth near the built-in microphone at a distance of 3 – 6 inches (8 – 15 cm).

The phrase you have said in the foreign language will be compared to the model pronunciation. If you have pronounced the phrase correctly, the device will recognize it and then show or pronounce its translation in your native language. If the device does not recognize you – simply repeat the above steps.

The accuracy of speech recognition depends on the level of external noise. It is best to ensure silence in the room where you practice your pronunciation.


To achieve the best results, please consider the following.

1. Ensure the room is relatively quiet.
2. Choose an optimum distance of 3 – 6 inches (8 – 15 cm) from the built-in microphone, taking your normal speaking volume into consideration.
3. Do not say unrelated words or phrases into the microphone.
4. Try to say phrases distinctly and plainly without clipping syllables.
5. Avoid carelessness in pronunciation (smacking of lips, loudly inhaling or exhaling, mumbling, interruptions, repetitions, etc.).

Text Translation




ECTACO® Partner® LUX features a highly efficient text translation program.

- Enter the text for translation using the physical keyboard or the on-screen one.

Use the  key to show or hide the on-screen keyboard.

The translation will be shown on the lower section of the screen automatically.

Use the application menu to access the application settings and to listen to the pronunciation of the source text or its translation.

- To activate the application menu, press the  key.
- The translation direction can be changed in the application menu or by pressing the  key (marked as  on some models).

English Grammar

A complete guide to English grammar, vocabulary and phonetics for non-English students. This electronic language learning system will help you study English by yourself, without conventional teachers or tutors. The guide is covering the Beginner and Intermediate levels.

Video Courses

English video courses are based on the original author's method of teaching English. The material is presented in a fascinating way with a lot of useful examples learned by the author from his own experience of living in the USA. All examples are provided with their respective voiceover in an appealing form with handsomely produced texts in English.

American Idioms

Over 200 widely used American idioms and their equivalents or translations are included in the *American Idioms* application. Each idiom is provided with a real human voice in English and other languages. For many languages, idioms equivalents or translations are provided with their pronunciation in a human voice.

Irregular Verbs


All commonly used English irregular verbs are stored in the *Irregular Verbs* application. The verbs are provided with their spelling and human voice pronunciation in the Infinitive, Past Simple and Past Participle forms. The pronunciations of verb forms are recorded by a professional narrator in the English language. For many languages, verb translations are provided with their pronunciation in a human voice.

Picture Dictionary

The *Picture Dictionary* application displays pictures of related words and provides translations and human voice pronunciation.

For easy references, the words are arranged by topics. The words are listed on the left side of the screen with their translations on the right side.

- To change topic, tap the current topic name that is shown above the word list. You will see the topics list. Select the desired topic.

- To change subtopic, tap the current subtopic name. You will see the subtopics list in a drop-down bar. Select the desired subtopic.
- To listen to the pronunciation of any word or translation, use the buttons at the bottom of the screen.
- To activate the search mode, use the  button.

In this application you can view definitions of English words. To do this, follow the steps below.

- Set the source language to English.
- Look for the desired word. The English definition of the selected word will be shown below the picture at the right of the screen.

Let's Talk American

A practical guide to American English everyday conversations, which is intended for students at the upper beginning and intermediate levels. Answers included.



ADDITIONAL RESOURCES


Universal Translator

Universal Translator is an application combining over 180 languages with cross-language translation functionality.

- To define a word, enter it from the keyboard.
- Navigation within the application is performed as described in the *Dictionary* section on page 13.

How to Set the Desired Language Pair

- Press the  key to activate the application menu.
- Tap the  button in the application menu.
- Select the desired source and/or target language.

ECTACO® Partner® LUX speaks dictionary entries out loud with a real human voice in English and other languages. These entries are marked with a special icon: .


- To listen to the pronunciation of the word or phrase, tap .

Linguistic FlashCards

The face of a card shows the source word translation or definition, and the reverse side shows the source word. The player browses the cards and, whenever necessary, uses a hint.



The goal is to learn all the cards in the set.

The number of unlearned cards in a set is recorded for each game. This information is displayed on the screen. For example, *Words left: 10*, means you have 10 cards to be learned.

- If necessary, change the source language by tapping . The source language should be your native tongue.
- Select the desired topic and then tap the desired set name. The game will begin.
- Select the *Drop* button to set a card apart.
- To go to the next card, tap *Skip*.
- Select the *SHOW TRANSLATION* message to see the target word.


Spell-It-Right

In this game the focus is on the correct spelling of words. The program displays the cards one by one with the target word hidden. This game is similar to *FlashCards*, but this time you should type the word yourself. As in all other games, you can view the target word at any time.

- If necessary, change the source language by tapping . The source language should be your native tongue.
- Select the desired topic and then tap the desired set name. The game will begin.
- Type the correct target word in the text input field and then press the  key. If you enter the word incorrectly, the corresponding message will be shown. Just try again.
- Select *Skip* to go to the next card.
- Select the *SHOW TRANSLATION* message to see the target word.

Translation Test

In this game you should choose the word which best corresponds to the given description. You will be offered four choices, and you should select the correct one. If your choice is incorrect, you will be prompted to answer the given question later.

- If necessary, change the source language by tapping . The source language should be your native tongue.
- Select the desired topic and then tap the desired set name. The game will begin.
- The word description and four answer choices will be displayed. Select the correct one.

If you have made an error, the word will be replaced with "---". If you have guessed the word, the card will be set apart. If you guess wrong or select the *Skip* button, the card will remain in the set and will be displayed later. The number of unlearned cards in a set is recorded for each game. This information is displayed on the screen. For example, *Words left: 10*, means you have 10 cards to be learned.


When you have finished a set, the *Current set is finished! Start over?* message will be shown.

- Select *Yes* to reset the statistics and go to the first question in the current set.

Pockets

This is a traditional game targeting in-depth word learning. In this game, the same cards as those used in the *FlashCards* game are divided into 4 groups (4 pockets). At the beginning of the game all cards are located in the first pocket. You turn the cards one by one and, if you know the hidden word, put the card in the second pocket. Keep browsing until all the cards from the first pocket are moved to the second pocket.


At the second stage you move the cards to the third pocket and, again, if you know the hidden word, put the card in the next pocket. The game continues until all cards are moved to the fourth pocket and memorized. You will direct most of your effort at learning difficult words, while simple words will shortly jump to the fourth pocket.

- If necessary, change the source language by tapping . The source language should be your native tongue.
- Select the desired topic and then tap the desired set name.
- Use the stylus to select the first pocket. The first card from those stored in the selected pocket will be displayed.
- Select *Got It!* if you know the hidden word. The card will be moved to the upper pocket.
- If you do not know the target word, select *Forgot*, and the card will drop to, or will remain in the lower pocket, if it is already there.

The bottommost line of the screen displays the number of cards left in the pocket.

U-Learn™

Having your language courses in a digital format means you can learn a foreign language practically anywhere, even in your car. This application will help you enlarge your vocabulary quickly and have you speaking a foreign language in no time.

- Launch the application and follow the instructions announced.
- Use the  key to activate the application menu.




Sleep Mode does not require any feedback from you during the course and allows you to memorize words and phrases when you are unable or do not want to speak.

ECTACO® Market

Visit our online software store! It offers a variety of linguistic software for text translation and language learning. Here you will find talking dictionaries, phrasebooks, FlashCards, text translators and more. The LingvoSoft® applications are available in different versions for various platforms.

Settings

For best results and to ensure that you can fully employ all of the diverse features of your ECTACO® Partner® LUX, it is recommended that you thoroughly familiarize yourself with the device settings. The following are descriptions of some of the most important settings. The application has an intuitive interface; the options are provided with helpful explanations in numerous languages.

- If the *Home Screen* (the screen with application icons) is not displayed, press the  key.
- When the *Home Screen* is displayed, press the  key and then select the  icon. You will see the *Settings* list.

Wireless & networks

An Internet connection is required for working with applications that are based on the Internet resources. ECTACO® Partner® LUX connects to the Internet through radio waves by using Wi-Fi technology.

- Select *Wireless & networks*.
- Specify the settings as needed and establish connection to a wireless network.

Display

Brightness: Adjusts how bright the backlight is on the device. For the longest battery life between charges, use the dimmest comfortable brightness.

Auto-rotate screen: Check to automatically switch the orientation of the screen as you turn the device sideways or upright.

Language & keyboard

Here you can change the interface language, make modifications to the user's dictionary and modifications to the keyboard settings.

Allow installing third-party applications

- In the *Settings* application, select *Applications*.
- Select the *Unknown sources* check box.

Note: We recommend that you only install applications from trusted, authorized sources, such as the website of the official supplier.