

itak *Personal Backpack Amplifier*

Battery charging

1. After switch on, the Power/battery low indicator LED will glow GREEN to indicate enough power and ready for operation. If this LED glows RED, it means the power is too low and battery recharge is necessary. (only for NiMH type)
2. This product applies intellectual charging circuit. The charging indicator LED glows RED during charging process. It turns GREEN when batteries are fully charged and the charging process will automatically stop to prevent overcharge to batteries.
3. When the charging indicator LED flashes RED, it means abnormal charging. Causes include that the rechargeable batteries have reached life span or batteries are not chargeable type.
4. This product can be operated even during charging process.

Cautions

1. This product uses 4 pieces of AA size battery. Alkaline or NiMH types are recommended.
2. It is advised not to pull and plug in the microphone contact frequently to prevent loose contact.
3. When battery operating hour shortens tremendously or can not be charged, it means their life span has arrived and a new set of batteries is necessary. When changing the batteries, please replace all of them at the same time. Please do not mix and use new and old batteries together.



Do not attempt to recharge non-NiMH batteries in this product. Consequences caused by incorrect charging will not be compensated by CHIAYO.



CHIAYO ELECTRONICS CO., LTD.

Web site: <http://www.chiayo.com.tw> E-mail: sales@chiayo.com.tw

OFFICE: 30, LANE 27, SEC.4, JEN-AI ROAD, TAIPEI, TAIWAN / TEL: 886-2-2741-5741 FAX: 886-2-2752-5242

FACTORY: 88, CHUNG HSIAO STREET 2, CHIAYI, TAIWAN. / TEL: 886-5-271-1000 FAX: 886-5-276-7611



itak

Personal Backpack Amplifier

OPERATION MANUAL



CHIAYO ELECTRONICS CO.,LTD

italk Personal Beltpack Amplifier

Parts and Controls



1. Mic in socket for headset/lavalier/wired microphone
2. Power/battery low indicator LED
3. Power/volume control
4. Tone control
5. Charging indicator LED
6. Charging port

Standard Configuration

1. Beltpack amplifier
2. 6V DC/500mA charging adaptor
3. Φ 3.5mm signal cable(100cm)
4. Waist Belt
5. Speaker pouch
6. Operation manual

Optional Items

1. NiMH battery (1.2V / 2600 mAh)
2. Headset microphone
3. Lavalier microphone
4. Mini wired microphone (3.5mm phone jack + 120cm cable)

italk Personal Beltpack Amplifier

Input microphone selections

1. Headset microphone
2. lavalier microphone
3. Mini wired microphone



Operating Instructions

1. Please beware of battery polarity when installing the rechargeable batteries. The spring end being the negative contact. For first use, please charge the batteries for at least 6 hours. Thereafter 6 to 8 hours of charging is necessary when batteries become weak.
2. This unit is delivered with adjustable waist belt. It can be belt-packed or shoulder-strapped.
3. Turn Volume and Tone controls to minimum before switch on. After turning this unit on, adjust volume and tone controls gradually till maximum gain before feedback.
4. Insert the microphone plug completely into the MIC IN socket to get the full contact, otherwise contact noise may occur due to loose contact. Adjust the microphone to as near the mouth as possible to get the best voice pickup.
5. Microphone and speaker should always maintain a certain distance to prevent the unpleasant feedback effect.

Battery installation

italk uses 4 AA-sized batteries to operate. To install the batteries, please open the cover of its rear battery compartment, then place them in accordance with its indicated polarity.

