TPC7030 Portable Data Collector

Quick Start Guide



http://www.posline.com.mx

See User Manual for more information



Charging the Main Batteries at least 16 hours for the first time

It may take up to 2 hours to fully charge the empty backup battery. The first time charge should be for at least 16 hours to insure a proper charge


After you have initially charged your device for about 8 hours, the device is ready to be used.









Front View



Back View





- 1. Scan key
- 2. Cursor key
- 3. 10-key pad
- 4. Enter key
- 5. Power key
- 6. ESC key
- 7. Reset

SFT key


Switches between the character input mode and the number input mode. [abc][ABC] lit on the LCD screen indicates the character input mode. When [123] is lit, the terminal is in the number input mode.

Function key


- F1 (-): Inputs the minus (-) sign
- F2 (SP): Inputs a space
- F3 (DEL): Deletes a character
- F4 (BL): Turns the key lights ON and OFF
- F5 (): Increases buzzer volume
- F6 (): Increases LCD backlight
- P1: Decreases Buzzer volume and program 1 (for user SDK define)
- P2: Decrease LCD backlight and program 2 (for user SDK define)

Install or replace the main battery in the terminal

Install or replace the main battery in the gun grip



2. Load a Li-Polymer battery pack into the main battery compartment in the direction shown in the figure



1. Turn the screw



3. Attach the battery compartment cover to the terminal and slide the main battery compartment cover lock to the LOCK position.




2. Open the cover




Be sure to turn the terminal off before you do this

2. Charging the Battery

Red = Normal charge / Green = Full Charge




Single slot Serial / USB Cradle



3. Communication with Host

The TPC7030 portable data collector let you link to a host computer through the CRD-20 cradle for data communication.



Support Information

More Information on the TPC7030 Visit the POSline® Web site http://www.posline.com.mx

Setting up, Using and troubleshooting the TPC7030 TPC7030 User's Manual Available at http://www.posline.com.mx



49-P20001-001 Rev. A - November 2008

TPC7030 Quick Start Guide