

[SVENSKA]

**ALLMÄNT**

Läs igenom denna bruksanvisning noggrant innan du använder denna produkt och spara den för framtida bruk. Alla modifieringar som görs på produkten orsakar omedelbart att garantin upphör att gälla och kan göra produkten osäker att använda. Proove International AB tar inte på sig något ansvar för produkter som har modifierats, eller skador som uppstår på grund av sådana modifieringar. Denna produkt är endast avsedd för hushållsbruk.

**HUR DIN TRÄDGÅRDSBELYSNING FUNGERAR**

Under dagen laddas det uppladdningsbara batteriet upp av solljuset. När det blir mörkt, tänds ljuset automatiskt och använder strömmen som lagrats i batteriet. Tiden som lampan lyser beror på hur länge den exponerats i solljuset dagen innan. Maximal tänd tid är ca 6 timmar.

**INSTALLATIONSANVISNING**

Följande punkter hjälper dig att välja bästa möjliga plats att sätta lamporna på:

- Ställ lamporna där de kan exponeras för så mycket solljus som möjligt på under dagen.
- Se till så att lamporna är rena genom att torka av dem med jämna mellanrum med en fuktig trasa.
- Försök att inte ställa lamporna där solljuset kan skuggas, t ex under buskar eller träd. Sådan placering gör att batteriet inte laddas fullt, vilket leder till att tiden som lampan lyser blir avsevärt förkortad.
- Eftersom det är färre och kortare soliga dagar under höst och vinter, kommer lamporna att lysa kortare tid under dessa månader.
- Ljuset tänds automatiskt via den inbyggda sensorn. Denna sensor kan sluta fungera om lampan placeras så att den ständigt utsätts för ljus, t ex från en annan utomhusbelysning.
- OBS! Lamporna kan bli hala när de utsätts för väta.
- Lamporna får inte gutas ner i cement. Detta skadar lampan och gör det omöjligt att komma åt batteriet och strömbrytaren.

**BRUKSANVISNING**

1. Sätt på lampan genom att trycka på strömbrytaren och placera lampan enligt anvisningarna ovan.
2. Lamporna skall lämnas i direkt solljus i minst 8 timmar. (Detta gör att batterierna laddas upp maximalt). Om det är mulet så krävs det längre tid.
3. Lampan kommer att tändas när det blir mörkt och släckas när det blir ljusst eller när strömmen i batteriet tar slut.

**BYTA BATTERIER**

Endast uppladdningsbara batterier av typ AAA, 700mA, Ni-MH får användas. Blanda aldrig batterier. Du vet att det är dags att byta batteri när lampan lyser kortare tid än normalt trots att lampan exponerats för 8 timmars solljus dagen innan.

1. Ta upp lampan och gör rent undersidan från smuts och skräp.
2. Skruva ur de fyra skruvarna, lätta på locket och ta försiktigt bort gummipackningen.
3. Nu skall du kunna se batterifacket. Byt batteriet enligt anvisningarna ovan. Lägg tillbaka gummipackningen och skruva tillbaka locket.

**LED-LAMPORNA GÅR EJ ATT BYTA.**

**PROOVE**  
INTERNATIONAL AB



Proove International AB, Kabelvägen 7-9, SE-311 50 Falkenberg, Sweden  
Tel +46(0)346-71 56 00, Fax +46 (0)346-71 56 20, info@proove.se, www.proove.se

[ENGLISH]

**GENERAL**

Please read these instructions carefully prior to installation and retain them for future reference. If any modification is made, it will invalidate the warranty and may render the product unsafe. Proove International AB will not accept responsibility for modified products, or any damage or injury caused as a result of their modification. This product is for domestic use only.

**HOW YOUR GARDEN LED LIGHT WORKS**

During the day, the solar panel converts sunlight into electricity and recharges the internal batteries. At night, the light turns on automatically and uses the power stored in the batteries. The number of hours the light stays on depends upon the amount of sunlight the product has received the previous day. Up to a maximum of approximately 6 hours.

**FIXING INSTRUCTIONS**

Decide upon a suitable mounting position for your fitting with the help of these notes:

- Position your fitting in a location where it can receive maximum exposure to solar radiation during the day.
- Keep the solar panel clean by regularly wiping over with a damp cloth. A dirty panel will reduce the amount of solar radiation that is available to charge the unit's batteries.
- Try not to position your fitting in a location where solar radiation will be diminished, e.g. beneath trees or bushes. The effect from this will be a greatly reduced lighting up period at a night, because the battery within the unit will not be fully charged.
- Due to fewer daylight hours and generally cloudier skies in the autumn and winter, the overall lighting up period will be less during these months.
- The light turns on automatically at night via the built in photosensor. This sensor can fail to operate if the light is positioned in a location where bright light falls on the unit during the hours of darkness, e.g. from another outdoor light.
- NOTE: THE FITTING MAY BECOME SLIPPERY WHEN WET AND CAUTION MUST BE TAKEN WHEN DECIDING A LOCATION
- THE FITTING SHOULD NOT BE SET INTO CONCRETE. THIS WILL DAMAGE THE PRODUCT AND WILL PREVENT ACCESS TO THE BATTERIES / SWITCH WHEN REQUIRED.

**HOW TO USE YOUR GARDEN LED LIGHT**

1. Turn on the lamp by pushing the switch and place it according to the fixing instructions noted above.
2. The unit should be left in direct sunshine for at least 8 hours. (This will enable the batteries to reach their fully charged state.) If the sky is overcast, this period of time should be increased.
3. The lamp will now switch on when it becomes dark and switch off when daylight returns or battery power runs out.

**REPLACING THE BATTERIES**

When replacing the batteries, use type: AAA, 700mA, Ni-MH, rechargeable batteries only. Only use the same type and specification of batteries within the lantern. Never mix the batteries. It is time to replace the batteries when a shorter than normal operating time is detected, despite the lantern receiving a full 8 hour charge in direct sunlight.

1. Remove the unit from its location and clear any dirt / debris from the rear of the unit.
2. Remove the four retaining screws and ease of the cover and carefully remove the rubber seal.
3. The battery compartment should now be visible. Use only recommended batteries as stated above.

**THE LEDs ARE NON REPLACEABLE**

**PROOVE**  
INTERNATIONAL AB



Proove International AB, Kabelvägen 7-9, SE-311 50 Falkenberg, Sweden  
Tel +46(0)346-71 56 00, Fax +46 (0)346-71 56 20, info@proove.se, www.proove.se