archgon



USB 3.0

MD–3107–U3

Blu-ray Optical Drive

User Manual

Product

MD-3107-U3 Blu-ray Optical Drive

Thank you for purchasing External Blu-ray Drive from archgon. Please read following instructions carefully and note all Cautions and Warnings.

BEFORE USE

Please confirm the drive type in your hand. It can be identified by the retail package.

	CD		DVD		Blu-ray	
	Read	Write	Read	Write	Read	Write
Combo	V	V	V	V	V	**X**
Writer	V	V	V	V	V	**V**

Note：The external drive is compatible with both PC and Mac.

Install authorized Blu-ray software before reading or writing to a BD media.

For **Mac users**,

1. Please purchase and download appropriate Blu-ray playback software for Mac OS.
2. The external drive will be not detected if without inserting a disk.
3. Eject button function may be not work under Mac OS. Please click the eject icon from playback.


SYSTEM REQUIREMENT

Windows XP, Vista, 7, 8 or higher

Mac OS 10.5 or higher

INSTALLATION

1. Power on the PC/Laptop.
2. Plug the USB 3.0 micro B type connector to the back of the drive.
3. Connect the Type-A connector(s) to USB port(s) on the PC/Laptop.
4. Once properly connected, you will see the new drive under “My Computer”. The device will be ready to use without further setup.



Note：Connect fat cable to PC/Laptop as the major power. In some cases, the thinner one maybe

required to connect to the computer as well.

Troubleshooting

Drive not recognized.

1. Make sure the USB Y-cable and connectors are not damaged and firmly connected at all three ends.
2. Insert a BD, DVD or CD to allow your PC/MAC to mount a disc.

Cannot open the tray.

1. Wait until the software activity is finished; or stop the software activity and then press eject.
2. Turn off power to the drive, then insert a small stick or paper clip into the emergency eject hole to eject the tray.

Cannot read a previous session of a CD-RW disc that has been written to at least twice.

1. Make sure you properly select “import previous sessions” when writing new data to the disc.
2. Always use high-quality media. Always handle discs with care and keep them clean. Deep scratches, fingerprints or other contaminants on the disc’s surface can make it unreadable.
3. Remove the disc from the tray and reinsert it label side up.

Cannot play BD movies

1. Install authorized BD playback software.
2. Use CyberLink BD & 3D Advisor Overview to verify if your system meets the minimum requirements for BD movie playback. http://www.cyberlink.com/stat/bd-support/enu/index.jsp
3. Visit the website of your graphics card manufacturer to confirm both your graphics card and driver are HDCP compliant. Download and install the latest graphics card driver.
4. Visit your monitor manufacturer to confirm your monitor is HDCP compliant.

Cannot write to disc

1. Use the authorized software.
2. Contact the software supplier (or check the appropriate website) to ensure that it supports your BD drive.
3. Reinsert the disc label side up.
4. Ensure that the capacity of the write data is available on disc. (Required capacity may vary according to write method.)
5. Make sure the USB Y-cable and connectors are not damaged and firmly connected at all three ends.


Writing errors occur

1. Always use high-quality media. Always handle discs with care and keep them clean. Deep scratches, fingerprints, or other contaminants on a disc’s surface can make it unwritable.
2. Ensure that the capacity of the write data is available on disc. (Required capacity may vary

according to write method.)

Cautions

MD-3107-U3 Blu-ray Optical Drive



Safety information：

Do not let your device get wet.
Do not leave it in a damp condition, high humidity or direct sunlight.

Do not attempt to disassemble or repair the unit if you are not qualified to do so. Avoid opening the drive; it may result to exposure to laser radiation.

Do not place your device near strong magnetic fields, such as television or radios. This could affect the performance of the drive.

Do not place this device on an unstable surface where it might drop.

* For further questions, please write an e-mail to archgon@archgon.com

*All Trademarks and Logos reserved by Archgon International Ltd.

K-MU-00110
www.archgon.com