



User Manual

This Professional Cold-Air Aromatherapy Nebuliser changes the essential oil from liquid to an extremely fine mist without destroying any chemical constituents and is a very effective way of diffusing essential oils for around the home, office, or other indoor environments.




CONTENTS:

Glass Stopper 1
Glass Chamber 2
Ceramic Base Unit 3
Power Supply

OTHER ELEMENTS:

Internal Stem (attached) (4)
On/Off Switch and Intensity Dial (5)



SAFETY: The Nebuliser creates a fine mist of your essential oils without

the use of any flame or heat source.

OPERATION: The diffuser will function on a 2 minutes on and 1 minute off basis for two

hours, allowing the oil to last longer. Energy efficient!

DIGITAL CONTROL: Digitally programmed to stop automatically when minimum oil level is

reached. To save energy, the power automatically turns off after 2 hours.

4

5

USER FRIENDLY: The diffusion intensity level can be adjusted to reflect your personal

needs. This product is also easy to clean.

FEATURES: Up to 5 different colours of LED light can be used as a night light.

SUGGESTION: Try adding 4 drops of lavender oil, 2 drops of peppermint oil and 4 drops

of rosemary oil to create a fresh, positive, and clear aroma.

OPERATING INSTRUCTIONS

- 1. Install the glass chamber onto the ceramic base.
- 2. Remove the glass stopper from the chamber.
- Place between 10 and 20 drops of undiluted essential oil into the chamber.
 DO NOT FILL PAST 2/3 OF THE INNER STEM. ONLY USE ESSENTIAL OILS AND NOT WATER, OR OTHER PRODUCTS (see below this step by step for full details).
- 4. Place the glass stopper into the top of the chamber, ensuring all protective wrapping has been removed.
- 5. With dry hands, plug the power supply into the unit and a standard electrical outlet.
- 6. Turn the silver dial on the ceramic base to the right to turn on the unit. The LED light should come on and the unit should gently vibrate when the Nebuliser is turned on.

 Note: turning the dial to the right increases the intensity of the diffusion.

For best results and to ensure a long life for your lonic Nebuliser, we do not recommend using any any viscous essential oils as they will clog up the inner mechanics of your diffuser over time. We also do not recommend that you add any essential oil dilutions, massage oils, or carrier oils in this product. Examples of viscous essential oils include: Benzoin, Jasmine Absolute, Myrrh, Patchouli, Sandalwood and Vetiver.

CLEANING INSTRUCTIONS

Clean unit thoroughly 1-2 times a week or when a new oil is used.

When cleaning the machine please follow these steps:

- Ensure the unit is properly switched off before removing the glass chamber from the ceramic base.
- 2. Remove the glass stopper and pour out any remaining oil.
- Place a capful (3-5ml) of isopropyl alcohol (IPA), or rubbing alcohol, into the chamber and gently swirl it around for 2-3 minutes before emptying.
 USE CAUTION WHEN USING IPA AS THIS IS A FLAMMABLE IRRITANT. SEE THE LABEL ON THE BOTTLE FOR FULL CAUTIONS. DO NOT USE A CLEANING AGENT.
- 4. Allow all of the remaining alcohol to evaporate before reinstalling the chamber.

Alternatively, gently soak the glass chamber in warm soapy water for approximately ten minutes and rinse. DO NOT EMERSE THE CERAMIC BASE OR POWER SUPPLY IN WATER.

SAFFTY INSTRUCTIONS

- 1. Please follow the instructions to operate the unit
- 2. Use only the power supply provided to operate the unit.
- 3. Do not fill above 2/3 of the inner stem inside the chamber.
- 4. Do not place water, thick oils, or products other than pure, undiluted essential oils into the chamber.
- 5. Keep the unit on a flat and secure surface at all times.
- 6. Do not operate the unit with wet hands.
- 7. If a problem arises, shut off and unplug the unit from the power. Do not attempt to open the unit; repairs should only be carried out by a qualified service centre.
- 8. Do not immerse the ceramic base or power supply in water and ensure glass chamber is properly dry after cleaning before reinstalling into the base.
- 9. The unit will automatically stop working when the oil level reaches its minimum level, or when it has been on for two hours.
- 10. For indoor use only.
- 11. Keep away from young children and pets.

TROUBLESHOOTING/ SOLVING PROBLEMS

PROBLEM	SOLUTION
The unit does not appear to be turning on, and the light is not working	 Check that the power supply is securely plugged into both the unit and electrical outlet Check that the main outlet is working properly Check that the fuse has not gone in the power supply plug
The light is on however the unit does appear to be vibrating or dispersing mist	 To be working, the unit should be vibrating gently for two minutes, with one minute break Check that it has not already been on for two hours – if this is the case, simply turn the unit off, and back on again (this should reset the timer) Check that there is adequate oil in the glass chamber If this does not work, try thoroughly cleaning the glass chamber to remove any built up residue that could be blocking the unit (SEE CLEANING INSTRUCTIONS) Check that the chamber is properly installed and that the stopper is in place Restart the unit
There is less dispersal than usual when the unit is powered on	 Check that there is adequate oil in the glass chamber If this does not work, try thoroughly cleaning the glass chamber to remove any built up residue that could be blocking the unit (SEE CLEANING INSTRUCTIONS) Check that the chamber is properly installed and that the stopper is in place Restart the unit

We will be happy to assist you with any further issues or questions you may have. Please feel free to contact us using any of the options below.



Absolute Aromas Ltd. Tel: +44 (0)1420 540400 www.absolute-aromas.com sales@absolute-aromas.com









