LinQTab LQBBS



LQBBS – Hi-Def Bluetooth Speaker User Manual

Please read this manual before operating your device, and keep it for future reference.

Copyright

© LinQTab is a registered trademark of eXiom Technologies and its related entities.

The Bluetooth[®] word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG.

microSD[™] and the microSD logo are Trademarks of the SD Card Association.

Wi-Fi, the Wi-Fi CERTIFIED logo, and the Wi-Fi logo are registered trademarks of the Wireless Fidelity Alliance, Inc.

Table of Contents

LQBBS – Hi-Def Bluetooth Speaker User Manual	1
Copyright	2
Table of Contents	3
General notices for use	
Disclaimer	4
Box Contents	4
Getting Started	5
Product Specifications	5
Battery Charging	6
Flashing LED Definitions	6
Understanding your LQBBS Speakers	7
Speaker Buttons	8
Pairing your speakers with another device	8
Customer service	10

General notices for use

- This product is a highly advanced electronics device. Disassembly, customization or repairs without the appropriate knowledge and precautions can lead to dangerous situations with chance of damaging the product and causing serious personal injuries.
- Avoid use in extreme conditions such as high or low temperatures, high humidity or moist environments and around magnetic fields. Also avoid long-time exposure to sunlight.
- Only use the manufacturer permitted accessories to avoid damages to the product and possibly warranty loss.
- Please follow the relevant local environmental regulations to deal with obsolete machines and accessories.
- Use a protective folder to avoid extreme physical shocks to the device (i.e. of dropping).

Disclaimer

- The screenshots in this manual are for reference only. They may be made on a device with a different resolution or hardware configuration than yours and therefore can be slightly different that the final product.
- The manufacturer takes no responsibility for loss of information or data caused by hardware or software failure. The user is responsible for performing timely backups of important data.
- All information and images used in this user manual are provided 'as is' and are subject to change without notice.
- The manufacturer accepts no liability for the information offered in this document.

Box Contents

- □ LinQTab LQBBS Speakers
- □ USB cables

Getting Started

Product Specifications



LQBBS

Model No.	LQBBS – LinQTab Hi-Definition Portable Bluetooth Speakers
	Hi-Definition Bluetooth Speaker
	Hex designed
	Crystal-clear sound
Main Features	Light Weight with Shock absorbing material
Loudspeaker Output	3W * 2
Speaker Specification	$\Omega 40 MM$
Frequency Response	280HZ – 16KHz
Signal-to-Noise	≥95dB
Bluetooth	Bluetooth V 4.0
Connectivity	PC, Mobile and Tablets
Support	A2DP, AVRCP, Headset, hands free profile
USB	Micro USB
Working Range	Up to 10 m
Working Time	Up to 5 Hours
Microphone	Built-in Microphone for phone calls
Audio Input	3.5 mm Audio Jack
Special Feature	Super Bass in-built Sub Woofer
Controls	Double function control: Volume, + Next - Previous and Call
Dimension	15.5cm(L) x 4.8cm(W) x 4.8cm(H) or 6.1"(L) x 1.9"(W) x 1.9"(H)
Weight	265 grams or 0.58 Lbs
Battery	Lithium Ion
Color	Black Speaker Unit
Warranty	6 months

The information contained in this document is subject to change without notice.

Battery Charging

Please make sure that the battery is fully charged before your first use. To charge the battery, please connect the USB cable to your computer or wall adapter (sold separately) and insert the other end into the USB interface of LQBBS.

Once the LQBBS speakers have been charged, please unplug from the charger.

Flashing LED Definitions


LED Color	Meaning
Green Flashing	In TF card MP3 mode
Green On	TF card MP3 is paused or in AUX mode
Blue Flashing	In Bluetooth mode
Alternating Red and Blue	Bluetooth pairing
Red On	Charging
Red Off	Fully charged
Red Flashing	Low Power

Understanding your LQBBS Speakers

Front Views of speakers



Back View of speakers



Top View of speakers



Speaker Buttons

The buttons on the top of the speakers serve different purposes depending on the mode you are using:

lcon	Description
	<u>TF / Bluetooth Mode</u>
	Short Press: Previous Song
	Long Press: Volume Down
	TF Mode
	Short Press: Play / Pause
	Bluetooth Mode
	Short Press: Play / Pause / Answer / End/ Cancel Dial / Pair
	Double Click: Redial last number
	Long Press: Reject call
	TF / Aux Mode
	Press: Switch between TF Card and Aux
	<u>TF / Bluetooth Mode</u>
	Short Press: Next Song
	Long Press: Volume Up

Pairing your speakers with another device

- 1. Turn off your speakers
- 2. Switch the speakers on setting it to Bluetooth mode. You will see the blue LED flash 6 times.

- 3. On your mobile or other device search for Bluetooth devices
- 4. In the list of devices you will see LINQ-100 select it and connect
- 5. Enter Password or PIN 0000 and press "Yes" or "Confirm"
 - a. **Important: If the connection is successful, blue LED will flash. If the pairing is unsuccessful, the LED alternate between red and blue. You will need to pair to your device again.

Customer service

If you have any questions or suggestions, please contact us:

E-mail: contactus@exiomtech.com