



## User manual

### Electronic air ioniser – Air purifier

*Attention! Do not touch the needles when unit turned on!*

#### Function:

By the combination of three of the world's most recognized technologies of purification, **AIRBUTLER** Frank is able to guarantee a maximum of purification: dust purification, removal of bacteria and elimination of nasty odours. All that can be achieved by a very powerful generator of ions. It produces negatively charged ions which are able to destroy virus and mites. The power consumption for the mechanics of filtration, purification and for the fan is only 8 W. The produced active oxygen is in the position to purify air, to eliminate smoke and neutralize bad smells.

#### Bond of dust:

After a few days of use, you will find a considerably deposit of air pollutants on the DDC electrostatic dust collector.

#### Integrated UV lamp:

In the interior of the **AIRBUTLER** Frank, an UV lamp is installed which is automatically activated in switching on the appliance. This lamp kills bacteria and virus inside the device. This lamp only uses 0.5 W and has a shelf life of about one year.



# FRANK

### **Well-being effect:**

**AIRBUTLER** Frank eliminates dust, odours and bacteria and promotes a general feeling of wellness. You constantly breathe fresh and pleasant air.

### **Low-noise:**

**AIRBUTLER** Frank can work with a fan of 2 levels, HIGH and LOW. Both of them are quite noiseless. You don't need the fan to have Frank working well, just use it in case you have to eliminate intensive smells.

### **Applicable areas:**

Frank can be used in all kind of rooms of daily living, in vehicles, offices, waiting rooms, etc. Please place **AIRBUTLER** Frank at a height of 150 – 180 cm or in immediate proximity to air conditioning units, in order to guarantee unrestricted movement of purified air. If the appliance is used in a vehicle, make sure that it is fixed with the enclosed adhesive pads at a secured place, and that it does not affect your security!

### **Start-up:**

Plug **AIRBUTLER** Frank into the socket with the enclosed mains cable. A red lamp will light up, when you turn on the unit with the button „POWER“. You can smell freshness, when the ioniser works flawless, just like after a thunderstorm. The appliance has a state-of-the-art microchips, which ensure a controlled ON / OFF cycle. The appliance switches off automatically in LOW mode after 1 minute and returns to an endless circle 3 minutes later. **AIRBUTLER** Frank works constantly when in HIGH mode. To turn ON / OFF the fan, shift the button at the side of the device.

### **Setting:**

The output of active oxygen and ion production can be adjusted optimally to the respective room size using the controller at the front side of the appliance (LOW / HIGH).

## Cleaning / Maintenance:

**AIRBUTLER** Frank is very efficient in binding dust without using any filter or other auxiliary devices. The dust collector binds all pollutants and has to be cleaned at least every 14 days. Turn off and unplug the appliance. Remove the dust collector at the side of the appliance by turning downward the black disk and pulling it up. Dust collector should be cleaned under flowing warm water with a mild detergent. You can also put the dustcollector into the dishwasher!

Clean the ionisation sprockets with a dry brush. Make sure that all parts are completely dry, before you reassemble the unit. The inside of the casing should be cleaned twice a year. Proceed like aforementioned. Now open carefully the right and left plastic front grips as well as the rear part. Open the casing by loosening the 6 screws at the bottom of the **AIRBUTLER** Frank. Clean the inside with a wet tissue. Make sure that all parts are completely dry before you reassemble the unit. Proceed in reverse order for the re-assembly of the appliance.

## How to replace the UV lamp:

- Please open carefully the backside of the **AIRBUTLER** Frank.
- Take the UV lamp with both hands and insert the beginning either by either the left or the right to the places provided for that purpose.
- With a light pressure insert the new lamp and place it in its location by making slight pressure, start by either the left or the right.



- Make sure that the lamp is properly put in place.
- Close the backside of the device so that the arrows show down.

### **Important information:**

- Please keep a distance of 50 cm to the air outlets while appliance is working.
- Do not insert any metallic objects into the unit to prevent electrical shocks and damage. Do not place the unit close to flammable and explosive objects.
- Please, connect **AIRBUTLER** Frank in vehicles only with the adapter cable provided.
- Do not hit or drop **AIRBUTLER** Frank.
- Do not set up **AIRBUTLER** Frank in direct sunlight or steam.
- Do not use alcohol or benzene for cleaning the casing to avoid any damage on the surface.
- Keep appliance out of reach of children and pets.

### **Further information:**

This ioniser purifies air, it is not a substitution of regular airing of rooms. Do not modify the appliance in any way. Neither the manufacturer nor the trader can accept any responsibility of any kind of damage thus resulting.

### **Accessories:**

- 1 adapter 230 V
- 1 adapter cable for cigarette lighter 12 V
- 2 adhesive pads to fix appliance in vehicle

## Warranty for FRANK

1. All **AIRBUTLER** products are subjected to stringent testing before they leave the factory. Guarantee of function for two years from date of purchase.
2. Damage and malfunctions within the warranty period are only dealt with on presentation of the completed warranty certificate. Please return the appliance to the trader so that the cause of malfunction can be identified. If the damage or malfunction is due to a production fault then the appliance will be repaired immediately or replaced with a new appliance. Damage which is not due to a production fault cannot be taken into account.
3. The warranty does not include any damage due to incorrect handling, faulty reassembly, manual conversion in or on the appliance, omission of cleaning, exterior damage to the appliance or obvious damage to the interior of the casing (such as e.g. lightning, artificial cause or natural events).
4. The date on the warranty certificate and submission of the bill are imperative for any warranty claims.



Name: \_\_\_\_\_

Address: \_\_\_\_\_

Purchase date: \_\_\_\_\_

Phone: \_\_\_\_\_


Stamp of trader: \_\_\_\_\_

\_\_\_\_\_

## Technical data:

Type	AIRBUTLER Frank
Voltage	230 V / 12 V
Power consumption	8 W
Negative ions	$> 1,2 \times 10^6$
Active oxygen	$< 0,05$ ppm
Radiance	20-30 $\mu$ W
Dimension	350 x 220 x 126 mm
Weight	1406 g
Applicable area	30 m <sup>2</sup>

**AIRBUTLER** reserves the right of any technical modifications of the appliance.



We are at your service for questions or application problems:

[office@airbutler.com](mailto:office@airbutler.com)

