

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

QNN[®] Safe

USER'S MANUAL FOR B / BW SERIES

SAFE

Serial Number:



This package contents:

- User manual
- 2 Master keys
- 4 Bolt Down Screws M12mm x 80mm (2 for BW model)
- 4 AA Batteries
- 3 handle bars

Please contact your retailer or Qnn Safe Australia P/L if any shortage is occurred

For the first time use, it needs to supply 4 AA batteries power to the safe:

- Counter clockwise the Keypad then to insert the supplied 4 AA batteries into the Battery Box
- Prepare the master key into the position
- After enter the right code, turn master key clockwise and turn the handle clockwise, Safe is now unlocked.

This safe is operated by the Master Key and the digital code.

The factory setting for the Master Code is: “1 2 3 4 5 6 “

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233






Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

Opening instructions:

- Prepare the master key into the position
- Single Control Mode : Press  and then the code, and then press  .(Factory setting at Single Control Mode , Master Code “123456”)
- Dual Control Mode: Press  and then the first code, and then press  , and then the second code, and then press  . **(Please note: The pause between the two code entering is 60 seconds)**
- Green light on with one beep indicated that the digital lock is unlock.(factory setting master code “123456”)
- Turn master key clockwise and turn the handle clockwise, safe now is unlocked.
- All light off with 2 beeps means a wrong code try. 3 continual wrong code tries will lead a freezing period of 5 minutes

Closing instructions:







- Close the door
- Turn the handle counterclockwise
- Turn master key counterclockwise, and remove the key.

Changing Master Code:

Please keep the door at opening position during the whole processing until fully ensure that the code is changed correctly.

For security reasons, please change to your own code after the first opening.

Your code can be set up to 10 digits

- Open the safe door
 - Press  then enter **Master Code**, then press  . Orange light on with one beep.
 - Press  , press  and then enter **New Master Code** then press 
 - Enter **New Master Code** again then press  to confirm.
 - Orange light on with one beep means the Master Code has been change successful
 - Keep the door open, check and remember the code
- Orange light off with two beeps means changing is fault. And the old Master Code is still in place.**

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

User setting:

Under the control of the **Master Code**, the maximum user of this safe can be set up to 6:

The supervisor is able to setup and delete up to other 5 users.

User Number 2: for Supervisor

User Number 3 - 7: for other 5 user.

- **To set New Supervisor Code by Master:**

To set up: Press then **Master Code** then press , enter **New Supervisor Code** then press , enter **New Supervisor Code** again then press to confirm.

To delete: Press then **Master Code** then press

- **To set New User Code by Master / Supervisor :**

To set up: Press then **Master Code / Supervisor Code** then press then enter the User Number (Could be from 3 to 7) then press , enter **New User Code** then press , enter **New User Code** again then press to confirm.

To delete: Press then **Master Code / Supervisor Code** then press then enter the User Number the press

Changing Supervisor Code by supervisor:

Please keep the door at open position during the whole processing until fully ensure that the code is changed correctly.

For security reasons, please change to your own code after the first opening. Your code can be set up to 10 digits

- Open the safe door

- Press then enter **Supervisor Code**, then press . Orange light on with one beep.

- Press , press and then enter **New Supervise Code** then press

- Enter **New Supervise Code** again then press to confirm.

- Orange light on with one beep means the Master Code has been change successful

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233

Unit 9 / 376 Newbridge Road, Moorebank NSW 2170

Web site: www.qnnsafe.com.au

Email: info@qnnsafe.com.au

Phone: 02-87982669

- Keep the door open, check and remember the code



Orange light off with two beeps means changing is fault. And the old Supervise Code is still in place.

Changing User Code by user:


Please keep the door at opening position during the whole processing until fully ensure that the code is changed correctly.

For security reasons, please change to your own code after the first opening. Your code can be set up to 10 digits

- Open the safe door

- Press  then enter **User Code**, then press . Orange light on with one beep.

- then enter **New User Code** then press 

- Enter **New User Code** again then press  to confirm.







- Orange light on with one beep means the Master Code has been change successful







- Keep the door open, check and remember the code







Orange light off with two beeps means changing is fault. And the old Code is still in place.

Other features:

- **Dual control mode:** safe needs to be opened under two digital codes. There are two dual control mode.

- ◆ Press  then **Master Code** then press , press  , press  .
Control by any 2 normal user (User Number 3 – 7)

- ◆ Press  then **Master Code** then press , press  , press  .
Control by one of the Master Code or Supervisor Code with one normal user (User Number 3 – 7)

- ◆ **To delete the Dual control mode:** Press  then **Master Code** then press ,
press  , press  . Go back to the Single control mode.

QNN SAFE AUSTRALIA PTY LTD

ABN 47 168 078 233


Unit 9 / 376 Newbridge Road, Moorebank NSW 2170





Web site: www.qnnsafe.com.au









Email: info@qnnsafe.com.au

Phone: 02-87982669

- **Time delay function:** Time delay can be set from 60 seconds to 99 minutes.

- ◆ Press  will start the time delay period. During the time delay period, yellow light flash every 5 seconds and all keys are locked.
- ◆ SET light flash at last 10 seconds, and the period ended with two beeps.
- ◆ There are 2 minutes operation period before entering into the next Time delay

To activate: Press  then **Master Code** then press , @@ then press , @@ then press  to confirm. (@@: 01 – 99 minutes)

To de-activate: Press  then **Master Code** then press ,   then press ,   then press  to confirm.

Cautions:

- **When the green light change to yellow, it means that the batteries need to be replaced. Please replace new batteries as soon as possible.**