


Nokia Wireless Plug-in Car Handsfree HF-35W



9249090/1

DECLARATION OF CONFORMITY

We, NOKIA CORPORATION, declare under our sole responsibility that the product HF-35W is in conformity with the provisions of the following Council Directive: 1999/5/EC.

A copy of the Declaration of Conformity can be found from http://www.nokia.com/phones/declaration_of_conformity/.

CE 0678

The crossed-out wheeled bin means that within the European Union the product must be taken to separate collection at the product end-of-life. Do not dispose of these products as unsorted municipal waste.

© 2006 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia and Nokia Connecting People are registered trademarks of Nokia Corporation. Other product and company names

mentioned herein may be trademarks or tradenames of their respective owners.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products may vary by region. Please check with the Nokia dealer nearest to you.

Unauthorized changes or modifications to this device may void the user's authority to operate the equipment.

Export Controls

This device may contain commodities,

technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

For your safety

Read these simple guidelines. Not following them may be dangerous or illegal.



Road safety comes first
Obey all local laws. Always keep your hands free to operate the vehicle while



Interference

All wireless devices may be susceptible to interference, which could affect performance.

driving. Your first consideration while driving should be road safety.

Introduction

This easy fit product allows you to make and receive calls hands free in your car. You can connect the handsfree to a compatible phone that

supports Bluetooth wireless technology.

Read this user guide carefully before using the handsfree. Also read the user guide for your phone, which

provides important safety and maintenance information. Keep the handsfree out of reach of small children.

Bluetooth wireless technology

Bluetooth wireless technology allows you to connect compatible communication devices without cables. In a Bluetooth connection, the phone and the handsfree should be within 10 meters (30 feet) of each other. Connections can be subject to interference from obstructions, such as walls, or other electronic devices.

Get started

Before using the handsfree, you must install it in the car, and pair it with a compatible phone.

The handsfree is compliant with the Bluetooth Specification 1.2 supporting the following profiles: Handsfree Profile 1.0 and Headset Profile 1.1. Check with the manufacturers of other devices to determine their compatibility with this device.

There may be restrictions on using Bluetooth technology in some locations. Check with your local authorities or service provider.

Parts

The handsfree contains the following parts shown at the start of this guide:

- Tilttable cigarette lighter plug (1)
- Speaker (2)

- Indicator light (3)
- Function key (4)
- Volume keys (5)
- Microphone (6)

Install the handsfree in the car

To function properly, the handsfree must be connected to the cigarette lighter socket of the car, and power must be supplied by the 12 volt car battery.

Insert the handsfree into the cigarette lighter socket. You can tilt the cigarette lighter plug to the desired angle (up to 90 degrees). Do not try to force the plug to tilt more.

Ensure that the handsfree is properly inserted in the cigarette lighter socket, and does not interfere with the normal operation of the car.

In some car models, the cigarette lighter socket is powered by the car battery even when you remove the

ignition key. In those cases, the car battery might be discharged if the handsfree is left on, or if the handsfree is turned off but connected to the cigarette lighter socket for a long time. Contact the vehicle manufacturer for more information.

Switch the handsfree on or off

To switch on, plug the handsfree into the cigarette lighter socket, or if already inserted in the cigarette lighter socket, press and hold the function key. When the handsfree is switched on, the indicator light flashes blue.

To switch off, press and hold the function key until the indicator light briefly flashes red, or pull the handsfree out from the cigarette lighter socket.

Pair the handsfree with a phone

1. Switch on your phone.

2. Ensure that the handsfree is installed properly and switched off.
3. Press and hold the function key until the indicator light alternately flashes blue and red.
4. Activate the Bluetooth feature on the phone, and set the phone to search for Bluetooth devices. See the user guide of your phone.
5. Select the handsfree (Nokia HF-35W) from the list.
6. Enter the Bluetooth passcode 0000 to pair and connect the handsfree to your phone. In some phones you may need to make the connection separately after pairing. See the user guide of your phone.

If the pairing is successful, the indicator light flashes blue five times, and the handsfree sounds a long beep and appears in the phone menu

where you can view the currently paired Bluetooth devices.

You can set your phone to connect with the handsfree automatically when the handsfree is switched on. To do this in Nokia phones, change your paired device settings in the Bluetooth menu.

To disconnect the handsfree from your phone, switch off the handsfree, or disconnect the handsfree in the Bluetooth menu of the phone.

To reconnect the paired handsfree to your phone, ensure the Bluetooth feature is activated in the phone, and switch on the handsfree.

If you want to remove the pairing, you can do it in the Bluetooth menu of the phone.

Call handling

To adjust the volume during a call, use the volume keys on the handsfree.

To make a call, use your phone in the normal way when the handsfree is connected to your phone. Speak toward the handsfree microphone.

For optimal performance, check that there are no objects in front of the microphone and that the microphone is in front of the user, not beneath or behind.

If your phone supports redialing with the handsfree, briefly press the function key twice when no call is in progress.

If your phone supports voice dialing with the handsfree, press and hold the function key when no call is in progress, and proceed as described in the user guide of your phone.

When you receive a call, you hear a ringing tone through the handsfree speaker. To answer the call, press the function key, or use the phone keys. To reject the call, press and hold either volume key until the handsfree beeps twice.

To end a call, press the function key, or use the phone keys.

Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions

below will help you protect your warranty coverage.

- Keep all accessories and enhancements out of the reach of small children.
 - Keep the device dry. Precipitation, humidity and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.
 - Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
 - Do not store the device in hot areas. High temperatures can shorten the life of electronic devices and warp or melt certain plastics.
 - Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
 - Do not attempt to open the device.
 - Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
 - Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
 - Do not paint the device. Paint can clog the moving parts, microphone, or speaker, and prevent proper operation.
- If the device is not working properly, take it to the nearest authorized service facility for service.

Additional safety information

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, and air bag systems. For more information, check with the manufacturer or its representative of your vehicle or any equipment that has been added.

Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment

as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.