


Features



- Pre-charged and ready to use
- Up to 12 hours extra talk and play time
- Built-in LED flashlight
- Optimized to quickly charge the latest iPhone and Android phones
- Multi-function switch (charge, off, flashlight)
- Power indicator light
- Up-to 3 Months super long stand-by time
- High Performance Li-ion battery with 500+ life cycles

TENERGY CORPORATION

TENERGY®

Tenergy Corporation
Fremont, CA 94539, USA
Tel: (510) 687-0388, Fax: (510) 687-0328
www.Tenergy.com

TENERGY®



LITE3000

Mobile Power Bank + Flashlight

Please carefully read the instruction before using.

INSTRUCTION MANUAL

Introduction


Thank you for purchasing Tenergy Lite3000 Mobile Power Bank. It provides one full backup charge for virtually any smartphone. It's slim, elegant design fits conveniently in any bag or purse giving users power on the go. Included LED flashlight provides extra convenience and security.

Package Content

- Tenergy Lite3000 Mobile Power Bank
- Micro USB recharging cable
- User's manual

Quick start

1. Charge Lite3000 Mobile Power Bank to full from a computer or USB charger with included Micro USB cable.
2. Slide multi-function switch to ⚡ turn it on.
3. Connect your mobile devices to the charger and verify charging takes place.
4. Slide multi-function switch to ➤ turn on LED flashlight.



Operation Instructions

Charging devices - output

- Slide multi-function switch to ⚡ turn it on.
- Connect your mobile devices to the charger and verify charging takes place.

Recharging - input

- The first time use or when the Power Bank needs to be recharged, use included Micro USB cable to connect the battery to any USB power source such as a wall USB charger, car USB charger or a computer's USB port.
- Verify if LEDs light up or not.
- LED indicator will turn green to indicate that the power bank is fully charged.

Maintenance

To keep your Power Bank operating to its fullest potential, make sure to do the following:

1. Re-charge your Power Bank once every three months even if not being used.
2. Keep Power Bank in a dry environment and avoid moisture or corrosive materials.
3. Do not wash the Power Bank with harsh chemicals, soaps or detergents.

Warning

Read all of the instructions and warnings prior to using the product. Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or hazards, causing serious and/or fatal injury and/or property damage.

1. Do not modify, disassemble, open, drop, crush, puncture or shred the product.
2. Do not expose the product to rain or water.
3. Keep away from open flames or sunlight to prevent heat built-up
4. Keep away from high voltage devices (e.g. power lines)
5. This product is not a toy, keep away from small children. Insure that all persons who use this product read and follow all warnings and instructions.

Specifications

- Battery: 3000mAh Lithium Ion
- Input: 5V DC, 1A
- Output: 5V DC, 1A
- Charging time: approx. 4hrs
- Dimension: 105mm x 23mm x 23mm

Item No. 51102 / 51103 / 51104 / 51105

