

A C T 6 0 0 0

Advanced Communication Tester

SINE SIGNAL & NOISE GENERATOR - SELECTIVE LEVEL METER
CROSS TALK METER - SPECTRUM & NETWORK ANALYZER
LONGITUDINAL BALANCE & RETURN LOSS METER
MICROINTERRUPTION & IMPULSIVE NOISE METER
VOLTAGE - RESISTANCE - CAPACITANCE METER
TDR & RESISTANCE FAULT LOCATOR
POTS DEVICE SIMULATOR

ALL ON THE PALM OF YOUR HAND!

This new instrument combining various kinds of transmission, metallic and special tests, may be considered up to today the most advanced Test Set for qualifying and maintenance of advanced transmission systems and copper pairs used for various telecommunication services:

•POTS •ISDN •T1 •E1 •HDSL 1/2P •SHDSL •ADSL •ADSL2+ •VDSL2



ERGONOMIC CHARACTERISTICS

One of **ACT6000** most interesting features is the colour LCD high resolution graphic display, a real "window" on the most advanced measurements' world.

The alphanumeric keypad, as well as the function-keys, grant to the instrument a high operating level. Moreover, don't miss to notice that, due to its accurate and intuitive "Human Machine and Graphics User Interface", this instrument doesn't need the help of the user's manual, if not to arrange and carry out unusual measurements and/or settings.

DATA-COMMUNICATION CHANNELS & COPPER PAIRS QUALIFICATION / CERTIFICATION

One **ACT6000** can perform easy and quick "Single-End Line Tests" or very accurate "End-to-End Line Tests" if coupled with another **ACT6000**. The wide kind of measurements of the **ACT6000** allows the qualification and certification on various communication carriers and copper pairs used for digital streams with a frequency occupancy up to 6 MHz (or 30 MHz optional); moreover, the instrument can automatically extrapolate the ADSL and VDSL maximum expected data rate of the copper line under test.

COPPER PAIRS DIAGNOSTIC & FAULTS FINDING / LOCATION

ACT6000 can be configured for high troubleshooting mission, by special functions and internal optional modules.

The complete adoption of these modules allows the simple and fast finding and localization of anomalies and/or faults on the copper line and communication systems.

ACT6000 – TECHNICAL CHARACTERISTICS

General	
	: ABS shielded for EMI / EMC compatibility.
	: • "RTX" connectors IN/OUT and "TX" OUT triple banana-jack;
	 polarized connector for external supply;
	RJ-45/4 connector for headset;
	 USB & RS232 port for PC connector;
	 USB for Pen-drive connector.
Display	: LCD color 320 x 240 pixel (1/4 VGA) back-lighted and reverse.
Power supply (internal)	: • rechargeable battery pack (green) 2 x 4 NiMh 1.2 V / 2.7A, for
	8 hours (mid.) of continue operation with battery state indication.
	 external: from 16,5 to 26,5 Vdc / max 2,5 Ah.
	: 150 x 210 x 50 mm / 1,5 Kg. (batteries included).
	: operative: 0 ÷ +45° C. / stock -20 ÷ +70° C.
Humidity range	
	: In/Out connectors up to 150 Vdc / 140 Vpp.
. ,	: ±1 ppm within the operating temperature ±2 ppm/year.
	: ±0.025% within the operating temp. ±0.025% / year. Directive 2004/108/CE, 89/336/EEC, Decree 2007/194
CE Mark - EIVIC	CISPR 11, ISO 14253 and CEI EN: 61326/A1/A2, 55011,
	61000-4-2, 61000-4-3, 61000-4-4, 61000-4-6, 61000-4-11.
Special Features and Setup	: ● Software update and Results Export using Pen Drive;
opecial i catales and octup	 Results Storage on internal flash memory;
	Remote control by USB port interface*.
	remote control by CCD port internace i
Signal Generator	
	: • base band: from 20 Hz to 20 kHz;
	 middle band: from 20 kHz to 6 MHz;
	 high band (optional): from 0.02 to 30 MHz.
•	: 1 Hz up to 9.999999 MHz; 10 Hz over 10.0 MHz.
Frequency setup mode	: manual on single frequency and steps mode on
	programmable band / steps.
	: -60 ÷ +20 dBm @ 150 Ω / 0.1 dB steps.
Output level accuracy	: ±0.2 dB from 400 Hz to 20 kHz @ 600 Ω;
	±0.2 dB up to 2 MHz, ±0.3 dB up to 6 MHz; @ 100 Ω;
Dalanced output impedances	±0.5 dB up to 30 MHz @ 100 Ω.
Balanced output impedances	: • base band: 150, 200 and 600 Ω;
	 middle band: 100, 110, 120, 135, 150 and 1350 Ω; high band 100 Ω.
Unhalanced output impedances	: 50 and 75 Ω by Banana/BNC optional adapter.
ombalancea output impedances.	. 30 and 73 12 by Banana/Bivo optional adapter.
White Noise Generator	: 1 kHz ÷ 6 MHz / -74 ÷ -144 dBm/Hz / 0.1 dB steps.
Signal & Level Meter	
Frequency range	: from 20 Hz to 6 MHz (two bands) base version;
	up to a 30 MHz (with EBM 30 optional module).
	: 1 Hz up to 9.999999 MHz; 10 Hz over 10.0 MHz.
	: absolute (dBm or dBV or Volt) or relative (dBr).
	: -120 ÷ +12 dBm @ 100 Ω / 0.1 dB Resolution.
Level meter accuracy	: ±0.2 dB from 400 Hz to 20 kHz @ 600 Ω;
	±0.2 dB up to 2 MHz, ±0.3 dB up to 6 MHz; @ 100 Ω;
Noise floor (TV OFF)	± 0.5 dB up to 30 MHz @ 100 Ω.
Noise floor (TX OFF)	
rrequericy inleter sensitivity	: ≤-40 dBm on wide band or selective mode.

^{*} by Advanced Software 2

Input impedances balanced	. : ● base band: 150, 200, 600 and >10 kΩ;
•	 middle band: 100, 110, 120, 135, 150 Ω;
	 high band 100 Ω.
Input impedances unbalanced	. : 50 and 75 Ω by Banana/BNC adapter.
•	.: • base band: psophometric; C-Message; 0.3 ? 3.4
	kHz, 0.02 ÷ 3.4 kHz, 0.3 ÷ 6.0 kHz, 0.02 ÷ 6.0 kHz,
	0.3 ÷ 15.0 kHz, 0.02 ÷ 15.0 kHz, 0.3 ÷ 20.0 kHz,
	20 ÷ 20.0 kHz, 20.0 kHz flat,
	middle/high band: E, F, G and VDSL.2 -12 -17 and 30.
Selective filters / notch	. : • base band: (200 Hz ÷ 20 kHz) pass band and notch
	for S/N+D (dB and %) test; 10 Hz @ fo <200 Hz;
	5% fo @ >200Hz fo <4 kHz; 200 Hz @ fo >4 kHz.
	selective for telegr.chann.: 120, 240, 360, 480 Hz.
	• high band (20 kHz ÷ 6 or 30 MHz) selective: 25,
	100, 200, 400 Hz and 1.74, 3.1, 4.0, 8.0, 16.0 kHz.
Spectrum and Network Analyz	er
Spectrum and Network Analyz Frequency range	
	. : ● from 200 Hz to 6 MHz (two band) base version;
Frequency range	 . : • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30).
Frequency range	. : ● from 200 Hz to 6 MHz (two band) base version;
Input impedances balanced	 .: • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). .: • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω.
Input impedances balanced Input impedances unbalanced	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). : • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter.
Input impedances balanced Input impedances unbalanced Base band	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). : • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window).
Input impedances balanced Input impedances unbalanced Base band Span	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz.
Input impedances balanced Input impedances unbalanced Base band Span	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). : • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div. : 625, 1.250, 2.500 Hz / div.;
Input impedances balanced Input impedances unbalanced - Base band Span Resolution horizz. / vertical	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div.: 625, 1.250, 2.500 Hz / div.; - 192 pixel / 8 div.: 1, 2, 3 ÷ 20 dB / div.
Input impedances balanced Input impedances unbalanced - Base band Span Resolution horizz. / vertical Resolution (BW)	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div.: 625, 1.250, 2.500 Hz / div.; - 192 pixel / 8 div.: 1, 2, 3 ÷ 20 dB / div. : 50, 100, 200 Hz (other resolutions are interpolated).
Input impedances balanced Input impedances unbalanced - Base band Span Resolution horizz. / vertical Resolution (BW)	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div.: 625, 1.250, 2.500 Hz / div.; - 192 pixel / 8 div.: 1, 2, 3 ÷ 20 dB / div. : 50, 100, 200 Hz (other resolutions are interpolated). : 1 kHz to 6 (30) MHz, by Digital SSB quad. conversion.
Input impedances balanced Input impedances unbalanced - Base band Span Resolution horizz. / vertical Resolution (BW) - Middle band Span	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). : • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div. : 625, 1.250, 2.500 Hz / div.; - 192 pixel / 8 div.: 1, 2, 3 ÷ 20 dB / div. : 50, 100, 200 Hz (other resolutions are interpolated). : 1 kHz to 6 (30) MHz, by Digital SSB quad. conversion. : 30 ranges: from 10 to 8000 kHz, 10 per decade.
Input impedances balanced Input impedances unbalanced - Base band Span Resolution horizz. / vertical Resolution (BW) - Middle band Span	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). : • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div.: 625, 1.250, 2.500 Hz / div.; - 192 pixel / 8 div.: 1, 2, 3 ÷ 20 dB / div. : 50, 100, 200 Hz (other resolutions are interpolated). : 1 kHz to 6 (30) MHz, by Digital SSB quad. conversion. : 30 ranges: from 10 to 8000 kHz, 10 per decade. : - 250 pixel / 10 div: 1, 2, 4, 8, 16 ÷ 800 kHz / div.
Input impedances balanced Input impedances unbalanced - Base band Span Resolution horizz. / vertical Resolution (BW) - Middle band Span Resolution horizz. / vertical	 • from 200 Hz to 6 MHz (two band) base version; • up to 30 MHz (by optional module EBM 30). : • base band: 150, 200, 600 and >10 kΩ balance; • middle band: 100, 110, 120, 135, 150 Ω; • high band 100 Ω. : 50 and 75 Ω by Banana/BNC optional adapter. : 200 ÷ 25000 Hz, by FFT analyzer (Kaiser window). : 6250, 12500 and 25000 Hz. : - 250 pixel / 10 div. : 625, 1.250, 2.500 Hz / div.; - 192 pixel / 8 div.: 1, 2, 3 ÷ 20 dB / div. : 50, 100, 200 Hz (other resolutions are interpolated). : 1 kHz to 6 (30) MHz, by Digital SSB quad. conversion. : 30 ranges: from 10 to 8000 kHz, 10 per decade.

- **High band** measure method : Double conversion receiver by int. optional module.

Span: 0 ÷ 12, 0 ÷ 18 and 0 ÷ 30 MHz.

Level reading mode: absolute: dBm, dBm/Hz, dBV and dBr (relative). Measurement mode.....: normal, peak (max, mean or min. value), 2 Wires +/-

> (for Return-Loss measurement), 2 Wires +/+ (for Longitudinal Balancement measurement) and 4 Wires.

Input range: $\leq -100 \div +12 \text{ dBm} @ 100 \Omega$

Noise floor: \leq -140 dBm/Hz @ 100 Ω (high band) with 16 kHz filter.

Resolution marker (lev. / freq.) ...: 0.1 dB / as selected resolution (BW).

Network Analyzer: by tracking generator or single freq. in 2/4 wires mode.

Mix measurements Generator/Meter and Network Analyzer

• Cross-Talk (4 Wires)

Test mode.....: Near-End (Single-End) and Far-End (End-to-End)

single frequency or scanner on limited band.

Frequency range: 200 Hz ÷ 6 MHz (up to 30 MHz - EBM 30 opt. module)

Measurement accuracy: up to 2 MHz: ±1 dB / between 0 ÷ -90 dB;

up to 6 MHz: ±2 dB / between 0 ÷ -86 dB:

up to 30 MHz: ± 3 dB / between 0 \div -80 dB.

Intrinsic crosstalk.....: ≤- 90 dB (with precise resistive load).

Frequency range	single frequency or scanner on limited band. 200 Hz ÷ 6 MHz (up to 30 MHz - EBM 30 opt. module) up to 2 MHz: ±1 dB / between 0 ÷ -50 dB; up to 6 MHz: ±2 dB / between 0 ÷ -46 dB; up to 30 MHz: ±3 dB / between 0 ÷ -40 dB.
Frequency range	single frequency or scanner on limited band.
Measuring Mode / readout Operating Band Graphic Extrapolation Operative Impedance Accuracy	: 20 kHz ÷ 6MHz and 30 MHz.
Event Tests	
Monitoring time Events indicators	:-3 ÷-20 dB - 2 kHz Test Tone (default) or on programmable frequency up to 6 MHz.
- DSL bands / PB filters: - Monitoring time Events indicators	: 0 ÷ -60 dBm. : 200 ÷ 12,000 Hz Flat, 600 ÷ 3,000 Hz, 300 ÷ 500 Hz. : 20 kHz ÷ 6 / 30 MHz (some sectors of E,F,G and VDSL filter) **
Special Measurements	
 Line Immunity by White Noise Output level range 	: -70 ÷ -144 dBm/Hz @ Zref. 100Ω - 0.1 dB Resolution. : 100, 120, 135, 150 and 1350 Ω (balanced).
Zoom:	: 90, 180, 450, 900, 1800, 3600, 7200 m. @ 0.600 PVF. : vertical: -8 ÷ +77 dB; horizontal : 1x, 2x, 4x. : - minimum range: about 0.4 meters (or 1 feet);
Operative mode	- maximum range: about 40 meters (or 100 feet). single line (2 wires), Crosstalk (4 Wire), Differential by relative comparison with other line; Monitoring to events localization by Peak mode (Sample & Hold).
	short and long: 2.2 Vpp; Boost: 5.5 Vpp.

Pulse length.....: automatic on range selection, from 10 to 5000 ns.; IN/OUT impedance.....: 100, 110, 120, 135, 150 Ω (balanced). TGC (automatic gain control)....: 0 ÷ 6 dB/km. Propagation velocity.....: PVF: 0.300 to 0.999 o PV (90 to 300 m/ μ s).

• **Digital Multimeter DC / AC** (by DMM optional module) Measuring mode.....: automatic between a-b; a-c (Gnd); b-c (Gnd) and reverse. DC Voltage, Range / Accuracy...: 0 ÷ 140 Vdc / ≤ 2% of reading ±1 digit. AC Voltage, Range / Accuracy ... : $0 \div 100 \text{ Vrms}$ / $\leq 2\%$ of reading $\pm 1 \text{ digit}$ (up to 1kHz). Resistance / Insulation - Test Voltage: ≤ 100 Vdc (with current limitation 1mA max). - Range / Accuracy.....: 5 $\Omega \div 1$ G Ω /: $\leq 2\%$ of reading \pm digit. LINE LENGTH BY LOOP RESISTANCE - Line length evaluation: (as function of measured resistance) - Line Gauges setting from 0.4 to 0.9 mm or from AWG 26 to AWG 19. Line Resistance correction Line Temperature setting from 1.01 to 1.60 x standard copper resistance. set from -20°? +60° C. - Range / Resolution.....: 0 to 99.999 kUnits (meters or feet) / 1 units. DC CAPACITANCE (time of DC discharge method) - Test Voltage: ≤ 100 Vdc - Range / Accuracy.....: > 10 nF ÷ 10 μF / ≤5% of reading ± 1 digit. AC CAPACITANCE (by capacitive bridge) Measuring mode.....: by 1 kHz tone – 1.1 Vpp between a-b wires. Range / Resolution: 0.1 to 3000 nF / 0.1 nF. Accuracy.....: \pm 1% of reading \pm 1 nF @ C <500 nF; \pm 5% of reading \pm 1 digit @ C >500 nF and < 3000 nF. LINE LENGTH BY CAPACITANCE Line length estimation.....: (as function of measured capacitance): Line Capacitance setup: 10.0 to 300.0 pF / Length Unit. Range / Resolution / Accuracy ...: 1 to 99999 Units (m. or ft.) / 1 units / as derived from measured capacitance. RFL (Resistance Fault Locator) - Loop resistance.....: 4 kΩ maximum. - Fault resistance : from 100 Ω to 20 M Ω maximum. - Accuracy of RTF @ 1 M? : ± 0.1% of Loop resistance. - Readout: graphic representation and action help. RBAL (Resistance Balancement): starting from 5 Ω . - Readout: graphic representation and action help. MULTI GAUGES facilities **.....: to set 3 sectors of multi gauges lines to compute the line length or fault localization by loop resistance / line insulation. • POTS Subscriber Simulator (by optional module installed on DMM module) Dial Encoder.....: - Pulse, programmable on duration/ratio (default 100 ms / 40/60%); - DTMF std. tones, programmable on Level, Duration, Inter-tone. Ring Detect. Range & Meas: Level: 10 ÷ 90 Vrms; Frequency: 15 ÷ 70 Hz. Ring Detector AC Load............: R 7310 $\Omega \pm 2\%$ in series + 940nF $\pm 10\%$ capacitor. Ring current self limitation: ≤ 15 mA peak; safety fold-back limited.

On Hook / Break & Make specs.. : $R = 120 \Omega \pm 2\%$ @ I = 100 mA; Voffset = 4 Vdc.

Single End Line Tests for line pre-qualification *

With single ACT6000 on open lines, 2 or [4] Wire mode:

One button test (automatic sequence):

Metallics: AC / DC Voltage, DC Insulation, AC / DC Capacitance, End-Of-Line (by TDR).

<u>Transmissives (Wide band)</u>: Noise (local), Return-Loss, Longitudinal Balance-Loss, "FDR" Insertion-loss & frequency response estimation, Far-end Noise (estimation), SNR prediction, ADSL - ADSL2+ and VDSL 1 / 2 ***, Bit-Rate prediction, [NEXT].

Single transmissives tests (real time spectral readout): Noise, Return-Loss, Longitudinal Balance-Loss, Next and PSD.

Automatic End-to-End Test for line qualification **

With two ACT6000 (Master/Slave configuration) for Double-End Tests, 2 or [4] Wire mode:

Only Transmissives (base and wide band): Noise (bilateral), Return-Loss (bilateral), Longitudinal Balance-Loss (bilateral "LCTL"), Insertion-Loss, SNR (bilateral), ADSL - ADSL2+ and VDSL*** Bit-Rate evaluation (Up & Down stream), [NEXT and FEXT].

Masks for pre-configured SELT or DELT line tests *

• Wide band: ISDN, HDSL 1p, HDSL 2p, E1, T1, SHDSL, ADSL, ADSL2+ and VDSL2 -12, 17, 30.

Masks for pre-configured DELT telephone tests **

• Base band: M1040, M1020, G.712E2, EURO16k, EURO32k, MIL16k, MIL32k

Notes:

- * by Advanced Software 1
- ** by Advanced Software 2
- *** by adoption of EBM 30 optional module

Supplied Accessories (base kit):

ACT6000 Base Instrument, included:

- Nylon Carrying Case with pocket for accessories;
- User Guide (English or Italian language, as requested):
- AC Power Supply and Battery Charger (Line Input: 100 220 Vac; Output: 20 Vdc; 1.4A);
- Banana-Banana + Crocodiles shielded cable (2.30m total length);
- Ground Cable unipolar Banana-Crocodile cable;

Extra cost Accessories and Optional Modules

- **ASW1 Advanced Software 1** (see the above description).
- **ASW2 Advanced Software 2** (to be develop), it will include the End-to-End (Master/Slave) line test, PC utility programs to: SELT Remote Control, SW Update, Capture Screen, Export & Read Saved Tests, Masks Editor etc..
- ACT-11 POTS Module (Subscriber Simulator Module for POTS for signalling tests):
- ACT-12 DMM Module (Digital Multimeter Module for metallic tests);
- ACT-13 EBM30 Module (Extension Band Module for 30 MHz operation);
- ACT-14 USB Pen-Drive 4 GB;
- ACT-15 Probes to perform Medium & High Band PSD measurement on lines fed;
- ALT-05 Headset with 2m cable and RJ-45/4 connector;
- **ALT-09** Resistive Termination Set (100, 120, 135, 150 and 600?);
- ALT-16 Banana to BNC Adapter.

ATEN S.r.l. - Via dei Lavoratori, 180 - 04100 LATINA - ITALY

Tel.: +39 0773 240696 Fax: +39 0773 240676 - e-mail: sales@aten.it - Web: www.aten.it